

COMBIER

SMART TOILET SEAT
USER'S MANUAL
Please read this instruction carefully before using

Model CMA102 / CMA102S-B / CMA105 / CMA105S

North American Version 2021.10-1

3 Installation ways

Precaution before installation

1.Ensure that the water pressure range of the inlet is between 0.05-0.75Mpa.
2.Be sure to use the original accessories and consumables.
3.Please do not switch on the power until the installation is completed to avoid failure.

Method of mounting base

1.Draw the mounting base from the machine.

2.Install the accessories as shown in the diagram.

Screw

Gasket

Steel disc

Mounting base

Anchoring rubber

4

1 Components

CMA102

CMA102S-B

CMA105

CMA105S

1

Lid

Water inlet

Warm air

Posterior wash

Skin sensor

Warm seat

Feminine wash

Anion

Side panel

2

2 Accessories

A

B

C

D

E

F

	Name	Quota
A	Three-way valve	1 PCS
B	PE pipe	1 PCS
C	Screw	2 PCS

	Name	Quota
D	Steel disc	2 PCS
E	Anchoring rubber	2 PCS
F	Gasket	2 PCS

3

4 Installation and removal

1.Push with two hands when install the machine onto the toilet, and make sure the installation is in place.

2.Pull outward with two hands when separate the machine from the toilet.

6

CMA102

CMA105

STOP

CLEANING

BIDET

DRY

AUTO

HI

WATER-DRY

LO

SAVE ELE

LIGHT

POWER

7

CMA102S-B

CMA105S

STOP

CLEANING-SPA

BIDET-SPA

DRY

DEFECATION

AUTO

CHILDREN

POSITION

PRESSURE

POWER

LIGHT

SAVE ELE

AIR TEMP

WATER TEMP

SEAT TEMP

INTELLIGENT TOILET REMOTE CONTROL

8

5 Operation (detailed)

Preparation

1.When you sit on the unit, please sit down on the central position in order to activate the sensor.
2.When you sit down on the seat, the buzzer will end with One Solid Beep. You can use it normally.
3.When the unit is occupied the deodorizer will start working automatically.

CLEANSING

■CLEANSING 1.(CLEANING)

-Press " CLEANING " (), the nozzle comes out and sprays warm water to posterior. the nozzle moves back and forth automatically. Press again to stop nozzle move.

■CLEANSING 2.(BIDET)

-Press " BIDET " () the nozzle comes out and sprays warm water to feminine area. the nozzle moves back and forth automatically.

■CLEANSING (Model CMA102S-B/CMA105S) 3.(DEFECATION)

-Press " DEFECATION " (), the nozzle sprays a highly concentrated water stream that can induce a smooth bowel movement.

■CLEANSING 4.

This product has an automatic nozzle self-cleaning function that cleans the nozzle before and after each use.

9

NOZZLE POSITION ADJUSTMENT

■Position is adjustable to the desired position by pressing " POSITION " () button.
(Model CMA102S-B/CMA105S)

WATER PRESSURE ADJUSTMENT

■Press " WATER pressure-high & Low button" (H/LLO) to adjust the water pressure.

WARM AIR DRYER

■WARM AIR DRYER 1.(DRY)

-Press " Dry " (), to turn on dryer.

■WARM AIR ADJUSTMENT 2.(AIR TEMP)

-Press " DRY-high & Low button" (H/LLO) to adjust the warm air temperature, The dryer automatically stop in 3 minutes .

CHILDREN

■For child use , press " CHILDREN " () buttonfirst, nozzle position water pressure and seat temperature will be adjusted. (Model CMA102S-B/CMA105S)

AUTO

■Press " AUTO " () this button to start the automatic cleaning, which automatically running by the sequence of " cleaning-massage-dry-stop"

10

WATER TEMP ADJUSTMENT (Model CMA102S-B/CMA105S)

■Press "WATERTEMP-high & Low button " () to adjust the temperature of water.

Level 1

Level 2

Level 3

OFF

High

Middle

Low

(Level1~3)

AIR TEMP ADJUSTMENT (Model CMA102S-B/CMA105S)

■Press " AIR TEMP " ()-high & Low button to Adjust the warm air temperature, The dryer automatically stop in 3minutes.

Level 1

Level 2

Level 3

OFF

High

Middle

Low

(Level1~3)

SEAT TEMP ADJUSTMENT (Model CMA102S-B/CMA105S)

■The temperature of seat can be adjusted to the desired level by () button

Level 1

Level 2

Level 3

OFF

High

Middle

Low

(Level1~3)

11

LIGHT

■Press " LIGHT " () this button to turn on / off the night light.

SAVE ELE

■Press " SAVE ELE " () the button to save electricity, Press again to recover to theoriginal state.

STOP

■Press" STOP " ()this button to stop all operations.

POWER

■It refers to the power switch.

BUZZER SOUND

■Press the "POWER"button to turn off, then press the "STOP" button hear a "beep", you can set the buzzer sound to be off or on.

SENSOR

■In the boot state press the "STOP" button hear a "beep", you can set the sensor to off or on.

12

6 Pilot run

Tips : the spraying time will be delayed by 5-10 seconds for the first time using after installation which is normal phenomenon,not a fault.

For operation

1.Connect the power plug to the socket of 110V/220V voltage.At this time, the floodlight and water temperature light flash.
2.Turn on the water source, and the water temperature light flashes. After 30 seconds, the water temperature light stops flashing and stays on, indicating that the machine has completed the self-test.

Function confirm

1.infirm the functions accroding to the instructions.

13

7 Maintenance

A drainage when not in use for a long time

1.Please unplug the power supply
2.Turn off the water supply
3.Pull the machine outward from the toilet
4.Screw out the WATER SCREW(the positon indicated on the diagram) to drain the water
5.Tighten the WATER SCREW and replace the machine

Pull outward

External body cleaning method

1.Main surface should be wiped with sponge or soft dishcloth or the dishcloth with sticky neutral detergent.
2.Note: do not use diluent, light gasoline, detergent or chemical to wipe, do not use pesticides, aromatic agents, deodorant,etc.

14

8 Quick Guide Q & A

Q1

A1

Q2

A2

Q3

A3

15

Q4

A4

Q5

A5

Q6

A6

Q7

A7

Q8

A8

16

9 Maintenance

Please follow the safety information below

Please use the new pipe attached in the product

Self-disassembly or Self-repair are forbidden

Leaving water or detergent on the product or plug is forbidden, in case of accident or breakdown

In case of accident, do not touch the plug with wet hands

Ensure the water is pure and clean

17

! WARNING

1.Don't use the lacquer thinner,gasoline,medicine,medicine,detergent or pesticide to clean this product.
2.Don't put any aromatic or medicine in water tank.
3.When sitting on this smart toilet for a long period of time,please regulate the seat temperature to the lower grade.
4.In case the product is electrified,but no water was supplied to it,don't place it upside down, otherwise it may result in troubles of heating pipe.
5.When the product is used by persons(including children)with body,sensory,mental deficiency, or lack of common sense,please pay your attention and prevent them from low temperature burning.
6.It's strictly prohibited to step on the cover plate,seat ring,or operation panel,it's not very suitable for children to use it.
7.Cables and sockets used in the house must meet the requirements of national standards, all lines must be grounded reliably.It's strictly prohibited to use the patch board with two-hole or insufficient power to work as the extension line.

This product si prohibited in the high temperature or place in storage and use of flammable and explosive.

18

10 Self-trouble-removal \ Technical parameter

Troubles	Inspect ways	Solutions
Not activated	Water pressure	Insert the power plug into the socket
	Make sure the power plug has been inserted into the socket	Pull out the power plug from the socket and insert it again
No water or a little	Make sure the water supply is normal and the water gauge is open	Ensure the water supply is working normally
	If the nozzle is blocked	Clean the nozzle by toothbrush
Leakage of water	Inspect all the joint of pipes	Back up all the joint of pipes
	Cold water or cold seat	Adjust the temp of water and seat to higher levels

Specifications	AC 110V 50Hz 1500W		
Water supply	Way	Connect to water pipe (0.5-0.75Mpa)	
	Water pressure	0.05-0.75Mpa	
Cleaning	Water amount of posterior wash	0.7L/min	
	Water amount of feminine wash	0.85L/min	
Heater	Temp of water	3 levels(LOW,MED,HIGH)	
	Heating power	1500W	
Warm air dry	Safety protection	TDS(water temperature sensor/WAT)	
	Temp of seat	3 levels(LOW,MED,HIGH)	
Leakage of water	Heating power	200W	
	Safety protection	TDS(water temperature sensor/thermal cutoff)	
Other safety protection	Temp of air	3 levels(LOW,MED,HIGH)	
	Safety protection	TDS(thermal cutoff)	
Product class	Leakage protective plug	Weight	5.9kg
	Handrail operation	Length of wire	1.5m
Dimension	Production	(CMA102:1037*460*140mm / CMA102S-B:1037*380*140mm)	
	TX	DC 3V from battery	
Remote control parameter	RX	AC 100-240V 50/60Hz	
	Operation frequency	433MHz	

19

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.