

instructions

Statement:

First of all, thank you for using our products! Please read this manual before use and use the product correctly. For better service, the contents of this user manual may be changed. Changes due to product performance and function will not be notified.

Product model: BG-01

Product Name: smart audio glasses

This product is Bluetooth glasses with stereo sound, easy to operate, beautiful and practical, easy to carry.

Designed and manufactured in China.

1、 Product parameters:

1. Frame color: black lens color: Black
2. Frame material: nylon, PC + ABS lens material: Nylon
3. Frame style: 2007 frame size: 65 □ 16-140
4. Bluetooth protocol: 5.0
5. Charging time: 2 hours
6. Talk time: 6 hours
7. Music Playing: 6 hours
8. Standby time: 200 hours
9. Battery capacity: 120mAh * 2
10. Charging current: DC5V, 200mA
11. Channel: dual speaker, stereo

2、 Packing list:

Glasses * 1; charging line * 1; glasses cloth * 1; glasses box * 1; instruction manual * 1; warranty card * 1;

3、 Operating instructions:

Tip: in order to find the touch button conveniently and quickly, you can use your fingers to slide from the middle part of the mirror leg to the front of the mirror leg until you touch the touch button. At this time, if your fingers leave the touch button, it is a press operation.

Turn on the left and right mirror legs. Within 5 seconds before power on, the left and right mirror legs automatically form a team. After the team is completed, enter the Bluetooth connection mode. At this time, you can find the Bluetooth device and complete the connection.

- **On / off**

1. Turn on the spectacle leg and turn on the machine. The prompt sound "power surplus", and the indicator light flashes slowly.
2. Close the spectacle legs and turn off the machine. The prompt sound "turn off", and the indicator light is always on for 1 second.
3. If the mobile phone is not connected for 10 minutes, the product will shut down automatically, and the prompt sound "shut down".
4. In the power on state, click the left or right mirror leg 5 times in succession, and the corresponding mirror leg will be shut down separately, with the prompt "shut down".

- **Bluetooth pairing connection**

1. For the first pairing, the left and right mirror legs are automatically paired within 5 seconds after power on. The prompt sound "ready for pairing" and the indicator light flashes slowly.
2. In the power on state, click the key 4 times in succession and press the key for 10 seconds to clear the pairing record. The prompt sound "cleared pairing" and the indicator light flash twice.
3. When connecting back to the mobile phone, the prompt sound is "connecting the device"; when connecting with the mobile phone, the prompt sound is "connected"; when connecting with the mobile phone, the prompt sound is "disconnected".
4. When there is no pairing record, the power on automatically enters the pairing state. When there is a pairing record, it will automatically connect the last used mobile phone when the phone is turned on.

- **modulation**

Press and hold the right key to increase the volume and the prompt tone: "didi" and press and hold the left key to decrease the volume and the prompt tone: "didi"

- **Play music**

1. Next, click the right key three times.
2. On the previous song, quickly click the left key 3 times.
3. Music pause / play, click left or right once.

- **phone**

1. call reminder, different brands and models of mobile devices call reminder tone, feedback is different in this product.
2. to answer a call, click left or right once.
3. hang up and press left or right once.
4. to reject the call, click left or right twice.
5. when the current call is in progress and the third party calls, click the left or right button to keep the current call and answer the third party call; double click the left or right button to end the current call and answer the third party call.
6. In the three party call, click the left or right button to end the current call and answer the reserved call; double click the left or right button to keep the current call and answer the previous reserved call.
7. in the call, double-click the left or right button to switch between the phone and glasses.

- **Voice assistant**

Double click the left or right mirror leg button to wake up the mobile assistant and realize voice interaction.(it needs the support of mobile phone system. Different brands and models of mobile devices have different assistant functions.).

- **charge**

1. Low power alarm, prompt "low power" every 30 seconds, and the indicator light flashes once every 30 seconds.
2. Low power shutdown, prompt "battery power is low, about to shut down", indicator light is on for 5 seconds.
3. When charging, the indicator light is in slow flashing state. After charging, the indicator light is always on.
4. the power of glasses will be displayed on the mobile terminal (it needs the support of the mobile system).

- **other**

Charging temperature range (0-45 °C), when charging beyond the temperature range, the indicator light flashes 3 times, indicating "unable to charge".

IVTips:

1. Please read the manual carefully before using the product and keep the manual.
2. For the first time, please fully charge the product.

3. If the product does not charge for a long time (more than two weeks), please charge it before use.
4. Do not wipe dirty lenses directly. Wet them first and then dry them with glasses cloth. Try to use suede and absorbent glasses cloth gently wipe clean, not vigorously wipe. When wiping, the glasses cloth should be wiped in the same direction, not back and forth, or on the lens.

5. Warning:

1. Before using this equipment, please read all safety information to ensure correct and safe use.
2. Use of charging wires not approved by the manufacturer may cause fire, explosion or other hazards.
3. Do not remove or repair or modify the product for any reason, otherwise it may cause fire, electronic breakdown or even complete damage to the product.
4. Please use the equipment within the temperature range of 0 °C ~ 35 °C, and store the equipment and its accessories within the range of - 20 °C ~ 45 °C. When the ambient temperature is too low or too high, it may cause equipment failure.
5. If the charging is completed, please disconnect the charger from the product and unplug the charger from the power socket. Do not charge for more than 12 hours.
6. Do not wet or soak the product in the liquid.
7. Please do not throw the product into the domestic garbage. Improper disposal may cause the battery to fire and explode. Please handle this product and other accessories according to local regulations.
8. This product has built-in non detachable lithium battery. It is forbidden to disassemble, impact, squeeze or put the battery into the fire. If there is serious expansion, please do not use it intermittently.
9. Do not put the magnetic suction charging line or the magnetic suction charging port of the mirror leg close to the metal object. If the magnet is adsorbed on the metal object, it may cause the contact short circuiting and lead to danger, so as to avoid scalding, burns and other personal injuries caused by the overheated battery.
10. Do not put the product or battery into the fire, otherwise it will cause fire or explosion.
11. Do not expose the glasses to the sun for a long time, or they will be easily deformed, aged and broken.
12. Please follow relevant laws and regulations and do not use in the following environments:
 - it is forbidden to use the equipment in the environment where inflammable and explosive oil gas or chemicals are stored near the gas station, oil depot and chemical warehouse.
 - please do not use this device in the hospital operating room, emergency room, deep treatment department, etc. in order to avoid interference with the work of medical instruments, please keep away from the cardiac pacemaker, Xin aid, cochlear implant and other medical devices when using this device, please keep the distance between this device and pacemaker more than 15cm.
 - to use this device near personal medical devices, consult your physician and device manufacturer.
 - please observe all safety warnings and regulations concerning the use of this device while driving.
 - do not use outdoors in thunderstorm weather to avoid lightning accident.
 - do not use the charger in the bathroom or other places with high humidity, otherwise it will cause electric shock, personal injury, fire and charger damage.
 - please comply with the relevant laws and regulations explicitly prohibited in any environment.

To avoid hearing loss, do not use high volume for a long time.

6. After sales:

Manufacturer: Shenzhen SKCT Technology Co., Ltd

Manufacturer: Guangdong Xiaolin Technology Co., Ltd

Address: No.68, wushaxing 1st Road, Chang'an Town, Dongguan City, Guangdong Province

Service Tel.: 0769-85688888

QSG:

instructions	Operation method	Tips
Power on	Open the mirror leg	Hello, power surplus
Shut down	Close the legs	Shut down
Answer	Click left / right	Toot
Hang up	Click left / right	Toot
Reject a call	Double click the left / right button	toot toot
Play / pause	Click left / right	Toot
Volume plus	Long press right	Didi
Vol	Long press left key	Didi
Last song	Three left click	Dudu Dudu
Next song	Three right click	Dudu Dudu
Start voice assistant	Double click the left / right button	toot toot
Clear pairing	Four hit extended press	Device list cleared
Charging	-	Blue light blinks slowly
full	-	Blue light always on

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Information

This device meets the government's requirements for exposure to radio waves.

This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the United States.

CE Statement

Hereby, [ShenZhen SKCT Technology Co.,Ltd.] declares that the radio equipment type [BG-01] is in compliance with Directive 2014/53/EU.

To prevent possible hearing damage, do not listen at high volume levels for long periods.



Caution

Risk of explosion if battery replaced by an incorrect type.

Dispose of used batteries according to the instructions.

RF Exposure Information

This device meets the government's requirements for exposure to radio waves.

This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by Europe.