

OSW-800N_说明书
材质: 100g铜版纸 形式: 骑马钉成册 尺寸: 55x85mm (成品)

Internal Use (内部公开)

Product Overview
Full Touchscreen, Home Button, Charge Cable, Welcome Guide, Wrist Strap, Charging Port, Heart Rate Sensor
Setting Up Your Smart Watch
For the best experience we recommend using the updated oraimo Health App for iOS and Android.
Pair With Your Phone
1. Get ready with the oraimo Health App, scan the QR code on your watch or find the oraimo Health App in one of these locations; (depending on your device)
2. When the App is installed, open it and follow the instructions that help you create your account, or login to your existing account.
3. Your account asks for information such as height, weight, and gender to make various calculations and tailor your experience using the app. You can modify your information in oraimo Health - Account - User.
4. Long press the Home Button of the watch to turn it on, follow the onscreen instructions to set up the language, and get ready pairing with the phone.
WELCOME GUIDE
oraimo Watch 3 Lite | OSW-800N |
* For safety issue, the product remains low capacity during shipping. Please fully charge the product before initial use!

Scan the QR code to pair:
Device, Pair the device, Connect with QR code
Use oraimo Health APP to scan QR code
EN 02

Getting To Know Your Smart Watch
Wrist Placement
For all-day wear, your watch should usually rest a finger's width below your wrist bone and lay flat, as you would normally wear a watch.
Charge Your Watch
Connect the metal contacts of the USB cable with the charging dock on the back of the watch. Put the watch on a flat surface and connect the other end of the USB cable to a power supply.
EN 03

Power On/Off
To turn on the watch, make sure that the device is fully charged and then long-press the Home button for 3 seconds.
Wake Up the Watch
Method 1: Press the Home button to light up the display.
Method 2: Turn your wrist. (This "Raise to Wake" function is active by default. You can turn it off by tapping the Raise to Wake icon.)
EN 04

Explore Functions with Full-screen Gesture
Swipe Right to enter the function menu.
Swipe Left to explore Daily Activities, Heart Rate, Blood Oxygen, Sleep, Weather, and more.
Swipe Down from the top to turn on/off Raise to Wake and DND Mode, and adjust Brightness. Tap to access the Settings menu.
If the watch malfunctions, connect it to a power supply and long-press the Home button for more than 12 seconds for a hard reboot.
EN 05

Basic Product Specifications
Screen Size: 1.49" TFT 240*280
BT Version: V5.0
Battery Capacity: 200mAh
Battery Type: Lithium polymer
Charging Time: 2 hours
Average Using Time: 10 days for typical use, 6 days for heavy use
Standby Time: 30 days
Watch Size: 43.3*35.2*10mm (without strap)
Weight: 35.5g (with strap)
Material: ABS/PC/Silica Gel
Waterproof: IP68
Customer Service
365 DAYS WARRANTY
EN 06

Warranty Certificate
Name:
Address:
Tel. No.:
Date of purchase:
Store name:
Warranty period:
EN 07

User Manual
Smart Watch
Model: OSW-800N
Hereby, ORAIMO TECHNOLOGY LIMITED
Declares that this Smart Watch is in compliance with the essential requirements and other relevant provisions of directive 2014/53/EU.
EN 08

For more information, please visit:
www.oraimo.com @oraimo_accessories
EN 09