

OSW-822N_说明书

材质: 100g铜版纸 形式: 骑马钉成册 尺寸: 90x90mm (成品)

Internal Use (内部公开)

WELCOME GUIDE

Watch Nova RV | OSW-822N |

* For safety issue, the product remains at low battery capacity during shipping. Please fully charge the product before initial use!

PRODUCT OVERVIEW

Full Touchscreen, Home Button, Side Button, Charge Cable, Replacable Watch Strap x1, Welcome Guide, Wrist Strap, Charging Port, Heart Rate Sensor

SETTING UP YOUR SMART WATCH

For your best experience, we recommend using the latest oraimo health app for iOS and Android.

Pair With Your Phone

1. Get ready with the oraimo health app, scan the QR code on your watch or find the oraimo health app in one of these locations, depending on your device:

The App Store for iPhone. The Google Play Store for Android phone.

2. When the app is installed, open it and follow the instructions that help you create your account, or login to your existing account.

3. Your account asks for information such as height, weight, and gender to make various calculations and tailor your experience using the app. You can modify your information in oraimo health - Account - User.

4. Long press the Home Button of the watch to turn it on, follow the onscreen instructions to set up the language, and get ready pairing with the phone.

EN 01

Scan the QR code to pair

Use oraimo health app to scan the QR code on the watch.

If you can't pair successfully, try the following methods:

1. Make sure the BT permission is allowed for the app.
2. Make sure the watch is not connected to another phone.
3. Try turning off and on again the BT switch on your phone.
4. If none of these work, try rebooting your phone and the watch, and repeat the above steps again.

After pairing with your phone, read through this guide to explore the various functions!

EN 02

BT CALLING

Before pairing your phone and the watch for the BT Calling function, make sure the BT for call on the watch is switched on:

Press the home button, select and tap the Call icon on the main menu, then switch on the BT for the call on the watch.

In the BT list of the mobile system, connect to "oraimo Watch Nova RV" and you can use the watch to make calls.

EN 03

GETTING TO KNOW YOUR SMART WATCH

Wrist Placement

For all-day wear, your watch should usually rest a finger's width below your wrist bone and lay flat, as you would normally wear a watch.

Charge Your Watch

Connect the metal contacts on the charging dock to those on the back of the device, then put them on a flat surface.

Connect the charging cable to a power supply, the device's screen will light up and display the battery level.

Can't connect with BT.

1. Make sure that your device supports BT Version 5.3 and that your phone system is iOS 12.0 and above or Android 7.0 and above.

2. Make sure that you've set up the BT permission for the oraimo health app.

3. Check if the watch is connected to another phone. If yes, please disconnect and retry.

4. Disconnect the BT on your phone and reconnect after 20 seconds.

5. Reboot the watch and your phone and repeat the above steps.

Can't find the watch in BT.

1. Make sure that your location services are enabled (GPS is working) and the device has sufficient power.

2. Keep the device screen activated and place it close to your phone.

3. Make sure that the watch is not connected to another phone.

4. Disconnect the Bluetooth on your phone and reconnect after 20 seconds.

5. If you still can't find it, please turn off your phone's BT function and reconnect after 20 seconds.

Can't monitor heart rate or blood oxygen.

Make sure that the optical monitoring sensor is in direct contact with your skin.

For Android users, please make sure that the device is connected to your phone. Set up notifications permission for the oraimo health app in the phone's Health app settings. Add the oraimo health app to the trust list if any security software installed prevents its functioning.

For iPhone users, please make sure that the device is connected to your phone. Reboot your phone and try to reconnect.

⚠ If the smartwatch was in contact with water, please use a clean, dry towel or a microfibre cloth to gently pat the watch dry, and wipe the metal contacts before charging.

EN 04

Power On/Off

- When the watch is powered off, please connect it to the power and press the Home Button for 3 seconds to turn it on.
- Wake up the watch, press the Home Button for 3 seconds to select the Shutdown option, then the watch will vibrate and power off. You can also power off from the Settings menu (Settings - Shutdown).
- If there is a problem with the watch, please connect the power supply and press and hold the Home button for more than 12 seconds to force restart the watch.

Wake Up the Watch

Method 1: Press the Home button to light up the display.

Method 2: Raise your wrist. This "Raise to Wake" function is active by default. You can turn it off by tapping the Raise to Wake icon.

Using The Clock And Menus

Swipe to access the watch menu to explore more functions of the watch: music player, calls, workout functions and settings.

Create a Custom AI Watch Face

1. Open the oraimo health app and select "Dial Center". Proceed to the "Create dial" option.
2. Choose your preferred AI technology to produce a unique watch face design.
3. Ensure your watch is near your phone when applying the new watch face.

Note: The creation time may vary based on your internet connection speed.

Troubleshooting & FAQ

Can't connect with BT.

1. Make sure that your device supports BT Version 5.3 and that your phone system is iOS 12.0 and above or Android 7.0 and above.

2. Make sure that you've set up the BT permission for the oraimo health app.

3. Check if the watch is connected to another phone. If yes, please disconnect and retry.

4. Disconnect the BT on your phone and reconnect after 20 seconds.

5. Reboot the watch and your phone and repeat the above steps.

Can't find the watch in BT.

1. Make sure that your location services are enabled (GPS is working) and the device has sufficient power.

2. Keep the device screen activated and place it close to your phone.

3. Make sure that the watch is not connected to another phone.

4. Disconnect the Bluetooth on your phone and reconnect after 20 seconds.

5. If you still can't find it, please turn off your phone's BT function and reconnect after 20 seconds.

Can't receive notifications after enabling it.

Make sure that the optical monitoring sensor is in direct contact with your skin.

For Android users, please make sure that the device is connected to your phone. Set up notifications permission for the oraimo health app in the phone's Health app settings. Add the oraimo health app to the trust list if any security software installed prevents its functioning.

For iPhone users, please make sure that the device is connected to your phone. Reboot your phone and try to reconnect.

EN 05

Is the product waterproof?

This product supports IP68 waterproof. You can wear it while washing your hands, having a cold shower and washing your car.

Do I need to connect BT all the time? Will my health and sleep data stored if not connected to the phone?

The data will be kept on the watch for 7 days. When reconnected to the phone, your health and sleep data will be synced automatically. Please synchronize data in time to get maximized utility.

Basic Product Specifications

Display Screen	1.39" TFT
BT Version	V5.3
Material	ABS/PC/Zinc alloy
Battery Capacity	300mAh
Battery Type	Lithium polymer
Rated Voltage	3V
Charging Time	3 hours
Normal Usage Time	6 days
Standby Time	More than 21 days
Watch Size	48.2*12.2mm (without strap)
Weight	14.75g (without strap)
Waterproof	IP68

* oraimo Lab test results

Customer Service

365 DAYS WARRANTY

India: care@oraimo.com
Kenya: care.ke@oraimo.com
Monrovia: care.mn@oraimo.com
South Africa: care.za@oraimo.com
Tanzania: care.tz@oraimo.com
Juruy Coast: care.jc@oraimo.com
Angola: care.ao@oraimo.com

Nigeria: care.ng@oraimo.com
Ghana: care.gh@oraimo.com
Egypt: care.eg@oraimo.com
Cameroon: care.cm@oraimo.com
UAE: care.ae@oraimo.com
Bangladesh: care.bd@oraimo.com
Others: service@oraimo.com

EN 06

Warranty Certificate

Name :	
Address :	
Tel. No. :	
Date of purchase : (dd/mm/yyyy)	
Store name :	
Warranty period :	

Warranty Terms & Conditions

- * All quality-related defects on items sold directly by oraimo or oraimo's authorized resellers are covered by an extensive warranty, starting from the date of purchase.
- * oraimo's limited warranty is restricted to the country of purchase. The limited warranty is void on items taken outside the country they were originally bought in or shipped to directly from an authorized online purchase.
- * This warranty covers only original oraimo products. It is not applicable to normal wear and tear, or any defects arising from damage caused by misuse of this product.
- * Warranty is for the primary product only nor transferable. Any free additional product(s) are not covered in this warranty.
- * If the product fails regardless of usage in compliance with the instruction manual and other written precaution, replacement will be provided free of charge.
- * To claim the warranty, contact the services team from the platform or store where you bought from.

EN 07

User Manual
Smart Watch
Model: OSW822N
Herby, ORAIMO TECHNOLOGY LIMITED
declares that this Smart Watch is in compliance with the essential requirements and other relevant provisions of directive 2014/53/EU.

CAUTION

1. Risk of explosion if battery is replaced by an incorrect type, dispose of used batteries according to the instructions.
- disposal of a battery into fire or a hot oven, or mechanically crushing or cutting a battery, that can result in an explosion;
- leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;
- a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

2. EUT Temperature 5 C ~ +40 C (with adapter).

Operating Frequency:
BT: 2400-2483.5MHz (TX/RX); Modulation mode: GFSK, n/4-DQPSK, BPSK(BT), GFSK(BLE)
Max. Of Transmit power:
BT(BLE): 3.59dBm BLE:3.53dBm

FCC Caution

Labeling requirements. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

Information to user: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Information to the user: Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. Note: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

RF Exposure Statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

EN 08

EU DECLARATION OF CONFORMITY

In accordance with Annex VI of Directive 2014/53/EU of the European Parliament and of the Council For the following Radio equipment:
Model: OSW822N
Product: Smart Watch
Trade name or Brand: oraimo
Software / Hardware number: V1.0/WS180 V1.0
2. Name and address of the manufacturer or its authorized representative: Manufacturer: ORAIMO TECHNOLOGY LIMITED
Address: FLAT N 16/F BLOCK B UNIVERSAL INDUSTRIAL CENTRE 19-25 SHAN MEI STREET FOTAN NT HONGKONG
3. This declaration of conformity is issued under the sole responsibility of the Manufacturer.
4. Object of the declaration (identification of the radio equipment allowing traceability; it may include a colour image of sufficient clarity where necessary for the identification of the radio equipment).
5. The object of the declaration described above is in conformity with the relevant Union harmonization legislation: Directive 2014/53/EU (RED).
6. Reference to the relevant harmonised standards used or references to the other technical specifications in relation to which conformity is declared:
Article 3.1a Health: EN 62479:2010 EN 55637:2017
Article 3.1a Electrical Safety: EN IEC 62368-1:2020+A11:2020
Article 3.1b: ETSI EN 301 489-1 V2.2.3 (2019-11) ETSI EN 301 489-17 V3.1.1 (2024-09)
Article 3.2: ETSI EN 300 328 V2.2.2 (2019-07)
Notified Body Name: WORLD STANDARDIZATION CERTIFICATION & TESTING POLSKA Sp. z o.o.
Notified Body Number: 2618
Notified Body Assessment Performed: Module B/C on Article 3.1a, 3.1b and 3.2
Technical File Identification Number: N/A
8. Where applicable, description of accessories and components, including software, which allow the radio equipment to operate as intended and covered by the EU declaration of conformity: User instructions are provided in the User Manual. The Software and Hardware versions are specified above.
9. Additional information: Reference to Article 13.2 of the Directive, this equipment is so constructed that it can be operated in all Member States, without infringing applicable requirements on the use of radio spectrum. Referring to Article 10.10 of the Directive, there are no restrictions on putting this equipment into service or of requirements for authorization of use. Please refer to the User Manual for details.

On behalf of:
Manufacturer: ORAIMO TECHNOLOGY LIMITED
Address: FLAT N 16/F BLOCK B UNIVERSAL INDUSTRIAL CENTRE 19-25 SHAN MEI STREET FOTAN NT HONGKONG
(place and date of issue) Shenzhen, 2024-11-28
(name, function): YangDazhuang/ Manager
(signature):

(Name and signature of person responsible)

EN 09

For more information, please visit:

www.oraimo.com

@oraimo_accessories

EN 10

请注意调整封面封底位置!

↑
封底