

Ai Intelligent Translator



Model: Ai-01

Index :

1. Downloading and Installing the App for This Product
2. Connecting the APP to the Translator
3. Setting Up this Ai Translator
4. Recorded notes function operating instructions
5. Using the Translation Function
6. Using the Face-to-Face Translation Function
7. Using the Cross-Platform Translation Function
8. Enabling Paste Permissions
9. Using the AI Assistant
10. About the device
11. Usage Tips

1. Downloading and Installing the APP

Step1:

Scan the following QR code corresponding to your phone's operating system (Android or iOS) to download and install the app.



Downloading
QR Code



iOS



Google Android



Android

Step2:

Once installed, launch the app and scan the QR code on the back of translator device to activate your account.

2. Connecting the App to the translator

Step1: Enable Bluetooth on your phone and pair it with the translator.

Step2: Open the app and tap the "+" icon to search for nearby devices.

Step3: When this device appears as named "AI-01" tap the "Go to Connect" icon displayed in grey next to it. Upon successful connection, the icon will become "connected" and display in red.

Step4: If a Bluetooth pairing request appears, select "Pair" and grant any requested permissions.

Step5: Verify the connection in the app. If "Connected" is displayed, the device is ready for use.

Tips: Once the step2 cannot find the device, solve it by the following two methods:

Method1: Turn off the Bluetooth, after a while and turn it on, repair your phone to the device again.

Method2: Restart the App and scan the device again.

3. Setting Up the Translator

Power On

Long press the power button for 3s. The light will flash rapidly in blue and this indicates the device is on.

Power Off

Press the power button twice quickly, and then hold it for 3s on the third pressing. After the light flashes three times in blue, the device shuts off.

Charging

During charging, the red light flashes. When fully charged, the light remains steadily red.

Note:

The device automatically powers off while charging and cannot be turned on until charging is completed.

4. Recorded notes function operating instructions

Step1: Ensure the device is connected, then select "Simultaneous Interpretation" from the app's main menu at the bottom of the page.

Step2: Select the source and target languages from the languages bar at the top.

Step3: Tap the microphone button to begin. The device will capture and translate speech in real time, displaying the speaker's language above and the translated language below. Tap the stop button to end the session.

Conversations are automatically saved.

Additional Features

Start a New Recording: Tap the microphone button again. Confirm the prompt to clear the previous conversation and start a new recording.

View Chat Records: Tap the icon in the upper-right corner to access saved conversation files.

5.Using the Translation Function

To use the standard translation feature:

Step1: With the device connected,tap the 'Conversation Translation"from the apps main menu at the bottom of the page.

Step2: Choose "Voice Translation" to enter the translation interface.

Additional considerations

A:Activated Status without connection

After five minutes ofno connection, the light will flash three times in blue and the device automatically shutting down.

B:In Connection Status

Upon successful connection, the light will flash in blue for every ten seconds.

If there is no operation for ten minutes,the light will flash in blue as a warning and then the device automatically shuts down.

C.Working Status

After establishing a connection, the light will flash in blue every ten seconds.

D.Simultaneously

pressing both of the L and R keys will switch the device to simultaneous interpretation mode,during which the light will remain

constantly flash in blue.

6.Using the Face-to- Face Translation Function

For face-to-face conversations:

Step1: Ensure the device is connected, then select "Conversation Translation" from the app's main menu at the bottom of the page.

Step2: Choose "Face-to-Face Translation"

Step3: Select the languages for both parties separately from the drop down menus.

Step4: Press and hold the left or right icon at the bottom to speak, Release it to end recording.The app will translate and display the content. If enabled,the device will broadcast automatically the translation text.

7. Using the Cross _Platform Translation Function

To integrate translation with messaging apps:

Step1: With the device connected, select "Conversation Translation" from the app's main menu at the bottom of the page.

Step2: Choose "Voice Translation"

Step3: Select the desired languages in the language content box.

Step4: Enable "AutoPaste" and minimize the pop-up window(Must not close it).

Step5: Open your messaging app, start a chat,and activate the text input keyboard. Press and hold the L or R button to speak, Release it to translate and paste the text into the chat dialog box.Tap "Send" to deliver the message.

8. Enabling Paste Permissions

Step1: Access the settings menu in the app and scroll down.

Step2: Select the desired messaging app.

Step3: Enable "Paste from Other Apps"

Step4: Confirm by selecting "Allow"

9. Using the AI Assistant

To access the AI assistant:

Step1: Select "AI" from the app's main menu.

Step2: Enter your query in the dialog box and tap the arrow to submit.

Step3: The AI will display the requested information.

10. About the Device

Android operating System

This Bluetooth device is compatible with mobile phone models from major manufacturers and operates via Bluetooth connection. If the phone's built-in input method conflicts with this product's functions, we recommend downloading and installing another input method for smoother use.

Apple operating System

When using voice translation in the corresponding application, enable "Allow Paste Permissions" in the app's settings.

Setting Method: Go to the phone settings, find the software permissions, open them, and set "Paste from Other Apps" to "Allow"

Additional Notes

The microphone takes time to activate. When enabling the voice translation function, wait 1-2 seconds before speaking for better

translation results.

If the translator connects to the APP but has no functionality, plug in the charging cable to reset it, then reconnect for normal use.

11. Usage Tips

1. Wait for 1-2 s after activating the microphone every time for optimal voice recognition.

2. Use clear, concise phrases and sentences for accurate translations.

3. In noisy environments, maintain a distance of approximately 15 cm from the device.

12. Common Issues:

1. Unable to Power off:

If the device responds slowly, please be patient and try again.

2. Bluetooth Connected but Device Not Found in APP: Plug in the charging cable to reset, then reconnect for normal use.

3. Inaccurate Translation:

Use clear, concise sentences to help the device accurately capture and translate your input.

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.