

Smart Watch

Quick guide

K73

Please read this manual carefully before use and keep it
for future reference

Touch and buttons

Slide down: Control Panel

Swipe up: SMS notification

Swipe right: menu function

Swipe left: Customize card

Encoder

Short press: light up the screen, return to the watch face interface, and enter the menu interface

Double click: switch menu mode

Long press: enter the system interface

Rotate: switch dials, scroll interface

Motion keys

Short press: enter the exercise list

Long press: Enter the emergency call interface

※ If it fails to turn on after long pressing the power button for 3 seconds, please charge it and try again.

APP download

App herunterladen: Suchen Sie bei iOS-Telefonen im App Store nach "FitCloudPro" und bei Android-Telefonen in anderen App Stores (z. B. App Store), um sie herunterzuladen und zu installieren; Oder scannen Sie den Code, um ihn herunterzuladen und zu installieren.



(FitCloudPro)

Connect to phone

View device Bluetooth name in [Settings>System>System Information]



Open the app on your phone, log in or register your account



Click on [Device>Add Device>Start Search] in the app



Select the Bluetooth name of the watch in the search results to complete pairing

- ※ Please keep the watch's battery level above 20% before pairing to avoid pairing failure due to insufficient battery.
- ※ During pairing and connection, ensure that the phone's Bluetooth is turned on and within a valid connection distance from the watch.

Features



Dial switching

Press and hold on the home screen for 2 seconds to enter the watch face switching interface, slide left or right to switch to the selected watch face, and click to select the watch face.



Control panel

Function summary: do not disturb mode, brightness adjustment, settings, find mobile phone, audio call mode, etc.



Sports data

Display the daily recorded steps, kilometers, and calorie data, and the target can be set in the app.

Features



Sport

Sports mode options: walking, running, climbing, cycling, skipping, basketball, etc. When the watch is connected to the App, other sports modes can be added to the App.



Sports record

This interface saves your last 10 exercise history records and allows you to view data such as exercise duration, heart rate, calories, etc. during exercise.



Heart rate

Enable timed detection on the app, and this interface displays the heart rate data for the day;

Features



Sleep

This interface displays the sleep monitoring status for the day, with data updated daily. By connecting to the app, data can be uploaded and saved synchronously.



Information

Enable relevant information push on the app, and the watch can receive corresponding message push. Up to 15 messages can be saved, and if exceeded, they will be automatically overwritten.



Blood oxygen

When entering the blood oxygen measurement interface, the green light at the bottom lights up to start measuring, and the measurement is completed in 30-60 seconds. At this time, the measurement is based on PPG technology.

Features



Call Bluetooth

Click the button in the "Control Panel" to enter the Bluetooth settings for calling; After enabling searchable access, connect your phone to Bluetooth below to use the call function.



Call records

Up to 10 call records can be kept, and the latest call records will overwrite the oldest records.



Top contacts

You can add them through "App Device Common Contacts". Add, delete, sort, up to 10 frequently used contacts can be added.

Features



Dial

After connecting the phone to Bluetooth for calling, the dialing function can be used normally.



Music

Can control the music playback on the phone.



Weather

After connecting the watch to the app and enabling location permissions, this. The weather interface will display real-time weather temperature and weather type.

Features



Alarm clock

You can set a single alarm or a recurring alarm, up to a maximum of 10 alarms.



Stopwatch

This interface has a stopwatch function and can also set segmented timing. It can save up to 10 pieces of data.



Timer

In the timer function, users can quickly start timing through the system preset time, or click the custom button to set the time.

Features



Find phone

When the watch is connected to the app, click to search for the phone, and the phone will ring to prompt, while the watch will display a successful search; If the watch is not connected to the app, the watch end will prompt that it is not connected.



Set up

The settings function includes screen display (dial switching, screen duration, brightness adjustment, wrist flip screen duration), language, vibration intensity, menu style, QR code, and system settings.

Precautions

- 1 Please do not disassemble, repair, or modify the product without authorization.
- 2 Please do not violently collide with the product to avoid damage to the product.
- 3 Please avoid strong magnetic field, direct light or high temperature environment.
- 4 This product is not intended for disease diagnosis, treatment or prevention.
- 5 Please avoid wearing the watch strap too tightly, and keep the contact area between the watch and your skin clean.
- 6 Children should use this product under the guidance of their parents to avoid harm.

*** This app is not a medical device. Data obtained during the use of this app is for reference only, and should not be used for clinical diagnosis, medical research, diagnostic, or treatment purposes.**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.