

名称： N80说明书(做成一本小册子) 尺寸： 78x113mm 材质： 80g书纸

D80

Quick Start Guide

Before using, please read this manual carefully and keep it properly for future reference.

01. Product Introduction

1.1 Packing List

- Printer *1
- Printing Paper *1
- USB Type-C Cable *1
- Quick Start Guide *1
- USB Flash Drive *1

02. Usage Method

1.2 Printer Parts Instruction

Top Cover
Power Button
Type-C Charger Port
Reset Hole
Paper Exit
Paper Compartment
Cover Open Button
Paper Size Regulator
Power Indicator

03. Install and Change the Printer's Consumable

Single Paper Installation

- Take out the thermal paper and make sure the printing side. Note: Make sure the paper roll takes out from the thermal printer.

04. App Download

Before using the printer, please install the "Nada Print" app from Google Play or the App Store.

Nada Print

* Scan the QR code to download and install the "Nada Print" App for printing.

05. Connecting and Printing

- Turn on bluetooth on your phone.
- Long press the power button to start the machine.

06. Install the Corresponding Driver for Your Computer System.

Windows - Thermal Printer Driver Installation

Install Driver on Windows via USB cable

Turn on the printer. Connect the printer to computer via USB cable. Double-click the compressed file to install the driver.

- Select Language
- Select USB
- Click Install
- Click Close

MAC - Thermal Printer Driver Installation

Install Driver on MAC via USB cable

Turn on the printer. Connect the printer to computer via USB cable. Double-click the compressed file to install the driver.

- Click Continue
- Click Install
- Click Close

07. Right-click the file and click the print button.

08. Additional Instructions

01 Button Instructions

Button Type	Operation	Function
Power Button	Long press for 3s	Power on / off
Reset Hole	Use a fine needle to press it inside	Restart the printer

02 Indicator Light Instructions

Status	Meaning	Advised Action
Green light	Normal operation	/
Green light flashing slowly	Printing	/
Red and green lights flash rapidly alternately	Upgrading	/
Red light	Open paper Compartment	/
Red and green lights alternate and flash slowly	Heating head overheating	Wait still until the red light returns to green
Red light	No paper roll detected / Faulty	Reinstall the label paper
Red light	Low battery	Timely charging
Green light flashing quickly	Charging completed	/

09. Cleaning

Please shut down the printer, open the printer cover and take out the paper.
Dip cotton cloth or cotton swabs into it. On the medical alcohol, along the printing head center to around the direction of gently wipe.
After cleaning the print head, do not use the printer immediately Please wait 1-2 minutes until the alcohol has completely evaporated.

10. Related Statements

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF exposure statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

-French-

Cet appareil contient des émetteurs / récepteurs exempts de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:
Cet appareil ne doit pas causer d'interférences.
Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

Déclaration d'exposition RF:

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.

Notice:

If the device cannot be turned on, please charge for one hour.

Zuhai Jiuyin Technology Co., Ltd.
Support Email: admin@zhujiyin.com
Official Website: www.ndyn.com
Address: Room 302, Building 2, No.90 Changzhi Road, Tangjiaowan Town, High-tech Zone, Zhuhai