


Frequency	Percentage
Never	10%
Very rarely	5%
Rarely	5%
Sometimes	10%
Often	15%
Very often	20%
Always	40%



Charge it before use, the red light is always on during charging, the red light is off when it is fully charged. The red light flashes during use. The red light blinks during use, which means the battery is low and needs to be charged. You can check the battery level at the top left of the AiMouse voice typing software.




Diagram illustrating the ModeSwitching button and Toggle Switch. The ModeSwitching button is shown with three positions: ON (indicated by a dot), OFF (indicated by a dot), and a third position (indicated by a dot). The Toggle Switch is shown with two positions: ON (indicated by a dot) and OFF (indicated by a dot). The USB receiver (2.4G) is shown with a hatched area indicating the connection point.

Labels and connections:

- ModeSwitching button
- Toggle Switch
- ON
- OFF
- USB receiver(2.4G)
- B T 1 blue light
- B T 2 red light
- 2.4 G green light

Microsoft Edge, Google Chrome, Mozilla Firefox. Tips: Priority is given to the above browsers. If you encounter problems, you can try to change the browser or open the browser first, and then press the Ai button. Or contact customer service to solve the problem.

Voice key recording to text method: V key Long press : At the text input place, press and hold (V key) to speak to the mouse, the voice can be converted to text. Note: Voice typing interface: You can choose Mandarin or more languages, and also can choose dialog box translation.

Rated input: 5V $\equiv$ 500mA
Charging port: Type-C
Connection: 2.4G/BT5.2 Bluetooth
Built-in rechargeable battery voltage: 3.7V
Tracking System: Optical Optical Brightness: 16000-18000MCD
Operating system: Windows 10/11
D P I : 800-4000

This product has been inspected by our quality control department
Performance parameters in line with technical standards,
authorized to leave the factory

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.