

Sc-128Bvertical screen controller manual



1. Temperature + / previous song / manual channel search. Physiotherapy mode is temperature setting plus key, playback mode this key is the previous song, and radio mode this key is upward manual channel search.

2. Temperature - / next song / manual search. The physical therapy mode is the temperature setting minus key, the playback mode this key is the next song, and the radio mode this key is the downward manual channel search.
3. Time + / volume + key. The physiotherapy mode is time setting plus key, and the playback and radio mode is volume plus key.
4. Time - / volume - key. The physiotherapy mode is the time setting minus key, and the playback and radio mode is the volume minus key.
5. Radio, enter the radio mode, press the temperature plus or minus key to search the channel. After 5 seconds, this opportunity will automatically jump to the physiotherapy mode. Press again to display the radio status, and then press again to turn off the radio function.
6. Short press the Bluetooth / USB function key to enter the Bluetooth mode for 5 seconds, and then the opportunity will automatically jump to the physiotherapy mode. Press this key to display the Bluetooth status, and then press to turn off the Bluetooth function. After connecting the Bluetooth with the mobile phone, you can play the Bluetooth music on the mobile phone. Long press this key to enter the USB mode for 5 seconds, and then the opportunity will automatically jump to the physiotherapy mode Press and hold this key again to display the USB status, and then press to turn off the USB function. After inserting the U disk that copies MP3 music, MP3 music can be played.
7. The key to turn on the physiotherapy lamp is RGB → R → g → B → RG → RB → GB → turn off the physiotherapy lamp → automatic cycle, a total of nine modes.
8. Press the internal lamp control key to turn on the external lamp, and then press to turn it off.
9. Press the external lamp control key to turn on the internal lamp, and then press to turn off.
10. Turn on the key of physiotherapy function. Short press this key to turn on and then turn off the physiotherapy hair heater. Long press this key to convert Fahrenheit and Celsius.
11. Press the on / off button to start the machine and then press the off button.
- 12.USB/MP3



30(29)°C

30

2



3



MIN



VOL

MAX



4



5

6



7



8



9



10



AUX

11



USB

12



°C/°F

13

14

15

1. Press the on / off button to start the machine and then press the off button
- 2 temperature + / previous song / manual channel search. Physiotherapy mode is temperature setting plus key, playback mode this key is the previous song, and radio mode this key is upward manual channel search
- 3 Temperature - / next song / manual search. The physical therapy mode is the temperature setting minus key, the playback mode this key is the next song, and the radio mode this key is the downward manual channel search
- 4 time + / volume + key. The physiotherapy mode is time setting plus key, and the playback and radio mode is volume plus key.
- 5 time - / volume - key. The physiotherapy mode is the time setting minus key, and the playback and radio mode is the volume minus key.
- 6 the key to turn on the physiotherapy lamp is RGB → R → g → B → RG → RB → GB → turn off the physiotherapy lamp → automatic circulation, a total of nine modes.
7. Press the interior lamp control key once to turn on the interior lamp, and then press to turn it off.
8. Press the exterior lamp control key to turn on the exterior lamp, and then press to turn it off.
9. 9. Settings, enter settings and connect app Bluetooth sauna BT APP
10. Radio, enter the radio mode and search the channel according to the temperature plus or minus key
- 11 Bluetooth, you can play music on the mobile phone after connecting Bluetooth with the mobile phone
- 12 physiotherapy function on key, press this key to turn on the heating wire switch
- 14.USB, plug in USB and play music
- 15This key can convert Fahrenheit and Celsius.
16. Mobile app connection: Android mobile phone opens the mobile QQ browser, scans the local QR code, installs the app according to the mobile phone prompt, opens the app after installation, opens the mobile phone Bluetooth at the same time, and searches the

connection app in the app settings. Apple mobile phone scans QR code for installation in Apple mobile phone market.



Apple App



Domestic android APP



Overseas Android App

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.