

FG01 User Manual

How to turn on/off?

Press and hold the previous button for 3 seconds

Matching status

Turn on your glasses to enter pairing mode (Note: In pairing mode, the status indicator will flash blue)

Connect glasses

Turn on your phone's Bluetooth and search for the glasses model "YK06A". Then, tap Pair on your phone.

music

Play/Pause: Tap the touch button

Music switch: Double tap the touch button (next track)

Triple tap to play the previous song

Photo/Video/Audio

take a picture :

1. Click and press
2. Control recording with device voice recognition offline. The current entry is "Take a photo".

3. Start or stop recording via AI chat

control in the mobile app:

Double-tap to press

2. Control video recording through device offline voice recognition. The current entry is "Turn video recording on/off".

3. Control video recording through AI chat in the mobile app

Start recording/Stop recording:

Double-click the previous button

2. Control recording through device's offline voice recognition. The current entry is "Turn recording on/off".

3. Record audio through AI voice control in the mobile app

Incoming call

Answer or end call: Tap the touch button

Call rejected: Double-tap the touch button

Note: Third-party call

1. (When talking to phone A, hang up phone A and answer phone B): Click the touch button
2. (While on call with Phone A, hold Phone A and answer Phone B): Double-tap the touch button (tap to end call first)
B, click again to end call A)

Enable voice assistant

AI Assistant: Click the button before to wake up

Offline voice recognition: Wake up AI with voice recognition. Currently, the entries are "Xiaoqi Xiaoqi" and others.

Photo/AI Image Recognition

Turn on AI: Say something like "Detect objects in front of me" or "Tell me what's in front of me"

Offline speech recognition: Current entries are "What do I see?" and so on

Charging Instructions

After connecting the glasses to the charging cable, plug the USB end into a standard charger

During charging, the LED red indicator stays on. When the light turns off, the device is fully charged.

View glasses image/video/audio

After the glasses are connected to the phone APP, you can view the pictures and videos of the glasses by following these steps:

1. Turn on your phone's WiFi
2. Tap the "Album" option in the mobile app
3. Click OK to start file synchronization
4. The device will automatically connect to WiFi to sync photos, videos, and audio recordings

factory data reset

Restore factory settings: Press the button five times. The system will clear the settings with a "beep" sound. Restart the device to resume normal operation.

(Note: Restore default settings and clear all data on the glasses)

Clear pairing information

Clear pairing information: Press and hold for 5 seconds (Note: Clear pairing information for connected devices)

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-

Consult the dealer or an experienced radio/TV technician for help important announcement

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

APP

