

PT-1 PET TRANSMITTER



Introduction

The Communications Specialists Model PT-1 pet transmitter attaches to your pet's collar so it can be found if lost. The transmitter is programmed to operate on one of 50 channels so multiple pets in a single household or neighborhood can operate at the same time without interference to each other. The channel number of the transmitter is shown on the sticker on the PT-1 case. It weighs less than 1/2 ounce including the battery which allows it to be used with the smallest of pets. The battery will power the PT-1 for approximately 6 weeks.

Installation

Remove the collar from around your pet's neck and punch a small hole in it with a sharp nail or icepick. Unscrew the small nut holding on the antenna from the threaded shaft on the back of the PT-1. Push the threaded shaft through the hole previously punched in the collar. Reinstall the antenna on the threaded shaft and secure it with the removed nut. Tighten down the nut so the PT-1 and antenna do not twist and are securely attached to the collar. The PT-1 should be on the outside of the collar and the antenna should be laying parallel against it.

Battery

The battery is a CR2032 Lithium cell that is available from us in a 12 pack conveniently labeled for monthly battery changes. It may also be found at drug stores or markets that sell photo or hearing aid batteries. To change the battery, pop off the front cover on the PT-1 using your fingernail and remove the battery by grasping the finger tab that is laying down against the + side of it. Pull out the battery and dispose of it properly. Remove the current month's battery from the 12 pack by pushing it through the back of the package. This way you will always know in which month you replaced it. Install the new battery by holding the finger tab and gently sliding it into the battery compartment. Pop the back cover on and you are done for another 6 weeks.

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications to this device will void the user's authority to operate the equipment.

Warranty

The PT-1 is warranted to be free of defects in materials and workmanship for a period of one (1) year from the date of purchase. Just return the unit to the factory and we will repair or replace it at no charge.

