
Features

Wheel for Scrolling and Zooming

Scroll Functions - Move through documents by simply rolling the wheel forward or backward- instead of clicking on a scroll bar. Click scroll wheel and move mouse to scroll through documents.

Zoom Function - Hold Control key on your keyboard and Scroll wheel to easily size you active window (Zoom Window function works in Microsoft Office97-compatible or later applications)

No Mouse Ball-Stays Accurate Over Time

Mice that track movement using rubber balls need to be cleaned frequently because dust and lint can make the mechanism stick or skip. The Optical sensor has no moving parts, so your mouse is smooth and precise.

Optical Sensor Works on Hundreds of Surfaces

The precise optical sensor detects motion on hundreds of surfaces.

Specifications

Switch Life: 5,000,000 Cycles (Min)

Resolution: 400 DPI

Tracking Speed: 250mm/sec Max.

PC System Requirements

Microsoft Windows® 95, Windows 98, Windows NT® Workstation 4.0 Service Pack 3 or later.
For Windows® 95 drivers go to www.sejin.com to the download section.
Round mouse port (PS/2-compatible).

Installation

Turn off your computer.
Install the green mouse connector into the mouse port on the back of your computer.
Turn on your computer and you are ready to go.

Caution

Mouse is mechanically sensitive. Please avoid hard contact with other surfaces.