

**** USER'S MANUAL ****

FCC ID : HQXPC97010-06

ENGLISH

Installation

• Getting started

To install the mouse, you need the following items ready for use.

- Computer — IBM PC, XT or AT, IBM PS/2 model (mouse port or serial port) or other IBM compatible PCs.
- Disk — A floppy disk or including a fixed disk.
- DOS — The DOS Version 2.0 or later.
- Memory — 256K RAM or above.
- Serial port — COM1 or COM2 (mouse port : PS/2 mouse only).
- Monitor card - IBM Monochrome Adapter, IBM Color Graphics Adapter, IBM Enhanced Graphics Adapter with Enhanced Color Monitor or other compatibles.

• Mode Selection

Microsoft Mode — Simply power on the computer.

Mouse System Mode — Before turning on the computer, press any one of buttons on the mouse, keep pressing the button until the computer has completed all power up procedures.

Note: If you found a slide switch, marked "MS"(2) & "PC"(3) on your mouse, please operate it in reference to the instruction as below :

"MS" (2) : the mouse works under Microsoft mode.

"PC" (3) : the mouse works under Mouse System mode.

PS/2 Mode (for PS/2 models) — Simply power on the computer.

1. Installing a mouse driver under DOS

• Explanation of Mouse Driver Files

MOUSE.COM— The file serves to activate the mouse. By typing the MOUSE command, the driver program will be loaded into computer memory.

TEST.EXE— A mouse test program, including 17 mouse testing functions.

INSTALL.BAT— A batch file provided by us to assist you for easy, and automatic installation purpose.

READ.ME— A file with it's contents relate to additional parameter setting for the mouse. To see it, insert the driver diskette into disk A, and at "A:\>" prompt, simply type: "TYPE READ.ME <return>". Then you will see the contents.

• Floppy Disk Users:

There is no specific installation process for floppy disk users, to use the mouse, simply insert driver diskette into disk A, then at "A:\>" prompt, type: "MOUSE<return>", then mouse driver is loaded.

• Hard Disk Users:

Start DOS until C:\> appears. Insert the driver diskette into disk A. Following are two methods that both help you to install the mouse driver.

1. at "A:\>" prompt, type: "INSTALL A: C: <return>".
2. at "C:\>" prompt, type: "MD MOUSE <return>" then followed by "COPY A:.* C:\MOUSE<return>".

2. Installing a mouse driver under Windows 3.1

- a) Start Windows 3.1.
- b) Choose the FILE/RUN command.
- c) Type A:\WIN\SETUP.EXE if the mouse driver diskette is in drive A or Type B:\WIN\SETUP.EXE if the mouse driver diskette is in drive B and then ENTER.
- d) Choose "Continue" if you are sure you want to continue the setup program.
- e) Enter The Maker Identified Code <2182288> and choose "Continue".
- f) The mouse setup program will copy all program files into following directory: C:\WMOUSE (default) or you can specify a different directory.
- g) Choose "Continue" and enter to "Backup WIN.INI File" screen Choose "Continue" if you want to backup current WIN.INI file to WIN.MOU.
- h) Enter to "Backup SYSTEM.INI FILE" screen Choose "Continue" if you want to backup current SYSTEM.INI file to SYSTEM.MOU.
- i) A list of mouse drivers will be displayed, when "Show all devices" is chosen. Select one of them
 - Bus Adapter Mouse
 - PS/2 port Mouse
 - Serial Mouse
- j) Choose "OK" to complete the setup program.
- k) Re-start Windows.

3. Installing a mouse driver under Windows 95

- a) Insert the mouse driver diskette into Drive A (or B).
- b) Select the Start/Setting/Control Panel.
- c) Click on the mouse General/Change/Have disk.
- d) Type in the path of the mouse driver like A:\Nor B:\ WIN and click on OK.
- e) Press "ENTER" from keyboard to finish the installation and re-start Windows 95.