

WELCOME to the quick guide

Penclic Mouse combines ergonomically sound design with modern mouse technology to bring you unparalleled precision, comfort and efficiency.

Mouse setup

Insert the battery into the mouse

Charge the battery with the included micro usb charging cable until full.

Set the mouse power switch on the bottom of the mouse to ON

Trouble installing your Penclic Mouse R3. Please look at www.penclic.se/troubleshooting

HOW TO USE YOUR Penclic Mouse

1, Hold Penclic Mouse like a pen, the bottom part acts like a traditional mouse.

2, Let your forearm and your hand rest on a surface, while keeping your shoulders relaxed.

3, The pen part can be adjusted to suit specific grips.

Fixate the bottom part with one hand and rotate the pen to the preferred angle with the other.

- Left click 1
- Right click 2
- Middle click 3
- Scroll wheel 4
- On-off switch 5
- DPI switch 6
- Connect to new receiver button 7

TROUBLESHOOTING

<http://www.Penclic.se/troubleshooting>

- Check the battery.
- When the battery needs charging the LED on the mouse will show red. When the battery is fully charged a green light will be displayed.
- Cursor movement may be effected by very glossy surfaces.

TECHNICAL SPECIFICATIONS

The supported platforms for Penclic Mouse are all operating systems that support HID 1.1. These include Windows XP or later, Mac OSX version 10.1 or later and most Linux/BSD flavors. No extra software/driver installation is needed.

- Operates on almost any surface without any pad or tablet.
- Implements a 3-buttons and scroll wheel mouse.
- AAA 1.2V NiMH Recharging battery (Everyday use last approximately 3 months before charging is needed).
- LR 03/AAA/1.5V Alkaline None rechargeable battery can be used. **NOTE: DO NOT RECHARGE**
- Energy saving mode starts after 10 min, press left click (button 1) to activate.
- Wireless reach, minimum 5 metres.
- Dpi settings 800-1200-1600.

Measurements:

- Height: 140 mm Base: 44.1 x 20 mm
- Weight: 41 g

TECHNICAL SUPPORT

Should you require additional technical support with your Penclic Mouse™, please use our Web site for further information or contact our support group through e-mail. Call Technical Support during business hours, central European time plus one hour.

Contact: + 46 8 544 98 995 or email: info@penclic.se

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC WARNING

This device complies with Industry Canada RSS-210 standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a PCB and maximum -1.2dBi gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

SPRÅK: ord på 13 språk

Svenska, norska, danska, finska, tyska, franska, spanska, italienska, holländska, portugisiska, turkiska och grekiska. + polska