





AYANEO Pocket S2





Power on / Power off / Restart

Power On

When the device is powered off, press and hold the power button " " for approximately 3 seconds, then release. The AYANEO Pocket 2S will start up.

Power Off

When the device is powered on, press and hold the power button " " for about 2 seconds until the menu appears on the screen. Select " " to turn off the AYANEO Pocket 2S.

Restart

When the device is powered on, press and hold the power button " " for about 2 seconds until the menu appears on the screen. Select " ", and the AYANEO Pocket 2S will reboot.

Sleep / Wake up

Sleep Mode

When the device is powered on, briefly press the power button " ", and the AYANEO Pocket 2S will enter sleep mode.

Wake Up

When in sleep mode, briefly press the power button " " to wake up the AYANEO Pocket 2S. If a screen lock is set, you will need to draw the security pattern or enter a password/PIN to complete authentication before accessing the system interface.

Fingerprint recognition

Fingerprint Recognition Setup

To use the fingerprint recognition feature, you must first set up a screen lock:

- Go to " "Settings > " "Security & Privacy > "Set Screen Lock".
- Choose a lock method: Pattern, PIN, or Password, and follow the on-screen instructions to complete the setup.

Fingerprint Enrollment

After setting up the screen lock:

- In the "Security & Privacy" menu, select "Device Unlock" > "Fingerprint".
- Enter the previously set Pattern, PIN, or Password for security confirmation.
- Follow the on-screen instructions to enroll your fingerprint and complete the setup.

Note: After powering on or restarting the device, you must verify the screen lock security by entering the Pattern, PIN, or Password before using fingerprint unlock. All operations and icon functions are subject to the actual interface and on-screen prompts.

Volume

Volume Adjustment

Press the volume up button " " to increase the volume step by step. Press the volume down button " " to decrease the volume step by step. Long pressing either button will continuously adjust the volume.

Volume Settings

Go to " "Settings > " "Sound & Vibration to adjust media volume, notification volume, alarm volume, and more.

Text Input


When text input is required, tap on the input field to automatically bring up the on-screen touch keyboard. Use the touch keyboard to enter text.



Dropdown Menu

Swipe down from the top of the screen to open the dropdown menu, allowing quick access to settings such as internet, Bluetooth, and more. You can also adjust the screen brightness using the brightness slider.

Swipe down again to reveal more quick settings. Tap " " to customize the quick toggle options as needed.



Network / Bluetooth

The AYANEO Pocket 2S supports WLAN network connections and Bluetooth device connections.

Network Connection

Go to " "Settings > " "Network & Internet Icon > " "Internet Icon.

Under the WLAN section, select the network you want to connect to, enter the corresponding password, and connect to the WLAN network.

Bluetooth Connection

Go to " "Settings > " "Connected Devices.

Tap " "Pair with New Device, select the Bluetooth device you want to connect from the search list, and follow the on-screen instructions to complete the connection.

Storage Expansion

The AYANEO Pocket 2S is equipped with a Micro SD card expansion slot. Open the dust cover at the bottom of the device to install or replace the Micro SD card.



Data Transfer

To connect to a PC for data management, after connecting the AYANEO Pocket 2S to the PC, go to " "Settings > " "Connected Devices" > " "USB.

Under the USB Usage section, select "File Transfer" to enable proper data transfer.

Software Upgrade

To enhance the AYANEO Pocket 2S user experience, AYANEO will regularly push system software updates. You can check and install system updates by following these steps:

- Go to " "Settings > " "About Device > "System Update".
- On the System Update page, tap "Check for Updates". If a new version is available, follow the on-screen instructions to upgrade and enjoy the latest system features.

Note: A WLAN network connection is required in advance, and the network should remain stable during the update process. Ensure that the device has sufficient battery power, or connect to a power source to prevent unexpected interruptions during the upgrade.

More Features

The AYANEO Pocket 2S offers a variety of personalized feature settings, which can be managed through AYASetting, including:

- **Account:** Manage AYANEO personal account information and synchronization services.
- **Performance:** Adjust device performance modes based on your needs.
- **Controller:** Configure button mappings and controller functions.
- **Personalization:** Adjust system wallpaper, quick settings window, and other customization options.
- **Device:** Options for screen, fan, screen casting settings, and more.
- **Updates:** Perform updates for AYAWindow, AYASetting, AYASpace, and controller firmware.

Note: Specific settings and features may change with updates to the AYASetting app. Please refer to the actual version for accurate details.

Usage Notice

Before using this product, please read all instructions and specifications carefully. Incorrect usage may cause internal component damage or potential safety risks to personal health.

● Operating System

AYANEO Pocket 2S runs on the Android operating system and can be operated via touch controls.

● Charging

When charging, please use a safety-certified adapter. Do not use uncertified adapters, as they may cause damage to internal components and pose unpredictable risks. AYANEO Pocket 2S requires a charger that supports PD PPS. To ensure stable charging, it is recommended to use an adapter that supports PD 3.0 PPS 20V 5A, along with the included USB-C cable.

● Battery Replacement Warning

Do not attempt to replace the AYANEO Pocket 2S battery yourself. Doing so may damage the battery, causing it to overheat and potentially lead to fire and personal injury. The lithium-ion battery should be serviced or recycled by AYANEO or an authorized service provider. It must be separated from household waste for proper disposal according to local environmental regulations. Replacing the battery with an incorrect model can cause explosion risks.

● Thermal and Noise Notice

During use, the product may generate heat and fan noise, which is normal. Actual temperature and noise levels may vary depending on usage performance. You can switch performance strategies by pressing the Turbo  button according to your environment and needs.

● Software Updates

Please refer to the software updates pushed by AYANEO for the latest software features.

● Cleaning

Use a lint-free cloth to clean the product. Avoid using any chemical solvents or abrasives.

● Environmental Protection and Recycling

Do not disassemble the product yourself. It must be disposed of separately from household waste. Please follow local environmental regulations for recycling.

● Protection

Avoid dropping, crushing, or bumping the device, as it may cause physical damage.

● Accessory Variations

Some accessories may vary depending on the purchased configuration and country or region.

● Medical Device Interference

The internal components of the AYANEO Pocket 2S contain magnets and electromagnetic fields that may interfere with medical devices, pacemakers, defibrillators, or other medical equipment. Please maintain a safe distance between the AYANEO Pocket 2S and medical devices.

Consult your physician and medical equipment manufacturer for information. If you suspect the AYANEO Pocket 2S interferes with your pacemaker, defibrillator, or other medical equipment, stop use immediately.

Warranty Service

AYANEO provides a warranty for the hardware products and accessories included, effective for one year from the date of original retail purchase. The warranty does not cover normal wear and tear or damage caused by accidents or improper usage. To request service, please visit the official AYANEO website or an authorized service provider. Available service options may depend on the country or region where the service request is made and may be limited to the original country or region of sale. Additional charges, such as phone or international shipping fees, may apply.

When you submit a valid claim under the warranty service policy, AYANEO will, at its discretion, provide repair, replacement, or refund services for your AYANEO Pocket 2S. Your warranty rights are supplementary to those provided by local consumer laws. When submitting a claim under this warranty policy, you may be required to provide detailed purchase proof.

Support

For more support and troubleshooting information, please visit www.ayaneo.com.

Names and Contents of Hazardous Substances in the Product

Hazardous Substance						
Part Name	(Pb)	(Hg)	(Cd)	(Cr(VI))	(PBB)	(PBDE)
PCB Components	×	○	○	○	○	○
Plastic Parts	○	○	○	○	○	○
Metal Parts	×	○	○	○	○	○
Power Cables	○	○	○	○	○	○

This table is compiled according to SJ/T11364 regulations.

○: Indicates that the content of the hazardous substance in all homogeneous materials of the part is below the limit requirement specified in GB/T26572.

×: Indicates that the content of the hazardous substance in at least one homogeneous material of the part exceeds the limit requirement specified in GB/T26572.

Note: This product applies an environmentally friendly design concept and effectively controls hazardous substances. The "×" indicates that the hazardous substance is primarily due to the limitations of technological development, making substitution of the hazardous substance impossible.

Environmental Protection Use Period

The symbol indicates the period (ten years) during which the hazardous substances contained in electronic and electrical products will not leak or undergo abrupt changes under normal use conditions. During this period, the use of these electronic and electrical products will not cause severe pollution to the environment or cause serious harm to the user's health and property.



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Specific Absorption Rate (SAR) information: This device meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement the SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. The device has also been tested against this SAR limit. This device was tested for typical body-worn operations with the back of the Tablet computer kept 0mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain an 0mm separation distance between the user's body and the back of the Tablet computer.

The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF Exposure requirements, and should be avoided.