



Whiteboard 06



Specification

Thank you for purchasing our products.
In order to use it correctly, please read this manual carefully before operating it. Please keep this paper carefully.


Product introduction



- Desktop Whiteboard Reading Lamp
- Entire outward appearance, designs succinctly naturally.
 - Flexible and comfortable angle adjustment.
 - High color reducibility, which can protect vision well.
 - Fast wireless charge.

How to use it


Ready to use when power is connected.



- Please use the adapter provided with the product for power supply.
- If an adapter without 9V output is used, this device may not work.
- The lamp has a two-color color temperature switchable (cold white/warm white) to adapt to different reading environments. Touch the button to switch the color temperature in turn.
- When the light is on, press and hold the function key, and the light brightness will continuously change (continuously lighten/continuously darken)
- Place the mobile phone which supports wireless charging at the coil position to charge the mobile phone wirelessly


- Wireless charger standby state: indicator light is always on
- Wireless charger is charging: indicator light breathing
- There is foreign matter in the coil of wireless charger: the indicator light flashes

Angle adjustment



- Please pay special attention that all the above movable joints must be used within the allowed angle.
- ①The maximum range of movement of the lamp head elevation angle is 0° ~120°.
 - ②The adjustable range of the normal use angle of the light pole is 0° ~35°. Special point, when the lamp is folded and stored, its activity angle is: 0° ~90°.

- ③Light pole horizontal rotation angle range: 0° ~180°
- ④The lamp head can be tilted in the range of about 60° ~60° to adjust the optimal lighting angle.
- Recommended angle of use for this reading lamp: The lamp head is placed horizontally, the light-emitting surface is kept horizontal, and the vertical distance between the light-emitting surface and the desktop is about 400mm.



Note: When the hinge fails, you can try to open the decorative cover as shown, and use a screwdriver to adjust the hinge screws.

Parameters

Product	: Desktop Whiteboard
Model	: Whiteboard-06
Input (V)	: 240V~110V/50Hz-60Hz
Input	: 100~240V ~ 50/60Hz 0.6A max
Light	: 9W
Working Temperature	: <50°C ~40°C
Total LED	: 30

The appearance may differ from the actual display, it will be different due to different factors (picture is only for reference, please refer to the real object).

Packing list

- Desktop Whiteboard Reading Lamp:×1
- Data line(USB type-C):×1
- Specification :×1
- Adapter:×1

Notes for use

- Do not wear gloves or use other objects to operate the buttons;
- Please do not use it in wet places such as bathrooms. This product is not waterproof. Improper use will lead to poor insulation and short circuit;
- Please do not place high-temperature flammable items near lamps to avoid fires;
- Please avoid direct sunlight on the lamps to avoid discoloration, damage or failure of the lamps;
- Abnormal noise may occur when the lighting angle of the lamp is adjusted. This phenomenon is normal and does not affect the use;
- When lit for a long time or just extinguished, there will be a slight sound due to the expansion and contraction of the lamp housing. This is a normal phenomenon and not a malfunction;
- After a long time of use, the housing temperature of the lamp cap is relatively high. Do not directly touch the light emitting area of the lamp cap. Let it stand for a period of time before starting it
- When the lamp is not used for a long time, please disconnect the power supply to avoid fire accident.

Warnings :

- Do not use in unstable locations. Avoid tipping over, resulting in breakage of the luminaires.
- Do not cover the lamps with flammable materials. Avoid causing a fire accident.
- Do not modify the lamps at will to avoid inconvenient use, electric shock, fire and other accidents.
- Do not insert metal products or flammable objects into the gap of the lamp. Avoid fire and electric shock accidents.
- Do not place the light next to items that are easily exposed to high temperature or flammable. Avoid accidents such as fire.
- If any abnormality occurs, please cut off the power immediately for inspection and contact a professional.
- Do not forcefully adjust it beyond the normal use angle, so as not to damage the lamp or cause safety hazards.
- If the outer surface of the lamp is broken, please stop using it immediately to avoid potential safety hazards.
- Make sure your phone supports wireless charging.
- Do not put metal/magnet/credit card on your phone or case. It will affect wireless charging or cause damage to your device.
- Please do not use a case with a thickness of more than 0.09 inches, otherwise it will not charge.
- When charging, keep the distance between the implanted medical device (pacemaker, cochlear implant, etc.) and the wireless charger at least 20 cm to avoid potential interference with the medical device.
- Do not allow children to use the product alone.

FCC warnings :

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- FCC RF exposure statement:
 - The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. •This equipment should be installed and operated with minimum distance between 20cm the radiator your body.