


PRODUCT MANUAL

Aroma diffuser





If the QR code cannot be scanned, please search for "Scent Marketing" in Google play or APP store.




01 Specification

[Model]	A974-PRO
[Size]	φ75.5*296.9mm
[Bottle]	120ml
[Input]	12V = 1A
[Working Power]	5W
[Coverage]	55m ² /165m ³ /5800ft ³
[N.W.]	0.66 kg
[Material]	PP




02 Installation step



1. Take out the diffuser head;
2. Twist off the bottle;
3. Fill the bottle with essential oil;
4. Put the diffuser head back in the machine.

03 Functional analysis



Rotate

- Rotate clockwise to adjust the timer levels: 1H-3H-6H.
- Rotate counterclockwise to adjust the timer levels: 6H-3H-1H.

Grade button

- Short press to turn off and switch cycle through the settings: G1 - G2 - G3 - OFF.
- Long press for 1 second to turn on/off the ambient light, no matter the device's power status;
- Long press the OFF for 1 second to turn the ambient light on/off, without affecting other lights.

Timer Function

- Press to start the timer mode: Set to 1H for 1 hour of operation before automatic shutoff; Set to 3H for 3 hours, or 6H for 6 hours, after which the device will turn off automatically.
- Ambient light: Orange light. It defaults to always on when powered on.
- Long press for 10 seconds: Restore factory settings.
- (24-hour mode. Gear: 1st gear. Turn off ambient lights)

Smart APP

- Bluetooth Paired: the light flashes.
- Data receiving: the light flashes.
- Smart mode: The light remains on all the time.


04 Smart App Instructions

Where to get the app:


Please search for "Scent Marketing" in Google play or APP store.

Note:


Make sure that the location function of Bluetooth and mobile phone is enabled.



1. Open the scent marketing app and select Bluetooth.
2. Select your device.
3. Enter the default password 8888 and press Login.



4. On the Device Control page; You can change your device name and label information of your scent diffuser.
NOTE: Press the "Save" button at the top right corner of the screen after each change.
5. Different schedules by pressing the "+" button. To delete a schedule, swipe left.
6. Press the toggle button to turn on/off any schedule.
7. On the "Working period setting" page, Set the hours of the day you want your diffuser to run by scrolling the "Start working time" and "Stop working time".
8. Select the days of the week you want your diffuser to run (all days are pre-selected).
9. Press "+" or "-" to increase or decrease the preset intensity grades (1-5. See chart for details).
10. Check (✓) the Custom box to create a custom intensity and scroll the "Spray Time" and "Pause Time".
11. Press the "Save" button to update the Settings.
12. Change the default password by pressing on the "About" tab, in the "Device control".



13. Press the "Password Change" to access the password change page.
14. Enter a new four-digit password, then click "Confirm".

If you forget your password, hold down the On/Off button for 5 seconds, Restore factory settings, password is 8888

05 Concentration and consumption

Grade	Work time(s)	Stop time(s)	Consumption(g/h)
G1	10s	220s	0.11
G2	20s	120s	0.35
G3	25s	60s	0.72
Customized	5-35s	60-300s	—

Note: 1. Abova data is for reference only. If customers use essential oils with different viscosities, the oil consumption will vary;
2. For the best diffusion effect, it's recommended to use essential oils with a viscosity below 30mPa.s. And the optimal working temperature is 25°C.

06 ISED Statement

English: This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada’s licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).

French: Cet appareil contient des émetteurs/récepteurs exempts de licence qui sont conformes aux RSS exemptés de licence d'Innovation, Sciences et Développement économique Canada.

L'exploitation est soumise aux deux conditions suivantes :
(1) Cet appareil ne doit pas provoquer d'interférences.
(2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.

l'appareil numérique du ciem conforme canadien peut -3 (b) / nmb - 3 (b).

This device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 2.5 du cnr - 102 et conformité avec rss 102 de l'exposition aux rf, les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs rf et la conformité.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.

Cet équipement est conforme aux limites d'exposition aux rayonnements du Canada établies pour un environnement non contrôlé.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.

07 FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Not applicable

RF Exposure
This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

08 ⚠ WARNING

Safety Instructions
To ensure safe use and prevent harm or property damage, please follow these safety precautions. Failure to comply with these warnings may result in accidents. This product is not designed for the following situations:
- Use by unattended infants, individuals with disabilities, or those with cognitive impairments.
- Use as a toy by young children.


Usage and Storage Instructions
1.This aroma diffuser is designed for use with essential oils. Please read the manual carefully before use.
2.This product is not suitable for individuals with weakened health (including children). Elderly, pregnant individuals, and those with physical, sensory, or intellectual impairments should consult a doctor before use. Those lacking experience or knowledge, especially children, must be supervised by a responsible person to ensure safe use. Otherwise, they should be prevented from accessing the device.
3.The optimal operating temperature for the machine is 20-35°C, with a relative humidity of <85%. Diffusion performance may vary depending on environmental temperature and humidity.
4.Store essential oils in a cool, dry place with the cap securely closed, away from direct sunlight. The recommended storage temperature is around 25°C.
5.Dispose of the product and protective packaging materials in accordance with local regulations.

Prohibited Guidelines
1.Keep away from fire sources.
2.Do not ingest essential oil; seek medical attention if swallowed.
3.Do not use for purposes other than space diffusion; do not apply fragrance essential oil directly to the skin.
4.Avoid extreme temperatures (below -5°C or above 40°C).

Mandatory Guidelines
1.Do not modify, disassemble, or repair the machine unless you are a qualified technician. If a malfunction occurs, contact customer service from the original purchase channel.
2.Stop using the device immediately if any abnormalities occur during or after use.
3.Place the machine on a level surface and keep it upright after installation. Tilting or placing the device flat may cause oil leakage or malfunction.
4.Wipe up any spilled essential oil immediately.

Potential Risks of Injury or Property Damage
1. The following actions may cause electric shock, short circuits, or fire hazards:
- Do not get the machine or charging port wet.
- Do not use overloaded power outlets, damaged cords, or faulty plugs.
2. When adding essential oil, avoid excessive pressure to prevent leakage and damage to machine components.
3. Do not pull, crush, cut, or tamper with the power cord.
4. To prevent malfunctions or damage, do not disassemble the machine during use.
5. If the adapter, charging cable, or power cord is damaged, it must be replaced with a specialized component provided by the manufacturer or authorized service provider.
6. Use only the specified low-voltage power supply as marked on the device.
7. Only use the power adapter included with the product.
8. Use only the recommended evaporation medium. Using other substances may pose toxic or fire risks.

This product is intended for sale and application in a business environment. RED Article 10 2-This product can be used across EU member statesRED Article 10 10-The product is class 1 product, No restrictionsThe RF distance betwe en body and product is 20cmFrequency Range:2402-2480MHzMax. RF Output Power :-1.67 dBm (EIRP) @2Mbps



09 Troubleshooting

Before asking to have the machine repaired, please try to diagnose the problem first by following the instructions below.

Breakdown	Solution
Does not diffuse	-Check whether the mode you chose correct or not. -Check if the machine is in a "Non-Working period". -Air pump may be damaged, replace with a new one. -Check whether the tube is loose or not.
Low diffuse	-The atomizing core is blocked, clean with alcohol or change to a new atomizer heads. -Check whether the gasket is damaged/loose or missing. -Check whether the tube is loose or not connected.
Oil spill	-Check whether the bottle is loose . -Check if the gasket in the atomized head is damaged, loose or missing.
Oil sprinkle	-The atomized head is damaged: change to a new one. -The machine is tilted or laying flat, keep the machine vertical.
Abnormal noise	-The air pump is loose, retighten the pump -The air pump is damaged:replace.

10 Equipment cleaning

The machine needs to be cleaned when these conditions exist:
1. You're about to changing to another kind of essential oil;
2. The atomization volume becomes weak .

Cleaning steps:
1. Pull out the atomized head.
2. Find a larger container and fill with industrial alcohol up, then soak the atomized head and the bottle for 5-10mins.
3. Allow the atomizer head and the bottle to dry.