


Product Manual



Aroma Diffuser

Model:A-T370



01 Specification

- 【 Model 】 A-T370
- 【 Size 】 132*154*88.5mm
- 【 Bottle 】 60ml
- 【 Power 】 4W
- 【 Input 】 5V = 1A
- 【 Coverage 】 50m²/150m³/1766ft³
- 【 N.W. 】 580g
- 【 materials 】 PP




Bottle


Power adapter

Manual

Product Introduction



Usage process



1. Pull out the atomizer head upwards.
2. Unscrew the essential oil bottle;
3. After injecting an appropriate amount of essential oil into the bottle, screw the atomizer back onto the essential oil bottle.
4. Align the silicone stopper of the bottle and the atomizing head with the machine's clamping position and press it down.
5. Connect the power supply and plug in the data cable.
6. Press and hold the power button for 3 seconds to turn on the device, and it can be used normally.

* Press and hold the power button for 8 seconds to restore the factory Settings.

Smart App Instructions

Where to get the app:

1. Download the APP

Open the APP store on your mobile phone, search for the "Scent Home" app and download it. Or scan this code to download.


APP下载




Scent Home

2. Log in and add the device (please ensure the machine is powered on):


1. Turn on the Bluetooth of your mobile phone
2. Enter the app, register and log in.



- ① Click the "+" button at the top right corner.




- ② Select the model of the machine to be connected.



- ③ Select the corresponding machine ID, enter the initial password "8888", and click "Confirm".




- ④ Do not exit. Wait for the loading to complete.



- ⑤ Click "Complete" to enter the operation page.

APP Control Tutorial

Conventional mode



Equipment Settings

Ambient light switch

On/Off


Click the sliding switch to start or stop the preset tasks

Preview of Preset tasks

Customize working hours

The sliding node can change the mode to 24-hour mode and adjust the gear

Change password



The machine connection password can be modified in the device Settings

Just enter the new password and confirm to modify it

Concentration and consumption

Grade	Work time(s)	Stop time(s)	Consumption(g/h)
G1	7s	70s	0.09
G2	10s	70s	0.13
G3	15s	60s	0.2
G4	20s	60s	0.25
Customized	5-25s	50-300s	—

Note: 1. The abova data is for reference only. If customers use essential oils with different viscosities, the oil consumption will vary;

2. For the best diffusion effect, it's recommended to use essential oils with a viscosity below 30mPa.s. And the optimal working temperature is 25°C.

⚠ WARNING

Safety Instructions

To ensure safe use and prevent harm or property damage, please follow these safety precautions. Failure to comply with these warnings may result in accidents. This product is not designed for the following situations:

- Use by unattended infants, individuals with disabilities, or those with cognitive impairments.
- Use as a toy by young children.

Usage and Storage Instructions

- 1.This aroma diffuser is designed for use with essential oils. Please read the manual carefully before use.
- 2.This product is not suitable for individuals with weakened health (including children). Elderly, pregnant individuals, and those with physical, sensory, or intellectual impairments should consult a doctor before use. Those lacking experience or knowledge, especially children, must be supervised by a responsible person to ensure safe use. Otherwise, they should be prevented from accessing the device.
- 3.The optimal operating temperature for the machine is 20-35°C, with a relative humidity of <85%. Diffusion performance may vary depending on environmental temperature and humidity.
- 4.Store essential oils in a cool, dry place with the cap securely closed, away from direct sunlight. The recommended storage temperature is around 25°C.
- 5.Dispose of the product and protective packaging materials in accordance with local regulations.

Prohibited Guidelines

- 1.Keep away from fire sources.
- 2.Do not ingest essential oil; seek medical attention if swallowed.
- 3.Do not use for purposes other than space diffusion; do not apply fragrance essential oil directly to the skin.
- 4.Avoid extreme temperatures (below -5°C or above 40°C).

Mandatory Guidelines

- 1.Keep out of reach of children and pets to prevent accidental ingestion. Supervise children to ensure they do not play with the device.
- 2.Do not modify, disassemble, or repair the machine unless you are a qualified technician. If a malfunction occurs, contact customer service from the original purchase channel.
- 3.Stop using the device immediately if any abnormalities occur during or after use.
- 4.Place the machine on a level surface and keep it upright after installation. Tilting or placing the device flat may cause oil leakage or malfunction.
- 5.Wipe up any spilled essential oil immediately.

Potential Risks of Injury or Property Damage

1. The following actions may cause electric shock, short circuits, or fire hazards:
 - Do not get the machine or charging port wet.
 - Do not use overloaded power outlets, damaged cords, or faulty plugs.
2. When adding essential oil, avoid excessive pressure to prevent leakage and damage to machine components.
3. Do not pull, crush, cut, or tamper with the power cord.
4. To prevent malfunctions or damage, do not disassemble the machine during use.
5. If the adapter, charging cable, or power cord is damaged, it must be replaced with a specialized component provided by the manufacturer or authorized service provider.
6. Use only the specified low-voltage power supply as marked on the device.
7. Only use the power adapter included with the product.
8. Use only the recommended evaporation medium. Using other substances may pose toxic or fire risks.



Troubleshooting

Before asking to have the machine repaired, please try to diagnose the problem first by following the instructions below.

Breakdown	Solution
Does not diffuse	-Check if the machine is in a "Non-Working period". -Air pump may be damaged, replace with a new one. -Check whether the tube is loose or not.
Low diffuse	-The atomizing core is blocked, clean with alcohol or change to a new atomizer heads. -Check whether the gasket is damaged/loose or missing. -Check whether the tube is loose or not connected.
Oil spill	-Check whether the bottle is loose . -Check if the gasket in the atomized head is damaged, loose or missing.

Oil sprinkle	-The atomized head is damaged: change to a new one. -The machine is tilted or laying flat, keep the machine vertical.
Abnormal noise	-The air pump is loose, retighten the pump -The air pump is damaged:replace.

【FCC Statement】

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Not applicable

RF Exposure
This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. be installed and operated with minimum distance 20cm between the radiator & your body.

【ISED Statement】

English:This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.
The digital apparatus complies with Canadian CAN ICES - 3 (B)/NMB - 3 (B).

French: Cet appareil contient des émetteurs/récepteurs exempts de licence qui sont conformes aux RSS exemptés de licence d'Innovation, Sciences et Développement économique Canada. L'exploitation est soumise aux deux conditions suivantes :
(1) Cet appareil ne doit pas provoquer d'interférences.
(2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.
l'appareil numérique du ciem conforme canadien peut- 3 (b) / nmb -3 (b).

This device meets the exemption from the routine evaluation limits in section 6.3 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance. cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 6.3 du cnr - 102 et conformité avec rss 102 de l'exposition aux rf, les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs rf et la conformité.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment. Cet équipement est conforme aux limites d'exposition aux rayonnements du Canada établies pour un environnement non contrôlé.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.

SAVE THESE INSTRUCTIONS