


Product model: YS-001

YESOUL Smart Cycling Bike G1 MAX Product Manual


Installation Guide

STEP 2: Installation of bottom tube

1. Take L-type cross head hex wrench 6# (D) out of the ziplock bag.
2. Remove four hexagon socket button head screws (M6×45) and washers of the front tube 2 and rear tube 3 via the L-type cross head hex wrench 6# (D).




3. Align the holes of the front and rear front tube 2 and rear tube 3 with the bottom holes of the frame 1, manually screw the washers and hexagon socket button head screws (M6×45), and tighten them via the L-type cross head hex wrench 6# (D).



Installation Guide


3. Please align the two protruded holes on the screen fastener 14 with the display holder/s as shown in the figure and use the open-ended wrench 17# (A) and the hex wrench 4# (B) to lock the nuts and bolts and gaskets to the screen fastener 14, as shown in the figure.



* Note: Please check and ensure that the screen support rotating joint should be tightened.

4. Please pay attention that the screen support rotating joint should be tightened so that the screen can be fixed in a rotary manner at various angles, and will not easily drop and rotate. (During the usage process, if there is any looseness or if it is required to adjust the joint, please follow this method for adjustment.)

Please tighten the screen support rotating joint.



Product Parameters

Screen size	32 inch (1366*768 pixels)
Supporting software version	Android 8.0
Resistance system	Magnesium resistance system
Drive mode	Belt drive
Power supply input	DC 24V ■ 3A
Wireless connection	WiFi 2.4G/Bluetooth
Height limit	150 ~ 188cm
Rated maximum load	120kg
Net weight	27kg
Gross weight	40kg
Overall dimensions	(Length) 1495mm × (Width) 530mm × (Height) 1525mm


Routine Maintenance

1. Keep the cycling bike on a dry, ventilated and flat floor, if not used in a long time, the bike should be covered to keep its body clean and tidy.
2. Wipe off sweat on the frame with cloth after exercise. Do not wipe the bike with wet cloth, in order to avoid rusting.
3. Check the belt pulley for cracking and deviation, and adjust or replace the belt in time. Regularly clean the belt groove to prevent the belt from jumping out of the groove.
4. Always check the screws of all body parts for loosening or falling, and tighten or replace them in time.
5. Always check the resistance adjustment knob for loosening or falling. Check whether the resistance is reasonable, so as to calibrate resistance in time.
6. Always check the screws of pedals and cranks for loosening, and tighten them in time.
7. Always check whether the saddle is loose and tighten it in time. Wipe the saddle with cotton cloth to keep it dry.
8. Always check the power cable for cracking and deviation, and replace the damaged one in time.

Installation Guide


STEP 3: Installation of head tube

1. Screw out the adjustment knob as indicated by the arrow, and connect the screen connection cable in the head tube 13 to the cable in the bike 1 (as shown in the figure). After the screen connection cable is connected, align the head tube 13 to the mounting hole of the frame 1 (Note: Place the surface with a hole in the head tube 13 outwards. Do not press the cable).



Align the port to connect to the screen connection cable
* Please make sure that the connection direction is correct. Please do not connect it with violence.


2. Insert the head tube 13 into the frame 1, and keep the scale parallel to the top surface of the tube. Align the hole on the head tube 13 with the hole on the frame 1. Then, tighten the adjustment knob as indicated by the arrow.



Installation Guide

STEP 6: Installation of dumbbell rack


1. Use the hex wrench 5# (C) to remove the screws (M6×12) from the slide tube;
2. Put the dumbbell rack 11 on the slide tube and align the holes;
3. Manually install screws through the holes, and use the hex wrench 5# (C) to lock.
4. Place the dumbbell on the dumbbell rack.



STEP 7: Installation of bottle holder

- As shown in the figure, remove the two hexagon socket button head screws pre-installed in the screen bracket 6; and align the bottle holder with the slot in the screen bracket 6, and push it in along the direction shown in the figure.

- Then, use the hex wrench 4# (B) to align two hexagon socket button head screws with the holes, and lock the bottle holder.



Important Safety Instructions




Please read them carefully. Improper use may result in personal injury or death!

1. Make sure that the saddle height adjustment knob is secured correctly, and will not affect motion during exercise.
2. Keep children and pets away from this product. This product is for those over 18 years old only.
3. Never stretch any object or body part into the openings of the bike.
4. The weight of the user must not exceed the maximum load.
5. Get off the bike until flywheel and pedals stop rotating. Otherwise, severe injuries may be caused due to control failure.
6. If you feel any discomfort, such as dizziness or breathing difficulty, stop riding the bike and carefully get off.
7. Never turn pedals by hand, or touch any rotating mechanical part; otherwise, personal injury may be caused.
8. Keep the body hydrated as needed during riding.
9. Use this product according to the instructions in this manual. Warm up fully before exercise.
10. Without the preliminary determination of baseline fitness level and medical certificate signed by a doctor, never be engaged in high-speed or high-intensity sports. Before attempting any high-intensity short sprints, pay attention to the body state and posture, and apply a controllable speed.
11. Wear professional cycling clothes or tight-fitting sportswear and sports shoes, and tighten foot straps to avoid injury caused by pulling or entanglement by this product.
12. Never use this product with inappropriate shoes or barefoot.
13. Incorrect or excessive training may cause injury.
14. Check whether the bike for loosening or damage before each use.
15. Never ride this bike or use non-original accessories without permission. The casing must be opened by professionals, in order to avoid damage.
16. Those pregnant or with high blood pressure, heart disease, lumbar spondylosis or reduced mobility must not use this product without the permission of doctors.
17. In case of any discomfort such as dizziness or chest pain during exercise, stop exercising immediately and go to a hospital for examination.
18. If the product fails, immediately stop using it.
19. This product must not be used for medical rehabilitation.
20. Use this product on a flat and clear ground.
21. Carry out preventive maintenance regularly.
22. Never expose this product in a humid place. This product must not be used outdoor or in any humid place.
23. This product is for household use (Class II) and not medical fitness equipment.
24. Get off the bike or enable the emergency brake until inertia wheel and pedals stop rotating. Otherwise, severe injuries may be caused due to control failure.
25. Turn the knob to the right end to lock the corresponding component.
26. Please use the standard power adapter. Replacement of the power adapter without authorization may cause serious consequences.


Installation Guide

STEP 4: Installation of handlebar assembly

1. Remove the four M6×12 hexagon socket bolts pre-locked on the head tube 1.
2. Pass the screen connection cable through the hole in the handlebar assembly 5 (as shown in the figure).




3. Align the holes at the connection of the handlebar assembly 5, and place the M6×12 bolts 1-2 (as shown in the figure) into the holes, and manually rotate the screws (at this point, do not screw them tightly); then, connect the screen connection cable to the cable inside the display holder 6 (as shown in the figure). Then, insert the display holder 6 into the round hole of the handlebar as indicated by the arrow.



Installation Guide (for reference only, subject to the actual product)

STEP 8: Installation of pedal

1. Take the pedals from the package.
2. Distinguish left and right pedals. The right pedal is marked blue "R", and the left pedal is marked red "L". (Pay attention to distinguish left and right pedals, if they are not installed correctly, crank threads will be damaged!)
3. Stand behind the seat and face the handlebar. Install the right pedal on the right crank, and ensure that the pedal is vertical to the crank mounting hole. Use an open-ended wrench (C) to lock it toward the head direction. Install the left pedal to the left crank, and ensure that the pedal is vertical to the crank mounting hole. Use an open-ended wrench (C) to lock it toward the head direction. Note: During installation, correspond the red mark on the crank to the red mark on the pedal, and the blue mark on the crank to the blue mark on the pedal.



Note: Check whether the pedal straps are tightened before riding. Tighten them by pulling them down.



Safety tips:

Reverse riding is not recommended, as it is likely to loosen pedals. After reverse riding, check whether the pedals are locked, in order to avoid safety issues arising from loose pedals.


Installation Guide - List of Parts

STEP1: Check of parts


NO.	Name	Quantity	Picture
①	Frame	1	
②	Front tube	1	
③	Rear tube	1	
④	Pedal set left/right	1	
⑤	Handlebar assembly	1	
⑥	Display holder	1	
⑦	Decorative cover	1	
⑧	Screen	1	
⑨	DC 24V ■ 3A power adapter	1	
⑩	Hexagon socket cap screw M6×35	1	

Installation Guide

4. Align the holes correctly, and put the M6×12 bolts 3-4 (as shown in the figure) into the holes, and screw them tightly respectively. Then, take one hexagon socket cap screw M6×35.0 from the part bag, and manually screw it into the corresponding hole. (Pay attention to protecting the cable and avoid damage) (The picture on the right shows the effect after placing the screen brackets into the handlebar assembly 5).




5. Finally, tighten all bolts via the hex wrench 5# (C) and cover the decorative cover.



Installation Guide (for reference only, subject to the actual product)

STEP 9: Installation of connection cable

1. Plug the cable of the power port (a) and signal port (b) of the display into the jack at the bottom of the back of the display. Make sure that the cable is inserted tightly. Make sure to distinguish the ports specifications. The power cable port should be tightened without looseness.
2. Connect the power adapter 9 to the power jack on the rear part of the frame 1. (Please use the standard power adapter. Replacement of the power adapter without authorization may cause serious consequences.)



Note: Never insert the cable into the interface of the tablet or pull it out without cutting off the power supply.

Installation Guide - List of Parts

NO.	Name	Quantity	Picture
⑪	Dumbbell rack	1	
⑫	Dumbbell	2	
⑬	Head tube	1	
⑭	Screen fastener	1	
⑮	Bottle holder	1	


NO.	Name	Quantity	Picture
A	Open-ended wrench, 17#	1	
B	Hex wrench, 4#	1	
C	Hex wrench, 5#	1	
D	L-type cross head hex wrench, 6#	1	
E	Open-ended wrench	1	
F	Hex wrench, 8#	1	

* In order to facilitate assembly, some accessories have been installed on the body before delivery.

Installation Guide


STEP 5: Fixing of display

1. Use the open-ended wrench 17# (A) and the hex wrench 4# (B). Remove the bolts, gaskets, and nuts pre-installed on the display holder/s, as shown in the figure.



2. Remove the four M6×12 cross screws pre-installed on the screen 8, and align the screen fastener 14 to the hole (The two protruded holes on the screen fastener should be parallel with the screen). Use the L-type cross head hex wrench 6# (D) to fix the screen fastener 14 on the screen 8 with the four M6×12 cross screws through the hole on the screen fastener 14.


* Please put the screen on the desk. Do not touch the screen with hard objects to avoid screen damage.



Installation Guide (for reference only, subject to the actual product)

3. Safety tips:
Never insert the cable into the interface of the tablet or pull it out without cutting off the power supply.

360 degrees of rotation angles of the screen (Here, the hex wrench 4# (B) can be used to tighten/loosen).



Saddle tightening knob (Adjust the saddle horizontally)

Rear column tightening knob (Adjust the saddle height)

Front tightening knob (Adjust the head height)

Move the screen forward and backward

Lockable pulley

Before the first use, please turn the resistance adjustment knob counterclockwise to loosen it; otherwise, you cannot ride the bike!

Statement:

This manual contains the functional introduction and operating instructions as much as possible when printed. With the continuous improvement of hardware and software and optimization of design, this manual may be inconsistent with the purchased product. In case of any discrepancy in appearance, interface and color, the actual product shall prevail.

Free courses

Schematic diagram:
Downward the mobile
phone software



Connect to G1-MAX



1. Account registration:

- 1) Please connect to the G1-MAX cycling bike, and open the display. Use the third-party software in the mobile phone to scan the QR code on the screen, or input the short link in the screen to download the YESOUL APP;
- 2) After installing the YESOUL APP in the mobile phone, register the mobile phone APP account;
3. After account registration, click the "+" in the top-right corner of the mobile phone to connect the mobile phone APP to the G1-MAX device. After WIFI configuration, start to use the G1-MAX;

2. Start riding:

- 1) When you connect the mobile phone APP to the G1-MAX, the connection status can be checked in the left top corner of the APP;
- 2) You can select any training mode or course in the mobile phone APP to start riding;
- 3) Use the mobile phone APP to adjust the quality and control the voice for G1-MAX during riding;

3. About our membership:

- 1) Newly registered users of the Chinese version of APP-YESOUL will get the membership free of charge granted along with the cycling bike;
- 2) Registered users of the international version of YESOUL FITNESS will get 30-day experience period free of charge for the first signing subscription.


Company Name	FUJIAN YESOUL HEALTH TECHNOLOGY CO., LTD.
Product Name	YESOUL BIKE G1 MAX
Add	RM B616, BLDG., No.1, STRAT ECONOMIC AND TRADE PLAZA, FUZHOU FREE TRADE ZONE.
Grade	HC
Executive standard	ISO 20097-1:2007/ISO 20957-10:2007 (GB 17495.1-2008 GB 17498.10-2008 ASTM F 1226/ASTM F 2276
FCC ID	2A3YB-VSGB1MAX
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.	



How to Adjust Bike


1 .Handlebar height adjustment:

Turn the handle to the right with one hand, and hold the middle part of the handlebar with the other hand, and lift (or press) the handlebar to the desired position. Then turn the handle to the left until it is tightened.



2. Saddle height adjustment:


Turn the handle to the left with one hand, and hold the middle part of the handlebar with the other hand, and lift (or press) the handlebar to the desired position. Then turn the handle to the right until it is tightened.



How to Adjust Bike


3.Horizontal adjustment of saddle:

Loosen the handle under the saddle, slide the saddle back and forth to the desired position, and tighten the knob as much as possible.



4.Body level adjustment:

There are four adjustment pads at the bottom of the front and rear pedal tubes. Screw these pads until they are tightly secured on the floor and the body does not shake.



FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following

two conditions: (1) This device may not cause harmful interference, and (2) this device

must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for aClass B digital

device, pursuant to part 15 ofthe FCCRules. Theselimits aredesigned to provide reasonable protection against harmful interference in a residential installation.

This equipmentgenerates,usesandcanradiatradiofrequencyenergyand,ifnotinstalled andused inaccordance withthe instructions,may

causeharmfulinterferencetoradio communications.However,there isno guaranteethatinterferencewill notoccur in a particularinstallation.Ifthisequipmentdoescauseharmfulinterferencetoradioor

television reception, which can be determined by turning the equipment off and on, the

user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible

for compliance could void the user's authority to operate the equipment.

Thisequipment complies withFCC radiation exposure limits setforth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This radiator should be installed and operated with minimum distance 20cm between the radiator&your body.

How to Determine Correct Riding Posture


1. Setup of correct saddle position

Saddle height

Put the feet together, stand on one side of the saddle and adjust the saddle to the hip height (Fig. 1). Then sit on the saddle, and step on the pedals forcibly until they are stopped at 6 o' clock and the leg can be fully stretched (Fig. 2).



(Fig. 1)



(Fig. 2)

Horizontal position of saddle

Put the right foot into the clamp, and step on the pedals, until the right pedal is at 3 o' clock and the front side of the knee joint is on the same vertical line as the pedal, that is, the saddle is in the correct position (Fig. 3).

3o' clock the right crank is parallel to floor in the right directio



(Fig. 3)

How to Determine Correct Riding Posture

2. Setup of appropriate handlebar height

Each user can set up the appropriate handlebar height based on his or her body height and riding experience.

Recommendation: The handlebar should be slightly higher than the saddle for new users (Fig. 1) and flush with or slightly lower than the saddle for experienced users (Fig. 2). Users subject to lumbar muscle strain and lumbar spondylosis may ride the bike with the consent of doctors. It is recommended to adjust the handlebar into a higher position.



(Fig. 1)




(Fig. 2)

3. Handle position layout of bike

During riding, coaches will show the corresponding hand positions, i.e. the corresponding parts of the handlebar, as shown below.

- Hand position 1
- Hand position 2
- Hand position 3



RF exposure warning:

This radiator complies with radiation exposure limits

set forth for an uncontrolled environment. This

equipment should be installed and operated with

Minimum distance 20cm between the radiator and your body.

此页为备注页, 不用印刷
双胶纸70g
425*360mm
双面印刷
1页30面
单色印刷