

USER MANUAL



✉ Customer Service Email:
Sleeptour2016@gmail.com

Feature

- 5.2 Bluetooth Version. Compatible with any Bluetooth enabled devices.
- Built-in microphone for answering phone.
- Hand- washable after removing the Bluetooth modules.
- Lifetime Warranty and 24 hours friendly customer service .

Specifications

- Bluetooth Version: V 5.2 +EDR
- Transmission Distance: 33ft(10m)–49ft(15m).
- Rechargeable Lithium Battery: 180mAH
- USB Charge: 5V/0.5A
- Charging Time: 2-2.5 hours
- Working Time: 10-12 hours

-1-


Package Included:

- Sleep Headphones Headband x1,
- Charging Cable x1,
- User Manual x1,
- Customer Service Card x1

For warranty service or support,
Please contact our Service Team,
Fulext promises: FREE RETURN,
FREE REPLACEMENT or FULL REFUND
to solve your issue and make you satisfied.

Please contact our customer service email.
Sleeptour2016@gmail.com

Function Summary



- ① LED Status Light
- ② Volume Down/ Next Track
- ③ On / Off / Play / Pause / Answer
- ④ Volume Up / Previous Track

-3-

Control

Power On/Off		Press and hold for 3 seconds
Play/Pause Music		Press once
Volume Up/Down		Press and hold during music playing
Next Track		Press once
Previous Track		Press once
Answer/End Phone Call		Press once when phone ringing
Reject Call		Press and hold for 3 seconds
Switch to Mobile Device		Press and hold for 3 seconds

-4-

How to connect it?

- ① Turn on Bluetooth on device.



- ② Turn on the sleep headphones headband

Press power button for 3 seconds until red and blue lights blink. On your device, go to Bluetooth settings and choose BT-DLAB.

- ③ Connect to Bluetooth (Name: BT-DLAB) on device.

LED Color	Status
Rapidly flashing blue and red	Pending to be Connected
Red and blue lights disappear	Connected

-5-


⚠ Warning:Do not attempt to power on or connect the device while charging. The Bluetooth transmitter is disabled while it is charging,thus you will not be able to connect while charging.

⚠ Warning:When turned on, the sleep headphones headband will automatically connect to the last connected device if available. If no previously paired device detected, it will keep pairing mode.

⚠ Warning: Only one Bluetooth connection is allowed, if user want to connect to another device, please make sure to cancel the previous device.

-6-


2. Devices Name: BT-DLAB



-7-

CHARGER AND BATTERY

Slide cable out through the slit to connect to USB. Before using a different charger, check whether the specifications of the charger meet requirements. The recommended output voltage of the charger is DC5V+/-0.25V, and the recommended output current is 100 mA to 500 mA. A higher charging voltage may damage the device. Do not use the sleep headphones headband while charging. The sleep headphones headband will work with any USB-C cable. Connect the USB-C cable to USB charger (or computer USB port).



-8-

⚠ Please note that you MUST remove the control panel & speaker before washing the sleep headphones headband.

How to wash Bluetooth Headband?



-9-

- Do not expose sleep headphones headband to liquid or moisture.
- Do not store sleep headphones headband near acidic or alkaline material.
- Do not keep sleep headphones headband close to the fire. Do not tumble dry.
- Please remove the Bluetooth module before washing. After completely dried, put back to their original position.
- The speakers can be adjustable, you can adjust it to the best place until they fit for your ears!
- Please charge the sleep headphones headband when you receive it.
- Please turn off Bluetooth function to save power when not working.
- Please note that a 'DI DI DI' sound will be heard when reaches max/min volume level.

-10-

- Please try to restart your device if the sleep headphones headband keep cutting out.
- If you hear a low volume when you connect for the first time, try to adjust the volume key on your phone or tablet.

For warranty service or support,
Please contact our Service Team,
Fulext promises: FREE RETURN,
FREE REPLACEMENT or FULL REFUND
to solve your issue and make you satisfied.

-11-

Model Number:

LAH001 / LAH002 / LAH003 /
LAH004 / LAH005 / LAH006 /
LAH007 / LAH008 / NAH001 /
NAH002 / NA011 / NA012 /
NA013 / NA014 / NA015 /

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any

-12-

interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can

-13-

radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the

-14-

receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general **RF** exposure requirement. The device can be used in portable exposure condition without restriction.

✉ Customer Service Email:
Sleeptour2016@gmail.com

-15-