




56x168mm

Scan translation pen MD32 AI & OCR  user manual	01 Scanning method: Hold the pen, place the alignment line of the pen head in the middle of the text, and gently press it down Pen head: after the light is on, move the pen to the right at a constant speed for scanning.  Note: Please tilt it properly so that the pen head contacts the paper.  02 Key introduction  *[Return key]: The second button on the right side is the return button, or you can click "←" in the upper left corner of the interface to return to the previous interface. - 01 -	03 Power on Power on: in the power off state, press and hold the power button for about 3 seconds to enter the operation interface Shutdown: in the power on state, press and hold the power button for 3 or 10 seconds to select restart / shutdown or forced shutdown. After the screen goes to sleep, press the power button once to recover. 04 Force restart When the device gets stuck in a certain interface and cannot be operated, press and hold the power button for about 16 seconds to force a restart. 05 Connect WiFi Click on Settings, then click on "WiFi", find the correct WiFi name and enter the password to connect. [Note: When going out to connect to a mobile hotspot WiFi, it is necessary to set the mobile network to 2.4G (4G).Currently only supports connect to 2.4G (4G) WiFi and does not support 5G WiFi.] 06 Connect Bluetooth Click on Settings, then click on "Bluetooth", turn on the Bluetooth switch, and then turn on the Bluetooth for the Bluetooth earphones/Bluetooth speakers. Click on the Bluetooth device name in the search interface, and wait for 07 Set System Language Set/modify system interface language: Click on Settings, then - 02 -	click on "Language", find the desired language,and select it to switch system languages. (Settings->Language ->Select Language). 08 Sound volume settings Set/Modify Sound Volume: Click on Settings, then click on "Sound" to enter the volume interface and slide left and right to adjust the sound volume. (Settings ->Sound ->Slide Left and Right) 09 Scan translation Click on "Scan dictionary"/"Online scanning translation",set the left language to be scanned and the right language to be translated. Then start scanning the text. After the scanning is completed, it will be translated into the set target language in real time. Click on the "Speaker" icon on the left,it can speak the original text and translation text.In the settings, you can select to turn on the vertical to switch to the vertical scanning mode. 10 Voice translation  [Voice translation with WiFi]: Long press the "Speaker" icon to speak the blue language (top on left), which can be translated into red language. Long press the "Speaker" icon to speak the red language (top on right), which can be translated into blue language. The blue and red languages can be set by yourself, with over 100 languages to choose from. - 03 -
11 Text excerpt Click on "Text excerpt" in the main interface to scan the text content to be extracted. After scanning, click "Finish" to save it to the machine and view it from the history; Or click upload to email address, then download and save from email. You can extract the text you need in real time. 12 Smart record Click on "Smart record" in the main interface, then click build record in the upper right corner, click the recording button to start recording. After recording, save the recorded content in the device to make notes of important information. 13 Dictionary Click on "Dictionary" in the main interface to select a dictionary for quick word search and interpretation. There are several different dictionaries to choose from. 14 Vocabulay Built in primary school, junior high school, senior high school, level 4 and level 6 word content and vocabulary of postgraduate entrance examination, IELTS, TOEFL, SAT and GRE for easy reference and learning. - 04 -	15 Set up It can set horizontal / vertical scanning, WiFi connection, screen brightness, volume increase / decrease, standby time, shutdown time, voice channel, speech speed, input method switching, etc. it supports connecting Bluetooth headset. 16 AI- Assistant The "Assistant" function can be used for man-machine question and answer, realize online query and answer of words, idioms, poems and translations, and check the weather, tell jokes, etc. there is no lack of leisure and entertainment while studying and working. 17 Favorites "Favorites" contains the important and difficult words and characters collected during the study of English and Chinese word search. You can find them here when reviewing and consulting. It is more convenient and fast, improves the learning efficiency, and avoids the tedium of repeated word search. 18 Music & Video Support the data cable to connect the computer, copy the downloaded and saved music video content to the folder corresponding to the translation pen, and play the music video in the translation pen. Equivalent to music video player function. - 05 -	19 Warning Please use a charger with standard voltage of 5V and current of 1a to charge. If other types of accessories are used, it may violate the warranty scope and relevant regulations of the equipment and may lead to safety accidents. Please use the equipment within the temperature range of 2 °C - 35 °C, and store the equipment and its accessories within the temperature range of - 20 °C ~ + 40 °C. when the ambient temperature is too high or too low, it may cause equipment failure. Do not expose the equipment to high temperature or around the heating equipment, such as sunshine, heater, microwave oven, oven, etc. when the charging is completed or not charged, please disconnect the charging line from the equipment, And unplug the charger from the power socket. Do not use the charger during charging. The battery is built-in and cannot be disassembled. Do not replace the battery to avoid damage to the equipment. Please dispose of the relevant accessories according to the local electronic and electrical recycling pipes. They cannot be treated as general domestic garbage. 20 Packing list · Translation pen*1 · Protection film*1 · Instructions*1 · Protective sleeve*1 · Charging line*1 - 06 -	22 Warranty description Thank you for purchasing our products. To ensure your legal rights and interests, please read the following carefully. This card is the product warranty certificate. When the product needs maintenance, please provide this card together with the product to our company for after-sales service. This card is only valid for products within the warranty scope. For details, see the following: 1. The products obtained by the company through legal and formal channels enjoy a one-year warranty period 2. In case of unauthorized disassembly, improper use and natural disasters, products containing human damage are not covered by the warranty 3. It shall not exceed the warranty period of the product. 4. If the damage is caused by improper use or artificial damage, we do not support refund. 5. If the product has quality problems, repair or replacement is supported within the warranty period, and return is not supported. Warning: This product is not recommended for use alone by children under three years of age.Do not close to fire source or place in high temperature environment to avoid product failure or damage.  - 07 -

Federal Communications Commission Notice

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.