

骨传导无线耳机

使用说明书


健康 · 舒适 · 释放双耳

按键功能概述



释放双耳，放心自由，听音乐的同时还能聆听外界的声音；听音乐，打电话，玩游戏，立体声音，音质音效，清晰震撼；是您办公、外出、驾驶的最佳选择！

外观展示



控制说明

开机：耳机处于关机状态，长按右按键，保持3秒，蓝灯长亮3秒，再进入红蓝灯交替闪烁，提示音：英文是power on，中文是开机；
关机：耳机处于开机状态，长按右按键，保持5秒，红灯闪烁后关机，提示音：英文是power off，中文是蓝牙正在准备关机；
连接BT：开机后进入配对状态，红蓝灯交替闪烁，手机、台式电脑、笔记本电脑设备搜索到**H20**，手动点击连接，提示音：英文是pairing，中文是等待连接；
配对成功：开机状态下，耳机自动进入搜索配对模式，蓝灯每五秒闪一次，首次开启蓝牙需手动点击连接，耳机提示音：英文是Connected，中文是蓝牙已配对成功；
断开蓝牙：手机主动断开蓝牙，红蓝灯交替闪烁，耳机提示音：英文是pairing，中文是等待连接；
暂停/播放：蓝牙连接状态下，单击左/右按键播放，蓝灯每五秒闪一次；
音乐播放状态下，单击左/右按键暂停，蓝灯每五秒闪一次；
接听/挂断/拒接：来电状态下，单击左/右按键为接听，蓝灯慢闪(间隔5s)，长按2秒左/右按键为拒接；通话状态下，单击左/右按键为挂断；
音量增加：音乐和通话状态下，双击右按键，音量加一格；
音量减小：音乐和通话状态下，双击左按键，音量减一格；
下一曲：音乐状态下，3击右按键播放下一曲；
上一曲：音乐状态下，3击左按键播放上一曲；
语音助手：（连接蓝牙后，未拨打电话）长按2秒左按键进入语音模式，再长按2秒退出；（注意：开关siri, android需要在语音助手打开“蓝牙耳机按键启动”，ios需要关闭后台才打开siri功能）；
恢复出厂设置：开机任何状态下，一起长按左右按键5秒，连续3次红灯闪烁，听到“嘟嘟”后，表示恢复出厂设置成功；
中英文切换：蓝牙任何状态下，一起单击左右按键切换，听到提示音后，表示切换成功；

充电：

- 1.耳机使用5V充电座充电时，耳机关机，也无法开机，红灯常亮，充满电红灯转蓝灯。
- 2.充电时LED灯为红色，红灯常亮。
- 3.建议充电器规格，输出电压为：**DC5V +/-0.25V**，输出电流为：**100mA-500mA**

充电器和电池

充电器和电池
使用任何充电器给本耳机充电前，请先检查充电器的规格标注是否符合要求(建议充电器输出电压为：**DC5V +/-0.25V**，输出电流为：**100mA-500mA**)，充电电压过高极有可能会损坏蓝牙耳机。

警告： 仅可使用经过认可与此配套的充电器，使用其它规格的充电器可能违反对设备的认可和保修条款，并可能导致危险。如果出厂是配电线出货的，需连接通过3C认证的充电器或电脑给其充电。禁止对本产品严重碰撞，严重撞击有可能损坏电子主板及电池。

为电池充电

- 本耳机使用内置式不可拆卸充电电池，请勿尝试从耳机中取出电池，以免损坏耳机。长期不使用耳机时，请将其存放到干燥通风的地方，并每隔两个月给其充电一次。
- 1.当连接的耳机闪红灯，并听到滴滴的低电量提示音时，表示耳机电量不足。如果继续使用会自动关机，此时需要充电，将充电器的连接线插头插入耳机插孔中。
 - 2.将充电器插到交流电源插座上。
 - 3.充电时指示灯亮红灯。如果充电未开始，请断开电源与耳机的连接，然后将其重新插入耳机再试一次。电池充满电后，红灯熄灭，蓝灯常亮，此时断开充电器与电源插座和耳机连接。
 - 4.实际通话时间和待机时间可能与手机、使用设置、使用方法和环境而存在差异。

佩戴说明



产品规格

音乐播放时间-----标准状态:7小时	喇叭阻抗-----8Ω±3db
待机时间-----10天	麦克灵敏度-----42±2db
充电时间-----2.5小时	产品重量-----29g
BT版本-----5.0	连接距离-----10米

重要说明

- 本款耳机扬声器正确佩戴位置为耳朵前方的面颊骨处，请勿将扬声器置于耳内；
 - 长时间听大音量的音乐可能会带来不适感，请尽可能使用中等左右的音量，避免长时间使用大音量；
 - 无论音量大小，使用耳机都将影响您对周围环境的感知，使用耳机时多加注意；
 - 切勿乱扔、坐压耳机或将其浸入水中；耳机应远离火、水和高压设备；
 - 不适合三岁以下儿童使用，包含小零件；
 - 请勿将其归类为生活垃圾，而将其送往当地相应的电器电子设备回收站；
- ★若用户因违反以上警告内容造成的人身财产损失，本公司不承担任何责任。

合格证


品 牌 _____
产品名称 骨传导无线耳机
产品型号 H20A
生产日期 _____
检 验 合格
检 验 员 _____

Bone conduction wireless headset

User Manual


Health · comfort · Release the ears

Overview Of Button Functions



Free your ears, feel free, listen to music while listening to the sound of the appearance; Listening to music, making phone calls, playing games, stereo sounds, real sound effects, clear and shocking; It is the best choice for your office, going out and driving!

Appearance display



Control Description


Power on: when the headset is turned off, press and hold the right button for 3 seconds, the blue light will be on for 3 seconds, and then enter the red and blue light to flash alternately. The prompt tone: power on in English and power on in Chinese;
Power off: the headset is in the power on state, press and hold the right button for 5 seconds, and turn off after the red light flashes. The prompt tone: power off in English and Bluetooth in Chinese are preparing to power off;
Connect BT: enter the pairing state after power on, the red and blue lights flash alternately, the mobile phone, desktop computer and notebook computer search for H20, click the connection manually, and the prompt tone: pairing in English and waiting for connection in Chinese;
Pairing success: in the power on state, the headset automatically enters the search pairing mode, and the blue light flashes once every five seconds. When you turn on Bluetooth for the first time, you need to manually click the connection. The headset prompt tone: English is connected, Chinese is Bluetooth has been paired successfully;
Disconnect Bluetooth: the mobile phone actively disconnects Bluetooth, the red and blue lights flash alternately, and the headset prompt tone: pairing in English and waiting for connection in Chinese;
Pause / play: when Bluetooth is connected, click the left / right button to play, and the blue light flashes every five seconds;
When the music is playing, click the left / right button to pause, and the blue light flashes every five seconds;
Answer / end / reject: in the incoming state, click the left / right button to answer, the blue light flashes slowly (with an interval of 5S), and long press the left / right button for 2 seconds to reject; In the call state, click the left / right button to hang up;
Volume increase: double click the right button to increase the volume by one space in the state of music and call;
Volume reduction: double click the left button to reduce the volume by one grid in the state of music and call;
Next song: under music status, 3 Click the right button to play the next song;
Previous song: in the music state, 3 Click the left button to play the previous song;
Voice assistant: (after connecting Bluetooth, make a call without broadcasting) long press the left button for 2 seconds to enter the voice mode, and then long press for 2 seconds to exit; (Note: when Siri is turned on and off, Android needs to turn on "Bluetooth headset key start" in the voice assistant, and IOS needs to turn off the background to turn on Siri function);

Restore factory settings: in any state of startup, press and hold the left and right buttons for 5 seconds, and the red light flashes for 3 consecutive times. After hearing "beep", it indicates that the factory settings are restored successfully; Switching between Chinese and English: in any state of Bluetooth, click the left and right buttons together to switch. After hearing the prompt tone, it indicates that the switching is successful;
Charge:
1. When the earphone is charged by 5V charging stand, the earphone will be turned off but it cannot be turned on. The red light is always on, and the fully charged red light to blue light.
2. When charging, the LED is red and the red light is always on.
3. Recommended charger specification, output voltage:DC5V +/- 0.25V,output current:100mA-500mA.

Chargers and Batteries

Charger and battery
Before using any charger to charge the headset, please check whether the specifications of the charger meet the requirements (recommended charger the output voltage is: **DC5V +/- 0.25V**, the output current is: **100mA-500mA**), the charging voltage is extremely high and it is possible. Can damage Bluetooth headset.
WARNING: Only use chargers approved with this accessory. Use of other types of chargers may violate approval and warranty terms, and may cause danger, if the factory is shipped with a charging cable, you need to connect a 3C certifie Charger or computer. It is forbidden to severely collide with this product. Serious impact may damage the electronic motherboard and battery.
Charge the battery
This headset uses a built-in non-removable rechargeable battery. Do not attempt to remove the battery from the headset, as it may damage the headset. When you are not using the headset, store it in a dry and ventilated place and charge it every two months.
1. When the connected headset flashes red and you hear a low battery sound, it means that the headset is low on power. If you continue to work it will automatically shut down. At this time, you need to charge. Plug the charger's cable into the headphone jack.
2. Plug the charger into an AC power outlet.
3. The red indicator light is on when charging. If charging does not start, disconnect the power supply from the headset, then plug it back into the headset and try again. When the battery is fully charged, the red light goes out and the blue light is always on. At this time, disconnect the charger from the power socket and headphones.
4. The actual call time and standby time may differ from the phone, usage settings, usage and environment.

Wearing Instruction



Hang the earphones behind the neck and attach the speakers on the sides to adjust the wearing comfort.

Product Specifications

Music playing time----Standard status: 7 hours	Speaker impedance----8Ω±3db
Standby time ----- 10 days	Mike sensitivity-----42±2db
Charging time ----- 2.5 hours	Product weight -----29g
BT version -----5.0	Connection distance ----10 m

Important

- The correct position of this headset speaker is the cheek bone in front of the ear. Do not put the speaker in the ear.
 - Listening to high volume music for a long time may bring discomfort, please try to use a medium or so volume as much as possible to avoid using large volume for a long time;
 - Regardless of the volume, using headphones will affect your perception of the surrounding environment. Pay more attention when using headphones;
 - Do not throw, sit or press the headset or immerse it in water; • Keep the headset away from fire, water and high voltage equipment;
 - Not suitable for children under three years old, including small parts;
 - Do not classify it as domestic waste, and send it to the corresponding local electrical and electronic equipment recycling station;
- ★The company will not bear any responsibility for personal and property damage caused by the violation of the above warning content.

CERTIFICATE

Brand _____
Product Name Bone conduction wireless headset
Product Type H20A
Production Date _____
Test _____
Inspector _____

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction