

immoo

Dual-mode wireless mouse

Instructions

Product specification

Product name: M201

Working mode: photoelectric induction

Connection: 2.4G, Bluetooth

Working distance: about 10m open distance

Operating voltage: 5V

Product size: 100*62*35mm


Product weight: 70g±5G

Input: DC 1.5V(AA) battery

Working frequency: 2402-2480MHz

Supported systems: Windows 7, Windows 8, Windows 10, Windows VISTA,
Windows XP or later versions are recommended

Product specification



- ① Left button ② Right button ③ Mid button
④ DPI Switch button ⑤ Mode switch

Charging light instructions

When charging	power indicator is red on
When the battery is full	the power indicator is red off
Low power	the power indicator blinks red

2.4G Mode

1. Flip the bottom switch to 2.4g gear.
2. Turn on the Bluetooth switch of the computer device, search the mouse name: BT5.2 in the added device, and click Connect.
3. It can be used after successful connection.

Bluetooth Mode

1. Flip the bottom switch to bluetooth gear.
2. Turn on the Bluetooth switch of the computer device, search the mouse name: BT5.2 in the added device, and click Connect.
3. It can be used after successful connection.

* To use BT5.0 signal, you can long press the MOUSE DPI key, the left mouse key, the middle mouse key and the right mouse button for four seconds at the same time, the mouse will send BT5.0 signal, re-pairing operation can be done.

Sleep mode

In wired mode, the mouse does not sleep. In 2.4g/Bluetooth mode, the mouse will automatically sleep after 10 minutes of no operation. You can wake up the mouse by moving or clicking.

Bluetooth Mode

1	800 DPI	2	1200 DPI	3	1600 DPI
---	---------	---	----------	---	----------

FCC warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

