


Elibom BC02

User Guide



English

Warranty


All Elibom product carries a 12-month warranty from purchase date.
Please contact our official mailbox to activate the extra 2-year warranty.

Elibom customer service email:
elibomservice@outlook.com



Email QR code

Product information



Instructions

Turn on the headphones:

Press the right button for 3 seconds until the LED Indicator flashes.
Speaker will say: "Power on".

Turn off the headphones:

Press the right button for 3 seconds until the LED Indicator flashes.
Speaker will say: "Power off".


Pairing:

1. Start with Elibom turned off.
2. Press and hold the right power button until the LED Indicator flashes.



3. Open your device's Bluetooth settings and select "Elibom BC02".


Speaker will say "Connected", and the LED light flashes.



Wear

Pick up the headphones, bring them behind the back of the base of your neck, position the earhooks on your ears, then enjoy your music !

Wearing your headphones the wrong way could cause discomfort. The transducers should rest in front of your ears.



Multifunction Button


Features	Operating	Voice reminder
Turn on	Long press the right power button for 3 seconds	"Power on"
Turn off	Long press the right power button for 3 seconds	"Power off"
Adjust volume	Volume+: Long press the right button Volume-: Long press the left button	A "beep" will sound when the volume is at its max
Play/pause music	Click the button once	
Previous song	Double-click the left button while music is playing	
Next song	Double-click the right button while music is playing	
Answer call	Click the right/left button once	
End call	Click the right/left button once during a call	
Switch between English and Japanese	Triple-click the left button while on pairing. (in disconnected)	
Wake up Siri	Triple-click the left button	
LED light sensor switch	In the power-on state, triple-click the right button to close, and triple-click the right button again to open	

Headphone specifications


Model	BC02	Speaker	16MM bone conduction vibration speaker
Frequency band	20Hz~20KHz	Bluetooth connection distance	10 m
Microphone	-38dB±3dB	Bluetooth version	Bluetooth V5.3
Bluetooth protocol	V5.3(AAC,SBC)	Keep playing	8 h
Battery	Polymer battery	Charging time	2 h
Standby	Up to 10 days	Bluetooth operating frequency range	2402MHz~2480MHz
Weight	28g	Water resistance	IPX6
Charging voltage	5V±5%	Battery capacity	240mAh
Microphone impedance	8.5 ohm±20%	Maximum RF output power	7.11 dbm

Charging tips

When the headphones are at low battery, there will be a "battery low" prompt. Please use the corresponding cable for charging.



The charging indicator will turn red during the charging process and the headphones will automatically turn off. When charging is complete, the charging indicator will turn off.



Charging

*Please keep the magnetic charging port dry and clean before charging.
(For this purpose we have equipped a cleaning cloth, please wipe the charging port regularly to avoid failure to charge.)

Finished charging

Storage and Maintenance

- Store the headphones in a cool, dry place. The working temperature should be 0-45°C(32~113°F). Working in a cold/hot temperature, highly humid area, or low air pressure environment may reduce the battery life.
- Keep the product away from heat sources, direct sunlight, combustible gas or other liquids.
- Keeping the charging port dry before connecting to the charger will reduce the risk of damage.
- These headphones are water-resistant, but are not waterproof. Please do not submerge the headphones in water.
- Clean the headphones with a soft dry cloth.
- Do not charge right after exercising, in case there's sweat inside the charging port, which could lead to circuit burning while charging.
- After storage for a long period, please charge the headphones before using again.

Note:

Design and specification are subject to change without notice.
For the most up-to-date product information, please contact **elibomservice@outlook.com**


FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction
FCC ID: 2A72B-BC02

Packing list

If any part of your product is damaged or missing, do not use it. Contact authorized Elibom dealer or Elibom customer service.




*Please note that the packaging envelope may vary depending on the sales region.

Warning: Small parts not for children under 3 years or any individuals who have a tendency to inedible objects in their mouths.

ELIBOM

Elibom BC02

ユーザガイド



日本語

保証



すべてのElibom製品には、購入日から12か月の品質を保証する。
2年間の追加保証を有効にするには、公式メールでお問い合わせください。

Elibomカスタマーサービスの電子メールアドレス：
elibomservice@outlook.com



Email QR code

製品仕様



イヤホンの操作方法

イヤホンの電源オン:
LEDインジケータが点滅するまで、右ボタンを3秒間押ししてください。
*「電源オン」と音声案内が聞こえます。


イヤホンの電源オフ:
LEDインジケータが点滅するまで、右ボタンを3秒間押ししてください。
*「電源を切る」と音声案内が聞こえます。

ペアリング

- 1.Elibomを「オフ」にした状態で起動します。
- 2.LEDインジケータが点滅するまで、右の電源ボタンを押し続けます。




3.設備のBluetooth設定を開き、[ElibomBC02]を選択します。「接続済み」と言います。LEDライトが点滅します。



装着方法

イヤホンを手に取り、首の付け根の後ろにまわしてください。
イヤフックを耳にかけて装着します。あとは音楽をお楽しみください。



ボタン操作一覧


特徴	オペレーティング	音声リミッター
電源オン	右の電源ボタンを3秒間長押し	「電源オン」
電源オフ	右の電源ボタンを3秒間長押し	「電源を切る」
音量を調整する	音量+: 右ボタン長押し 音量-: 左ボタン長押し	音量が最大になると「ピープ音」が鳴ります
音楽の再生 / 一時停止	ボタンを1回クリックする	
前の曲	音楽再生中に左のボタンをダブルクリックする	
次の曲	音楽再生中に右ボタンをダブルクリックする	
電話に出る	右 / 左ボタンを1回クリックします	
電話を切る	通話中に右 / 左ボタンを1回クリックします	
英語と日本語の切り替え	ペアリング中に左ボタンをトリプルクリックします	
Siriを起動する	左ボタンを3回押し続けます	
LEDライトセンサースイッチ	パワーオン状態で、右ボタンを3回クリックすると閉じ、再度右ボタンを3回クリックすると開きます	

ヘッドホン仕様


モデル	BC02	スピーカー	16MM 骨伝導振動スピーカー
周波数帯域	20Hz-20KHz	Bluetooth接続距離	10m
マイクロフォン	-38dB±3dB	Bluetoothバージョン	Bluetooth v5.3
Bluetoothプロトコル	V5.3(AAC,SBC)	再生し続けま	8h
バッテリー	ポリマー電池	充電時間	2h
待機する	最大 10 日	Bluetoothの動作周波数範囲	2402MHz-2480MHz
重さ	28g	耐水性	IPX6
充電電圧	5V±5%	バッテリー容量	240 mAh
マイクのインピーダンス	8.5 ohm±20%	最大 RF 出力電力	7.11 dbm

充電のヒント

イヤホンのバッテリー残量が少なくなると、「充電してください」と音声案内があります。対応するケーブルを使用してください。



充電の時、インジケータが赤く点灯し、ヘッドホンの電源が自動的に切れます。充電が完了すると、充電インジケータが消灯します。



充電 充電が終了しました

*充電する前に、充電口を乾燥させ、清潔に保ってください。(そのためにクリーニングクロスを用意していますので、定期的に充電口を拭いて充電不良を防いでください)

保管とメンテナンス

- イヤホンは乾くて涼しい場所に保管してください。動作温度は0～45℃(32～113°F)とし、この温度を超える低温、高温、多湿の場所、または極端に低い気圧の場所での使用はバッテリーや製品の寿命を短くする原因となります。
- 製品は、熱源、日差し、可燃性ガス、およびその他の液体から遠ざけてください。
- 充電器に接続する前に、充電ポートを乾いた状態にしておくと、破壊のリスクを減らすことができます。
- このイヤホンは耐水性がありますが、防水ではありません。イヤホンを水の中に置かないでください。
- イヤホンは柔らかくて乾いた布で拭き、常に清潔を保ってください。
- 運動をした後、すぐに充電しないでください。念のため、充電ポート内に汗などの水分が残っていると、充電中に回路が焼け故障の原因となります。
- 長期間保管した後は、再び使用する前にイヤホンを充電してください。

ノート:

デザインや仕様は予告なく変更されることがあります。
最新の製品情報については公式サイトをご覧ください。
elibomservice@outlook.com

FCC警告


このデバイスはFCCルールのセクション15に準拠しています。
操作は次の2つの条件を満たす必要があります。
(1) 当該機器は有害な干渉を起こさず、かつ
(2) デバイスは、受信された干渉を受け入れる必要があります。望ましくない動作の干渉を引き起こす可能性があります。
当事者が明示的に承認していない変更または変更コンプライアンスを担当すると、ユーザーが操作できなくなる可能性がありますデバイス

注:このデバイスはテストされ、適合していますFCCセクション15によるBクラスデジタルデバイスの制限規則。これらの制限は、合理的な保護を目的としています住宅施設における有害な妨害を防止する。これデバイス無線周波数の生成、使用、放射に従っていない場合コマンド、無線に有害な干渉を与える可能性がある通信する。しかしながら、干渉を保証することはできない特定のインストールでは発生しません。デバイスが無線またはテレビ受信に有害な干渉を与えるデバイスを開いて開くことで判断できます。
ユーザーは1つ以上の是正を試みることを奨励する次の手順に従います。

- 受信アンテナの向きを変更するか、位置を変更します。
 - デバイスと受信機の間隔を増やします。
 - デバイスを別のデバイスに接続する受信機は受信機に接続されている。
 - ディーラーや経験豊富なラジオ/テレビ技術者に相談してください。
- この装置は一般的な無線周波数曝露に適合していると評価されている要件
この装置は携帯型暴露条件で使用できる制限なく
FCC番号: 2A72B-BC02

同梱物

製品の一部が損傷または欠落している場合は、使用しないでください。
Elibomの正規販売店またはElibomカスタマーサービスに連絡してください。



*販売地によってパッケージが異なります。

⚠ 警告: 3歳未満の子供や口の中で食べられないものになりがちな個人向けではない小さな部品。

ELIBOM