

Ostinato M7 Microphone

5

Congratulations!
**You've just taken your party
game up a notch.**

Whether you're celebrating with a few friends or with the whole gang - in the comfort of your home or in a big event space - your parties will be peppier with this beautifully - designed, deceptively-compact Ostinato M7 - Karaoke Machine from Masingo.

Choose from Bluetooth, AUX, USB, MicroSD or FM mode to fill the room with melody. Colorful LED lights set the stage as you belt out your best into one of our top-quality karaoke microphones. Sing out some show tunes with grandma, blast out some big hits with your pals, or serenade your sweetheart. To (literally) top it off, a built-in disco ball adds magic to every musical occasion, whether romantic dance night or family fun. No matter what your skill level, this box of magic is sure to delight vocalists from age 5 to 125.

Want to take your show on the road? The long-lasting batteries and built-in carry-strap mean easy transport to your next barbeque or block party. Need to send out some announcements during your big bash? No problem! This portable, multi-functional machine doubles as a punchy PA system for volume-adjustable, crystal-clear announcements.

When all is said and sung, just sling the microphones into their built-in carry holster and turn off the machine. In no time at all, you'll be ready for an encore.

Sing on!

[Welcome]



Microphones

How to set up the microphones

Unscrew the bottom half of the microphone (note: not at the colored cap, but at the seam halfway up the handle). Install two AA batteries. Replace the bottom of the microphone and rotate it gently until secure.

How to turn the microphones on

Turn the microphones on by sliding the power buttons upward into the "ON" position. They will automatically pair with the machine. Once paired, the mic indicator light on the machine will be lit.

How to customize your microphone vocal mix

To adjust the volume of your singing over the music, turn the **Mic+** knob to the left or the right until desired volume balance is achieved. Turn the **-Echo+** knob to the right or left to experiment with reverb effects.

How to Store the Microphones

To store the microphones for easy transport, slide each mic into a leather loop at the sides, making sure the end you sing into is facing up. You may also unsnap the buttons, wrap a leather loop around each mic, then secure them by snapping the buttons again.

To connect your own wired microphones

The Ostinato M7 is also compatible with wired microphones. Simply plug one or two 6.5mm microphones into the corresponding ports on the back of the machine. You may connect both wired and wireless microphones simultaneously.



Maintenance

How to Clean

Turn the machine and microphones off. Unplug the machine from any connections to AUX, RCA, or power.

Gently wipe the outside of the machine using a clean, dry cloth. Keep all vents, buttons, and openings free of lint and dirt. Do not immerse the machine in water and do not use any harsh cleaners.

How to Store

Charge the machine and microphones so that they are ready for next use. Dock the wireless microphones in their holsters. Make sure that the machine is clean and dry.

Bind the power cord, AUX cable, and RCA cable individually and gently with electrician-approved fasteners. (Note: Do not wrap or fold against the natural bend of the cords or cable). Do not wrap the cord around the machine. Store the machine in a cool, dry place away from damaging elements.

For best results, clean and store the machine after each use.

Operation Frequency: 565-604MHz

Number of Channel: 3 Channels

Equipment System: Digital systems



FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

ISED Statement

- English: This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).

- French: Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

l'appareil numérique du ciem conforme canadien peut - 3 (b) / nmb - 3 (b).

This device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 2.5 du cnr - 102 et conformité avec rss 102 de l'exposition aux rf, les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs rf et la conformité.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 0cm between the radiator & your body.

Cet équipement est conforme Canada limites d'exposition aux radiations dans un environnement non contrôlé.

Cet équipement doit être installé et utilisé avec une distance minimale de 0 cm entre le radiateur et votre corps.