



PitPat Smart bracelet User's manual W00



Version: W00

1.Assemble and wear the bracelet

- (1) Take out the bracelet body and wristband;
- (2) Put the bracelet body into the wristband;
- (3) Put the wristband on your wrist.



Note: it is best to wear the bracelet behind the styloid process of ulna. Adjust the size of the bracelet to suit the wrist according to the adjusting hole. The sensor should be close to the skin to avoid movement.

2. Install app on mobile phone

Search for “pitpat” in the app store or scan the following QR code to download and install the app.



System requirements: ios13 or above;Android 6.0 or above.

3. Bind the bracelet to the treadmill

- (1) Bracelet boot

Long press the bracelet button, and the bracelet vibrates once to display the pitpat interface;

- (2)Turn on the treadmill, put the screen of the bracelet on the NFC logo of the treadmill, the treadmill make a sound of “bleep”, and the bracelet is connected with the treadmill.

Once the bracelet is successfully bound, it will recording your running information immediately.

Note:The initial connection between the bracelet and the treadmill requires touching the NFC logo of the treadmill. After the first connection, the next time you start the bracelet, it will automatically connect to the treadmill.

4. Start using

Bracelet startup: in the shutdown state, long press the button, and the bracelet will vibrate then the pitpat interface will be displayed, and the bracelet will be powered on;

Bracelet shutdown: long press the bracelet button, the bracelet will vibrate then the bye interface will be displayed, and the bracelet will be shutdown.


(1)standby mode:



When the bracelet is not connected to the treadmill or the treadmill is in standby mode (the treadmill stops moving), the bracelet automatically enters the standby mode.

The bracelet displays the power of the bracelet in standby mode.

(2)Motion mode: .




When the treadmill enters the running state, the bracelet will automatically enter the sports mode,

- ① At this time, the main interface of the bracelet displays the heart rate, steps and movement information. (in the exercise mode, the bracelet will automatically detect the heart rate, and the heart rate detection light flashes.)
- ② The bracelet displays the power and Bluetooth connection status.
- ③ Touch the display screen and the screen will be lit when the hand is in the state of resting screen.
- ④ For other Bracelet click, double click and three click operations, please refer to the instructions of pitpat app

5. Bracelet charging.

Note:Make sure the bracelet is in normal power for the first time use. If it cannot be started normally in low power, please connect the charger to charge the equipment, and the bracelet will start automatically.



Insert the charging head of the bracelet body into the female head of the power cord

6. Product parameters

Product model: W00

Battery type: lithium polymer battery

Battery capacity: 90mah

Connection method: Bluetooth 5.0

Wristband material: Rubber

Equipment requirements: system requirements ios13 or Android 6.0 above

Screen size: 0.96 inch

WARNING

- (1) Please do not wear bracelets when bathing and swimming.
- (2) Do not expose the bracelet to high moisture, high temperature or low temperature for a long time.

FCC Regulations:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

Changes or modifications not expressly approved by the manufacturer could void the user’s authority to operate the equipment.

FCC RF Radiation Exposure Statement


This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. To comply with FCC RF Exposure compliance requirements, this grant is applicable to only Mobile Configurations. Transmitter Power - 2DBM, SAR Exemption Test.

Manual de usuario W00



Versión: W00

1. Ensamblar y llevar brazaletes
(1)Retire el cuerpo del brazalete y la pulsera;
(2)Coloque el cuerpo del brazalete en la pulsera;
(3)Pon una pulsera en la muñeca.



Nota: es mejor usar un brazalete detrás del proceso estiloide del cúbito. Ajuste el tamaño del brazalete para adaptarse a la muñeca de acuerdo con el agujero de ajuste. Los sensores deben estar cerca de la piel para evitar el movimiento.

2. Instale la aplicación en su teléfono móvil
Busque "pitpat" en la tienda de aplicaciones, o escanee el siguiente código QR para descargar e instalar la aplicación.



Requisitos del sistema: los 13 o más; Android 6.0 o posterior.


3. Atar el brazalete a la cinta de correr
(1)Botas de pulsera
Pulse el botón del brazalete durante mucho tiempo, el brazalete vibra una vez, mostrando la interfaz pitpat;
(2)Encienda la cinta de correr, coloque la pantalla del brazalete en el logo NFC de la cinta de correr, la cinta de correr emite el sonido "bip", la pulsera está conectada a la cinta de correr.
Una vez que el brazalete se une con éxito, registra su información de ejecución inmediatamente.

Nota: la conexión inicial entre el brazalete y la cinta de correr requiere tocar el logotipo NFC de la cinta de correr. Después de la primera conexión, la próxima vez que inicie el brazalete, se conectará automáticamente a la cinta de correr.

4. Empezar a usar
Pulsera activada: en el Estado apagado, presione el botón, pulsera vibrante, mostrar la interfaz pitpat, pulsera energizada;
Pulsera cerrada: Presione el botón pulsera larga, pulsera vibrará, y luego mostrar la interfaz de adiós, pulsera se cerrará.
(1)Modo de espera:




Cuando el brazalete no está conectado a la cinta de correr o la cinta de correr está en modo de espera (la cinta de correr deja de moverse), el brazalete entra automáticamente en modo de espera.El brazalete muestra la Potencia del brazalete en modo de espera.
(2)Modo de movimiento: .



Cuando la cinta de correr entra en funcionamiento, el brazalete entra automáticamente en el modo de movimiento.
① En este punto, la interfaz principal del brazalete muestra la frecuencia cardíaca, el paso y la información de movimiento. (en modo de ejercicio, el brazalete detecta automáticamente la frecuencia cardíaca y la luz parpadea.)
② El brazalete muestra el Estado de la energía y la conexión Bluetooth.
③ Toque la pantalla y la pantalla se encenderá cuando la mano esté en el estado estacionario de la pantalla.
④ Consulte las instrucciones de la aplicación pitpat para otros clics de pulsera, doble clic y tres clics

5. Carga del brazalete
Nota: asegúrese de que el brazalete está a la Potencia normal cuando se utiliza por primera vez. Si no se puede iniciar normalmente a baja potencia, conecte el cargador para cargar el dispositivo y el brazalete se activará automáticamente.



Inserte la cabeza de carga del cuerpo del brazalete en la cabeza de la madre del cable de alimentación

6. Parámetros del producto
Modelo de producto: W00
Tipo de batería: batería de polímero de litio
Capacidad de la batería: 90 Mah
Modo de conexión: Bluetooth 5.0
Material de la pulsera: caucho
Requisitos del equipo: requisitos del sistema iOS 13 o Android 6.0 o superior
Tamaño de la pantalla: 0,96 pulgadas

Advertencia
(1)Por favor, no use brazaletes durante el baño y la natación.
(2)No exponga el brazalete a alta humedad, alta temperatura o baja temperatura durante mucho tiempo.

Reglamento FCC:

El equipo cumple con la parte 15 de las normas FCC. El funcionamiento está limitado por dos condiciones: 1) el dispositivo puede no causar interferencias perjudiciales, y 2) el dispositivo debe aceptar cualquier interferencia recibida, incluidas las que puedan dar lugar a operaciones indeseables.
De conformidad con la parte 15 de las normas FCC, el dispositivo ha sido probado para cumplir los límites de los dispositivos digitales de clase B. Estas restricciones tienen por objeto proporcionar una protección razonable contra las perturbaciones perjudiciales en la instalación de viviendas. El equipo genera, utiliza y irradia energía de radiofrecuencia que, si no se instala y utiliza de conformidad con las instrucciones, puede causar interferencias perjudiciales en las comunicaciones por radio. Sin embargo, no hay garantía de que no haya interferencia en una instalación en particular. Si el dispositivo causa una interferencia perjudicial en la recepción de radio o televisión, que puede determinarse apagando y encendiendo el dispositivo, se alienta al usuario a que trate de corregir la interferencia mediante una o más de las siguientes medidas:
Reorientar o reubicar la antena receptora.
Aumentar la distancia entre el dispositivo y el receptor.
Conecte el dispositivo a un enchufe en un circuito diferente al circuito conectado al receptor.
Consulte a su distribuidor o técnico de radio / televisión experimentado para obtener ayuda.

Los cambios o modificaciones no aprobados explícitamente por el fabricante pueden invalidar los permisos del usuario para operar el dispositivo.

Declaración de exposición a la radiación de radiofrecuencia FCC

Este equipo cumple con los límites de exposición a la radiación de la FCC establecidos para un entorno no controlado. Para cumplir con los requisitos de cumplimiento de exposición a radiofrecuencia de la FCC, esta concesión se aplica solo a configuraciones móviles. Potencia del transmisor: 2DBM, prueba de exención de SAR.