

READ ALL ENCLOSED INSTRUCTIONS BEFORE USING THIS HELMET

- The helmet must be kept away from any heat source. Do not leave it inside the car or any other place directly or indirectly exposed to solar radiation. High temperatures lead to the deterioration of the helmet and consequent loss of its characteristics (namely the absorption of energy). The maximum temperature at which the helmet may be exposed to is 112 °F (50 °C)
- This helmet is not intended for use with any motorized vehicle or while performing any stunts.
- Support the weight of the helmet. Children under the age of one should be checked by a pediatrician before using the this helmet.
- This helmet should not be worn by anyone who cannot comfortably gets trapped whilst wearing the helmet.
- This helmet should not be used by children while climbing or doing other activities where there is a risk of hanging or strangulation if the child shows obvious signs of wear.
- A helmet has a limited lifespan in use and should be replaced when it damaged, the helmet should be destroyed or replaced.
- Do not expose your helmet to extreme temperatures. Do not leave your helmet in a hot vehicle for extended periods of time. If use abrasives or strong cleaning solvents.
- Use only mild soap and a soft cloth when cleaning the shell. Do not use abrasives or strong cleaning solvents.
- No attachments should be made to the helmet except those recommended by the helmet manufacturer.
- A helmet does not provide protection to any part of the body that it does not cover directly.

PLEASE READ WARNINGS AND SAFETY PRECAUTIONS BEFORE USING

CHARGING YOUR HELMET

- Open the charging plug on the LED. The charger is located on the back of the LED.
- Charge by using the USB to Micro USB cord (included) with a computer or AC adapter with USB jack (not included).



The power indicator shows steady red when charging. After the power supply is fully charged, the indicator is steady green. NOTE: Please allow approximately 3 hours for full charge. Battery will last up to 6 hours when connected wirelessly.

IMPORTANT: DO NOT OVERCHARGE THE BATTERY FOR LONG PERIODS, AS IT COULD DAMAGE THE BATTERY.

Complies with AU/NZ 2063:2008.
Australian Agent:
The Brand Exchange
401 Riverside Road, Hawthorn East VIC 3123

BLUETOOTH® SMART HELMET

OWNER'S MANUAL

READ BEFORE RIDING

SUITABLE FOR BIKE RIDING, SKATING, SCOOTERS AND SKATEBOARDING

The helmet you have just purchased provides protection, whether on or off the road. To insure proper use of this helmet, familiarize yourself with its features, fit and care by carefully reading through this manual before wearing your new helmet.

THE PROPER FIT

STEP 1: The helmet fits correctly when the pads and the adjustment dial (Diagram A) hold the helmet firmly but comfortably in place. For a correct adjustment, turn the adjustment dial clock-wise (to the right), until the helmet fits firmly and comfortably, to reduce the adjustment, turn the adjustment dial counterclockwise (to the left). All fitting adjustments must be made with the helmet in the proper position. Failure to do so will result in a poor fit. A poor fit allows the helmet to move out of position or to come off in an accident. For proper position, please refer to Diagram B and C.

DIAGRAM A



DIAGRAM B POSITIONING



DIAGRAM C PROPER STRAP POSITION




DIAGRAM D BUCKLE RELEASE





DIAGRAM E "O" RING



STEP 2: Always wear a helmet low in the front to protect the forehead as in the CORRECT image below in Diagram B.

STEP 3: The front and rear straps should join at a point slightly below and in front of the ears. See Diagram C. To adjust the position of the straps hold one end of the buckle in one hand and slide the slide adjuster up or down as necessary with the other hand correctly positioned. To adjust the front or rear strap individually, hold the strap to be adjusted and slide the slide adjuster in the appropriate direction.

STEP 4: Always wear the helmet with the chin strap buckle fastened and the strap pulled tight. Make sure the strap is well back against the throat, NOT on the point of the chin. Straps worn at the point of the chin increase the chance of the helmet coming off in an accident. See Diagram D. Fasten buckle by clipping ends together. Release buckle by squeezing sides. Diagram B shows the CORRECT placement of the chin strap.

Make sure the loose end of the strap passes through the Rubber "O" ring, if it does not, the strap may slide loose and the helmet can come off accidentally. See Diagram E.

STEP 5: Before using the helmet, make sure it fits correctly, the straps are correctly adjusted and the chin strap is tight enough. Put the helmet on in the correct position. Fasten the chin strap and pull it tight.

CHECK THE FIT: Grab the helmet with both hands and twist it to the left and to the right. If the helmet fits right, the skin on the forehead will move as the helmet moves. If it does not, the helmet is too loose. Return to STEP 1.

CHECK THE STRAPS: Grab the helmet with both hands and try to remove it by rolling the helmet forward and backwards as far as you can. Make a serious effort. If you can roll it off the head completely in either direction, roll it forward so far it blocks vision or backwards far enough to expose the forehead, it does not fit right. Repeat STEPS 3 and 4 until helmet movement is minimal.

WARNING: If you cannot adjust your helmet to fit as required by STEP 5. DO NOT USE THIS HELMET. Replace it with a different size.

STEP 6: Once you are satisfied that the helmet fits correctly and that all straps are properly adjusted and tightened, take a short ride. Pay attention to overall comfort and helmet stability while riding. Make any minor adjustments to the fit pads and straps to improve the comfort stability.

CLEANING YOUR HELMET

Use only mild soap and water to clean your helmet, straps and pads. DO NOT use chemicals. Do not use solvents, paints or hydrocarbons.

INSTRUCTIONS

The Bluetooth helmet has only one button, the power button.

- To turn the Bluetooth helmet ON:
Press the power button for 2 seconds.
- To turn the Bluetooth helmet OFF:
Press the power button for 2 seconds.



PAIRING

- Make sure your device has Bluetooth® capability.
- Turn the Bluetooth smart helmet on.
- Watch for that the beads at both ends of the LED light will light up, indicating that it's in Standby mode.
- Follow the instructions of your device to pair the unit.
- Pair your device by selecting aidy Bluetooth® Smart Helmet from the Bluetooth® listing on your device or by selecting YES. When successfully connected, you will hear a beep and the device will display bluetooth connection successfully.
- Press play on your device and use controls on it to adjust desired volume.

Once you have successfully paired your device, you may not need to repeat the pairing steps. When pairing with a computer, please consult your computer manufacturer for Bluetooth® pairing instructions and/or the latest Bluetooth® drivers. Keep all non-water-resistant devices (phones, mp3 players, etc.) in a dry place where they will not come in contact with water. A pairing code is not required.

NOTE: Volume is controlled only by the device connected to your Bluetooth® Smart Helmet.

VOICE RECOGNITION

Voice commands are available when the helmet is powered on, but only in the following terms.

Recognizable imperative sentence	Helmet response
Hello, Aidy	Can i help you
the left light	the left light has turn on
the right light	the right light has turn on
Turn off the turn light	the light has turn off
Turn on the warning light	warning light has turn on
Turn off the warning light	warning light has turn off
Turn on the double flashing light	double flashing has light on
Turn off the double flashing light	double flashing has light off
Answer the phone	Phone has been answered
Hang up	Phone has been hang up
increase volume	Volume has increased
Reduce the volume	Volume has reduced
turn off the helmet	Ready to turn off the helmet light
Play music	Play music
Pause music	Pause music
Continue music	Continue music
Last song	Last song
Next song	Next song
	go to stand by mode

The voice recognition module needs to hear "Hello AIDY" wake up every time before it can recognize other instructions.

If there is no new command ten seconds after waking up or you hear "back down", you will automatically return to the s standby mode , and you need to wake up again.

BACK COVER WHEN FOLDED

FRONT COVER WHEN FOLDED

SIDE A

SIDE B

DASHED LINES ARE FOLDS - SHEET IS FOLDED TWICE INTO QUARTERS

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.