

Scan translation pen

[Scan translate · Voice translation]

Product Manual



The schematic diagram is for reference only. Please refer to the actual product.
Warm prompt: This manual is provided with the product when it leaves the factory. If the product has software updates and upgrades later, please follow the latest software version!

Product introduction

This is a scanning translation pen, which can realize text scanning translation, voice translation and other functions. Built-in text collection, electronic dictionary, recording and other practical functions. This product is suitable for cross-border travel, business docking, learning foreign languages and other scenarios.

For more detailed product introduction, please continue to read this manual

Packing list

Product name	Quantity
Scan translation pen	1 PCS
Charging Cable	1 PCS
Product Manual	1 PCS

Product parameter

Product name	Scan translation pen
Product model	See outer package for details
Charging power	5V-1000mAh
Power supply mode	Li-ion Batter
Charging port	USB type-c
Scannable font size	No. 6 font-No. 2 font
Recognizable font	Multiple fonts
Working TEMP	0-40°C

Scanning considerations


Place the scanning window in front of the text and make the font faces the center line of the window. Press the scanning pen lightly, after the scanning indicator light is on, slide the scanning pen along the text direction at a constant speed from left to right.

Note: This product supports left-handed/right-handed pen holding, you can switch the pen holding direction in the settings.

Try scanning translation

The 1st step: hold the pen
Please refer to picture 1 for the pen holding posture

(Picture 1)



The 2nd step: try scanning
(Picture 2 / Picture 3)



(Picture 2)



(Picture 3)

The 3rd step: scan a word / sentence

(Picture 4 / Picture 5)



(Picture 4)

1: Aim at the blank space in front of the first word and start scanning



(Picture 5)

2: After scanning the word/sentence, lift up the pen.

Please try scanning below, appendix test scanning text

Please note that in the scanning and translation interface, the language on the left is used for scanning, and the language on the right is the language you want to translate.

你今天真漂亮!

这件衣服哪里买的?

今天天气真不错。

你今天戴口罩了吗?

我有一个想法。

今天我们一起去看电影。

You are so pretty today!

Where did you buy this dress?

It's a nice day today.

Are you wearing a mask today?

I have an idea.

Today we goto the cinema together.

Power on/off

Power-on method:

Press and hold the power button for 3 seconds in the power-off state to start the machine.

Shutdown method:


press and hold the power button for 3 seconds in the power-on state, a shutdown prompt appears on the screen, click and touch it to shut down.

For save power,the machine will automatically shuts down if no operation in 30 minutes.(the setting menu can adjust the automatic shutdown time)

Touch screen operation:

This product adopts a touch-sensitive color screen, you can touch the screen to slide the interface and click to select.

Main Functions



Scan translation: Use this feature to scan and translate

Voice translation: Use this feature for voice translation

Smart record: Use this function for voice recording

Excerpt: Use this function to save the scanned words / sentences

For more functions, please use this product to experience



Scan translation

No need to connect to the internet
Support 11 languages translation

- 1: Supports 11 languages of words / sentences translated single-line or multi-line scanning. For multi-line scanning translation, please switch on multiple lines.
- 2: In the scanning interface, select the language of the text to be scanned on the left side of the arrow mark, and select the native language you need to translate on the right side of the arrow mark.
- 3: After scanning, the scanned language will be displayed and read aloud at the top of the screen, and the native language you set will be translated and displayed at the bottom of the screen.
- 4: You can play the original text or the translated text, click on a word in the original text or the translated text to view the detailed content: paraphrase, phonetic transcription, example sentences, short sentences, synonyms, antonyms, grammar, etc. You can add it to your favorites for easy review later, and you can also perform pronunciation evaluation
- 5: Supports offline scan translation in 11 languages:

Simplified Chinese	简体中文
Traditional Chinese	繁体中文/粤语
English United States	American English
German	Deutsche
Spanish	Español
French	français
Italian	italiano
Japanese	日本語
Korean	한국어
Portuguese	português
Russian	русский



Voice translation

IFlytek Translation System Online Support
100+languages voice translation

- 1: Support 100+ languages online voice translation.
- 2: Before using this function, please connect to WIFI first, click the WIFI icon in the settings, choose to search for your WIFI account, fill in the password, and click confirm.
- 3: Click on the screen voice translation icon to enter the interface, select language A on the left at the top of the interface, and select language B on the right.
- 4: Press and hold the volume - button, corresponding to language A, please release the button after speaking, the screen will display language A and play language B.
- 5: Press and hold the volume + button, corresponding to language B, please release the button after speaking, the screen will display language B and play language A.

****100+ languages supported****

Please read the language list on the back of the manual



Smart record

Conference recording
Double wheat noise reduction

- 1: Dual microphone noise reduction processing, record your recording more clearly
- 2: Select the smart recording icon on the screen, click to enter the interface, click New Recording in the upper right corner, and then click the recording icon button to start recording. After the recording is over, select Confirm to save.
- 3: You can play previous recordings on this interface, or delete them.



Excerpt

Scan and save useful vocabulary
Read and export it at any time

- 1: You can use this function to scan and save useful vocabulary sentences, read it and export it at any time.
- 2: Select the excerpt icon on the screen, click to enter the interface, and then scan the text vocabulary. After the scan, the vocabulary will be displayed on the screen. You can click save and upload it to your independent storage space.
- 3: If you are using this feature for the first time, please click Register a storage space in the upper right corner of this interface, and then you can upload the scanned vocabulary to this storage space.
- 4: After the registration is complete, please visit the website displayed on this interface. You can access this website from your computer. In it you will see the vocabulary you uploaded. You can download and import it, or print it.

System settings

- 1 WIFI: Configure the WIFI network of the device. Experience will be better after the device connected to WIFI.
- 2 Bluetooth: Connect audio devices such as Bluetooth headsets, Bluetooth speakers, etc., to achieve a better listening effect.
- 3 Volume adjustment: adjust the volume level.
- 4 Brightness adjustment: adjust the screen brightness intensity.
- 5 Date and time: automatic synchronization.
- 6 Sleep time: You can choose the time to automatically rest the screen.
- 7 Shutdown time: You can choose the automatic shutdown time.
- 8 System update: check if there is a newer software version and update.
- 9 About this machine: check the current device model, SN number, software version and other information
- 10 Storage space: you can view the system space, used/remaining space.
- 11 Hold the pen direction: You can choose the left/right hand to hold the pen according to your habit.

Charging and Battery Caution

- 1: Before charging, make sure that the charging port is clean and free of foreign objects.
- 2: When connecting the charging cable to the charging port, make sure that the connection of the charging cable is correct. Do not connect the charging cable forcibly.
- 3: This product is not equipped with a power adapter, consumers should use a power adapter that meets the standard requirements for charging.
- 4: If the battery has abnormalities such as high temperature, discoloration, drumming, deformation, or liquid leakage during charging, use or storage, please stop using it to avoid safety problems.
- 5: When charging, please do not put it together with flammable products to avoid potential safety hazards.
- 6: It is strictly forbidden to disassemble, squeeze, heat or burn the built-in lithium battery of this product. It is strictly forbidden to use sharp objects, screwdrivers and other objects to pierce the battery. The above operations may cause the battery to catch fire or burn.
- 7: Children under 10 should use this product with their parents.

Product Declaration

- 1: Please read the contents of this manual carefully to ensure that you can use this product correctly and safely.
- 2: Please use the data cable that comes with the package to charge the product. If you use an incompatible data cable, it may cause damage to the product or even endanger the safety of you and your family. The company does not assume any responsibility for this.
- 3: Some functions of this product can only be used normally when the network is in good condition. The company does not assume any responsibility for any loss caused by service interruption due to network failure or other force majeure reasons.
- 4: Do not disassemble this product and its accessories without permission. The company will not take any responsibility for any damage caused thereby.
- 5: The company has the right to make adjustments and modifications to the product content during product update iterations. This manual is for reference only.

Maintenance

- 1: This product does not have a waterproof design. Please do not use it under splashing water or other environments that may cause water to enter the product.
- 2: Please use a soft and dry towel to clean this product. Do not use other detergent liquids.
- 3: If the product freezes or has delayed response after working for a long time, you can try to restart the device.
- 4: Pay attention to whether there is a newer version of the system software. You can try to update to the latest software version to bring a better user experience.
- 5: If you accidentally delete a certain file in the system and cause the system to crash and become unusable, you can try to restore the factory settings in the settings.

Voice translation

100+ languages appendix

Arabic (Algeria)
Arabic (United Arab Emirates)
Arabic (Oman)
Arabic (Egypt)
Arabic (Palestinian National Authority)
Arabic (Bahrain), modern standard
Arabic (Qatar)
Arabic (Kuwait)
Arabic (Lebanon)
Arabic (Libya)
Arabic (Morocco)
Arabic (Saudi Arabia)
Arabic (Tunisia)
Arabic (Syria)
Arabic (Yemen)
Arabic (Iraq)
Arabic (Israel)
Arabic (Jordan)
Amharic (Ethiopia)
Irish (Ireland)
Estonian (Estonia)
Bulgarian (Bulgaria)
Icelandic (Iceland)
Polish (Poland)
Persian (Iran)
Danish (Denmark)
German (Austria)
German
German (Switzerland)
Russian
French (Belgium)
French (France)
French (Canada)
French (Switzerland)
Filipino (Philippines)
Finnish (Finland)
Khmer (Cambodia)
Georgian
Gujarati (India)
Korean (South Korea)
Dutch (Belgium)
Galician (Spain)
Dutch (Netherlands)
Catalan (Spain)
Czech
Kannada (India)
Croatian (Croatia)
Latvian (Latvia)
Lao (Lao)
Lithuanian (Lithuania)
Romanian (Romania)
Maltese (Malta)
Maladi (India)
Malayalam (India)
Malay (Malaysia)
Macedonian (Northern Macedonia)
Bengali
Bengali (India)
Burmese (Myanmar)
Afrikaans (South Africa)
Nepali
Norwegian (Bokmal, Norway)
Portuguese (Brazil)
Portuguese (Portugal)

Chinese (Mandarin, Simplified)
Chinese (Taiwan Mandarin)
Chinese (Cantonese, Traditional)
Zulu (South Africa)
Vietnamese (Vietnam)
Javanese (Indonesia)
Japanese (Japan)
Swedish (Sweden)
Serbian (Serbia)
Sinhalese (Sri Lanka)
Slovak
Slovenian (Slovenia)
Swahili (Kenya)
Swahili (Tanzania)
Telugu (India)
Tamil (Malaysia)
Tamil (Singapore)
Tamil (India)
Thai (Thailand)
Turkish (Türkiye)
Urdu
Urdu (India)
Ukrainian
Uzbek (Uzbekistan)
Spain (Nicaragua)
Spanish (Argentina)
Spanish (Paraguay)
Spanish (Panama)
Spanish (Puerto Rico)
Spanish (Bolivia)
Spanish (Equatorial Guinea)
Spanish (Dominican Republic)
Spanish (Ecuador)
Spanish (Colombia)
Spanish (Costa Rica)
Spanish (Cuba)
Spanish (Honduras)
Spanish (USA)
Spanish (Peru)
Spanish (Mexico)
Spanish (El Salvador)
Spanish (Guatemala)
Spanish (Venezuela)
Spanish (Uruguay)
Spanish (Spain)
Spanish (Chile)
Hebrew (Israel)
Greek
Hungarian (Hungary)
Sunda (Indonesia)
Armenian
Italian (Italy)
Hindi (India)
Indonesian (Indonesia)
English (Ireland)
English (Australia)
English (Philippines)
English (Canada)
English (Ghana)
English (Kenya)
English (USA)
English (South Africa)
English (Nigeria)
English (Tanzania)
English (Hong Kong)
English (Singapore)
English (New Zealand)
English (India)
English (UK)

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.