

规格:135*62mm



HD Smart Bluetooth Glasses


Firstly, we would like to express our gratitude for choosing and using our HD Smart Bluetooth Glasses! To help you quickly become proficient in operating this device, we have included a comprehensive user manual. Before you begin using your product, please take the time to carefully read through this manual to ensure that you can make the most of your product.

Warning/caution

- ◆ Do not use Bluetooth smart glasses at high volume for an extended period.
- To prevent hearing damage, please use Bluetooth smart glasses at a comfortable and moderate volume.
- Start by lowering the device volume before putting on your Bluetooth smart glasses or placing them near your ears.
- ◆ Then gradually increase the volume until you reach a comfortable listening level.
- ◆ Please exercise caution and adhere to laws regarding mobile phone use while driving.
- ◆ If you are using Bluetooth glasses for activities that require concentration, such as cycling or walking on or near roads, construction sites, or railways, take care of your safety and that of others. You should remove your Bluetooth smart glasses or adjust the volume to ensure you can hear surrounding sounds, including alarms and warning signals.
- ◆ If your Bluetooth smart glasses emit abnormal noise, do not use them. In such cases, please turn off your Bluetooth smart glasses and contact customer service.
- ◆ Do not submerge smart Bluetooth glasses in water or expose them to a humid environment for an extended period.
- ◆ Do not wear them during water sports such as swimming, wakeboarding, and surfing.
- ◆ If you feel heat or cannot hear any sound, remove your Bluetooth smart glasses immediately.
- ⚠ This product contains small parts that may pose a choking hazard. Not suitable for children under 3 years.
- ◆ This product contains magnetic materials. Consult your doctor regarding its potential impact on implantable medical devices.
- ◆ To reduce the risk of fire or electric shock, do not expose this product to water or moisture.
- ◆ This product must not be exposed to splashing or spraying with liquids, and objects containing liquids (such as vases, etc.) must not be placed on or near this product.
- ◆ Please place this product away from open flames or heat sources.
- ◆ Do not place open flames (such as lit candles) on or near this product.
- ◆ Unauthorized modifications to this product are prohibited.
- ◆ Do not overheat products containing batteries (for example, please avoid direct sunlight and keep away from sources of ignition, etc).
- ◆ After each use, clean both sides and parts of the lenses of the glasses with the included cloth bag or dry cloth.

A)Product pictures and basic parameters:

Red/Green/Blue three colors



- B) Switch between Chinese and English languages: After powering on the glasses by pressing the buttons on both temple arms, and without connecting to a mobile phone, quickly press the right-side switch button three times to prompt the user to switch between Chinese and English languages.

C)Product function indicator code:

Flashing method	
Power on	First turn on the blue light for 2 seconds, then flash the red and blue lights alternately for 0.5 seconds
Shut down	The red light is on for 2 seconds and then off
Waiting to connect	The red and blue lights on the main unit flash alternately for 0.5 seconds, and the secondary side turns off
Connection successful	The main and secondary terminals turn off the lights
plays	The main and secondary terminals turn off the lights
Suspend	The main and secondary terminals turn off the lights
There is an incoming call	The blue light on the main and secondary terminals blinks 3 seconds per time
call	The blue light on the main and secondary terminals blinks 3 seconds per time
Low battery	Red light flashes 3 sec/time
Charge	The red light is always on
Fully charged	Turn off the lights

D) Bluetooth technical specifications:

- (1)Bluetooth V5.4 version, high-fidelity two-channel stereo sound quality

(2) frequency 2.4 GHz

(3) Maximum transmission range 10M

(4) 7 hours of continuous talk time

(5) Audio decoding rate 15 Bit

(6) Signal-to-noise ratio > 60 dB

(7) 10 days of normal standby time

(8) Operating temperature -10 to 55 degrees

(9) Charging current 60mA

(10) 3.4 V low power, 3.2 V shutdown
- (1) Product name: smart bluetooth glasses

(2) Product model: 1510

(3) Frame material: TR90

(4) Lens material: PC

(5) Frame color: black\ red\ blue\ green

(6) Product net weight: 40-44g

(7) Bluetooth protocol: V5.4

(8) Product size: 80*60*150mm

(9) Battery capacity: 95mAh

(10) Charging time: 2 hours

E) Notes and instructions for use of the produc

- 1) When placing the glasses, stack the temple arms in an overlapping manner, with the left arm inside and the right arm outside. Ensure that the lenses' front surface does not make contact with the tabletop to prevent scratching.
- 2) If the product gets contaminated with dust, sweat, grease, or other stains, please clean it first with clean water (for the lenses) or specialized eyeglass cleaner. Then, gently wipe it with a dedicated eyewear cloth to prevent lens abrasion.
- 3) Store the product in a cool, shaded, and dry place. It is recommended to keep it at a room temperature ranging from 0°C to 45°C.
- 4) Avoid leaving the product exposed to direct sunlight on the car's central console for extended periods.
- 5) Do not expose the product to environments with temperatures below -10°C or above 45°C for extended periods to prevent frame deformation caused by temperature fluctuations.
- 6) High-definition smart Bluetooth glasses are advanced technological products. Please store them properly when not in use.

F) Electrical control instructions:

- Mains**
- 1:Power On:To power on the device, press and hold the power button on both ends of the machine, which are in the off state, for 2 seconds. The blue light will stay on for 2 seconds, accompanied by the prompt "Power On." Afterward, the red and blue lights will flash alternately, indicating that the machine is now turned on.
 - 2:Power Off: In Bluetooth standby mode, press and hold the power button for 3 seconds. The red light will stay on for 2 seconds, accompanied by the prompt "Power Off." Then, the lights will go off, indicating that the machine has been powered off.
- G) Bluetooth Pairing:**
- 1:Topair via Bluetooth, ensure the machine is in the off state. Press and hold the left and right switch buttons for approximately 2 seconds. Bluetooth will automatically pair, and when only the red and blue indicator lights are flashing, with the indicator light on the other end turned off, it signifies that Bluetooth pairing is complete.
 - 2:Inpairing mode, initiate a device search on your Bluetooth-enabled phone. Once you find a device named "ZH10A," manually connect to it. Upon successful pairing, you will hear a voice prompt saying "connected," and the indicator light on the host side will turn off. At this point, the machine will automatically enter standby mode.
 - 3:Answer and End Calls
When an incoming call comes in, press the power button briefly to answer the call. During the call, press and hold the power button for about 2 seconds to end the call.
 - 4:Reject Calls
When a call comes in, press and hold the switch key for about 2 seconds to reject the call.
 - 5: Activate Phone Voice Functions (e.g., Siri, Google Voice, Huawei Voice Assistant)
Voice Assistant: In standby mode, double-tap to access the Siri, Google Voice, or Huawei voice assistant function.

L) Functions of Bluetooth Eyewear:

- (1) In a Bluetooth connection, when listening to MP3 music, if a call comes in, the MP3 playback will automatically pause. Press the ON button to answer the call. After the call is over, press the ON button once to resume MP3 playback;
- (2) High-tech lenses imported for this device can change color, effectively blocking ultraviolet rays and harmful blue light, providing maximum protection for your eyes;
- (3) To charge the device, simply plug the USB cable into a computer's USB port or a power adapter (it is recommended to turn off the device before charging);
- (4) During the charging process, a solid red light will indicate charging, and the light will go out after the battery is fully charged;
- (5) After the device is fully charged, promptly disconnect it from the charging cable to avoid any short circuits in the cable;
- (6) If the device is not used for an extended period, remember to charge it once every three months;
- (7) Do not wear Bluetooth glasses while they are charging;
- (8) Avoid exposure to strong electromagnetic waves, as they may cause product malfunctions.

M) Product packaging accessories list:

- (1) 1 pair of 1,510 smart audio Bluetooth glasses (2) 1 glasses cloth (3) 1 charging cable (4) 1 certificate of conformity
- (5) 1 instruction manual

Product warranty card

Warranty with this card
Please be careful about retention

User Information:

Name:_____ Date: _____ Zip Code:_____

Address:_____

Tel: _____ Product Model:_____

Product fault phenomenon: _____

Warranty instruction:

- (1) The warranty period for this product is 1 year. Damage caused by human actions or external conditions is not covered by the warranty;
- (2) If there are any quality issues with the product itself, please contact our company. Do not attempt to disassemble it on your own, as this will void the warranty;
- (3) When seeking warranty service, please have this warranty card and your purchase receipt ready and contact the seller.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.