

User manual
Human baby sensing light strip
Model: RMB912


You can use a switch or remote control to control the lighting effect



Short press on key: turn on the light -3000K-6000K-4500K - turn off the light (cycle)

Long press the power button: brightness+/brightness-

Remote control instructions



NO/OFF

Short press to increase brightness (8 gears),
long press to dimming infinitely



Short press to decrease brightness (8 gears),



Short press to adjust color temperature from
6000K to 3000K (8 gears), long press to
linearly adjust color temperature from 6000K
to 3000K



Short press to adjust color temperature from
3000K to 6000K (8 gears), long press to
linearly adjust color temperature from 3000K
to 6000K

notes

During use, if the switch can function normally but the remote control cannot function properly, a code matching operation needs to be performed.

If the light is disturbed by other remote controls or cannot be remotely controlled. Before executing code matching, please turn off the power before turning it on.

How to perform code matching operation: Within 5 seconds of turning on the power, press and hold the start button on the remote control for 3 seconds, and the light strip will flash 3 times, indicating that the code (remote control) matches.



FCC ID: 2A9H8-RMB912

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.