

Evaife	说明书	说明书尺寸：480mm*100mm	
印刷要求：100g以上铜版纸双面彩印；印刷颜色：多色 CMYK；			
		版号：1.2	日期：2021.12.7

Let's Set
Your UP For
Great Sleep

Evaife
www.evaife.com

How to use it?

Step 1: Plug in Evaife light

Connect the included power cable to the port on the device. Plug the opposite end into a power outlet. Always keep your device plugged in.

Step 2: Power on

Press the Power button to power on the device. The clock display will light up.

Step 3: Download the Evaife mobile app

Download the Evaife mobile app on your smartphone and create an account.

ANDROID APP ON Google play

Available on the App Store

Step 4: Complete setup

Follow the steps in the Evaife app to connect your device. Bluetooth must be enabled.

Note: Bluetooth is on by default. When the device is powered on, the Bluetooth indicator will display a blue light.

The Bluetooth indicator will display a blue light.

APP re-pairing: To reconnect or connect to a new Bluetooth device, press and hold the Bluetooth button for 5 seconds to reset the setting. And the Bluetooth indicator will flash three times.

Step 5: Light it up

To turn on the light and speaker, touch and hold the Touch Sensor for 3 seconds. The light can also be controlled using the mobile app

Light/speaker settings

Button Control

Volume Knob

Brightness Knob

Tap the sensor to cycle through the light colors

Sound Control

HAVING TROUBLE WITH EVAIFE?
WE CAN HELP!

Contact us at support@evaife.com
Our team of experts can help you resolve any issues.

APP Control

Steps to play music via Bluetooth:
1. Select "BT speaker mode" in the mobile app.
2. Ensure Bluetooth is enabled on your smartphone, and search and connect to the "Evaife speaker."
Now you can turn on your phone's music player to play music through the speaker.

Note: Select any white noise option in the mobile app to switch the white noise channel.

Create a sleep routine

Personalize a sleep routine to fit your child's bedtime schedule and let them know when it's time to get up and go to sleep.

Click the "Scene" icon to enter the scene list.

Then click the "+" icon to add a new scene.

Create your sleep routine.

Create shortcut mode

Note: The default Shortcut Mode is warm light without sound.

Click the "Scene" icon in the mobile app to enter the scene list.

Then click the Shortcut button to create a frequently used scene.

Press the Shortcut button to quickly turn on/off Shortcut Mode.

Step 6: Turn the light and speaker off

Touch and hold the Touch Sensor for 3 seconds or use the mobile app to turn off the light and speaker.

Care and Safety

Care Instructions

Unplug Evaife before cleaning. Clean the surface with a damp cloth, avoiding the power charging port.
CAUTION: Evaife may be damaged if the power charging port comes into contact with liquid.

For your safety and your child's safety

Always keep Evaife at least 1 foot (0.3 meters) away from children as the cord can pose a strangulation hazard. If the speaker is placed within 1 foot (0.3 meters) of a baby, a selected volume of ≤50dB is recommended. Do not use near or place in water.
For full instructions, visit: www.evaife.com/manuals

FCC ID 2AAV8EV001

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Statement
The distance between user and products should be no less than 20cm.

Note: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.