

User Manual


Bluetooth speaker

BTS83

GOLD FINGERS TECHNOLOGY CO., LTD

Instructions

Function Instruction



- (1) Function indicator
- (2) Power ON/OFF
- (3) Previous
- (4) VOL-
- (5) Play/Pause
- (6) VOL+
- (7) Next
- (8) Call/EQ
- (9) OUT 5V 1.5A
- (10) IN 5V 1A
- (11) LINE-IN
- (12) Battery Indicator
- (13) Rest

Voice function

1. "Power On"
2. "Power Off"
3. "Pairing"
4. "Paired"
5. "Battery Low"
6. "Line In"

operation Instructions

Thanks for choosing our Bluetooth Speaker, this device has built-in rechargeable battery, please make sure fully charge at the first time. There is voice alarm once a minute when battery low than 6V.

Power on: To press the button "⏻" for 2 second to open power on the device, the indicator will flash with blue LED light in 1 second, after 5 seconds later, the device LED light flashes in red and blue.

Power off: To press the button "⏻" for 2 seconds to power on, the indicator will flash with blue LED light in 1 second, after 5 seconds later, the device LED light flashes in red and blue.

Bluetooth mode: LED light flashes quickly in red and blue alternately, after paired successfully with your device, press "⏮" to play/pause, press "⏮" for previous, press "⏭" for next, press "⏮" for Volume-, press "⏭" for Volume+.

Incoming calls: press "📞" to answer call by Bluetooth speaker's microphone, to close the call, press "📞" again. Press "⏮" "⏭" to adjust volume. Reject incoming calls, double press "📞".

Line-in mode: connect with line-in cable, blue LED lighting, press "⏮" "⏭" to adjust volume.

Power bank: 4 pcs of blue LED lights, each represents 25%, display in actual battery capacity, while power bank charger for device, flash 1 second of actual battery capacity's LED.

EQ mode: default is bass, press "🎧" to shift surround mode.

Rest: If the device down, please use the 0.8mm round needle to click the reset holes to let the speakers turn off.

Pairing

Please turn on the Bluetooth App on your mobile phone, search for and pair with Bluetooth device named "BTS83". If system remind you to enter a password, please enter "0000". After hearing a voice guide "connected", the connection is finished.

Description

Bluetooth: V4.0
Rating Power: 5W*2
Range: 10m
Charge time: 5-6hours
Play time: 8-10hours
Standby time: 350hours
Product Size: L212*W60*H82mm
Net Weight: 1.08kg
Charging Output: 5V 1.5A

FCC Information and Copyright

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates,

uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.