

HB6351 说明书 (HelloBaby)

说明书为折叠式
尺寸: 540*120MM
材质: 100g双胶纸 (彩色)
版本: V1.0
类型: 环保

版本	修改内容	日期
Ver: 1.0	首次发行。	2022/03/10

540.00 mm

120.00 mm

Ver: 1.0

HelloBaby®

User Manual

2.4GHz Digital Wireless Video Baby Monitor

Model: HB6351

The pictures are for reference only, please subject to practicality.

www.hellobaby.net.cn

service@hellobaby.net.cn

Thank you for purchasing the HB6351 Baby Monitor. With our baby monitor, you could see and hear your baby sleeping or playing in their room anytime.

Please return your original dated sales receipt for your records. For warranty service of your product, you will need to provide a copy of your dated sales receipt to confirm warranty status. Registration is not required for warranty coverage.

Parent unit x 1

Camera unit x 1

Wall-mounting kit x 1

Power Adapter x 2

1. SAFETY INSTRUCTIONS

CAUTION: Keep the device away from children.

Strangulation Hazard: Children have STRANGLED in cords. Keep this cord out of the reach of children (more than 3ft (0.9m) away). Never use extension cords with AC Adapters. Only use the AC Adapters provided.

Choking hazard: This product contains small parts, please be careful when unpack and assemble the product.

Read and keep to instructions: All the safety and operating in instructions should be read before the video baby monitor is operated. This product cannot replace responsible adult supervision.

Water and moisture: This product is designed for indoor use only. The unit should not be exposed to rain, moisture, dripping or splashing. No objects filled with liquid should be placed on top of, or beside the product, such as a glass or vase. This item should not be used near water.

DO NOT: Use the appliance if the cord or plug is damaged. If your baby monitor is not operating properly or has suffered any damage, contact "Videosims" service center to request inspection and repair of the appliance in order to avoid any possible risk.

DO NOT: Do not attempt to repair or adjust any of the electrical or mechanical functions of the unit. Otherwise, the guarantee will be made void.

Ventilation: This baby monitor should not be used on a bed, sofa, rug or similar surface that may block the ventilation openings, or be placed in an enclosed area such as a bookcase or drawer that may impede air flow.

Keep away from sources of heat: This unit should not be exposed to direct heat sources such as candles, radiator, heat register, stove or other appliance that emits heat. The unit should not be left in direct sunlight.

Power source: This unit should only be used with the AC power adapters included in this package (rated 5V 1A).

Damaged requiring service: This product should be serviced by qualified personnel only when: Objects have fallen or liquid has been spilled into the product.
- The units have been exposed to rain;

3.1 INSTALLATION GUIDELINES

* To use your parent unit and camera unit together, you have to establish a radio link between them, and the range will be affected by environmental conditions.

* Any large metal object, like a refrigerator, a mirror, a filing cabinet, metallic doors or reinforced concrete between the baby and parent unit may block the radio signal.

* The signal strength may also be reduced by other solid structures, like walls, or by radio or electrical equipment, such as TV, computers, cordless or mobile phones, fluorescent lights or dimmer switches.

* Use of other 2.4GHz products, such as wireless networks (Wi-Fi routers), Bluetooth systems, or microwave ovens, may cause interference with this product, so keep the baby monitor away at least 5ft (1.5m) from such products, or turn them off if they cause interferences.

4. PLACEMENT OF THE BABY MONITOR

The camera can be placed on the desktop or mounted on the wall. Don't place baby monitor on soft quilted blankets or in the corners of cupboards, shelves, etc. Keep the baby monitor away from heat sources such as radiators, chimneys, cookers and direct sunlight. Keep the baby unit away from TV sets, microwave oven and radios. If interference occurs, move the camera to elsewhere.

* Place the camera within 6 feet (2 meters) of the area being monitored for optimum performance.

5. GETTING STARTED

5.1 TURN ON THE BABY UNIT:

1. Insert the DC plug of the power adapter into the DC jack in the rear of the Baby Unit;

2. Insert the other end of the power adapter into suitable electrical outlet;

3. Once the adapter is connected, the power LED will light up.

5.2 TURN ON THE PARENT UNIT:

1. Insert the DC plug of the power adapter into the DC jack in the side of the parent Unit;

2. Insert the other end of the power adapter into a suitable electrical outlet;

3. Press and hold the power key 3 seconds on the side of the parent unit;

4. Once parent unit is on, the power LED will light up and the image will display on the LCD

5.3 INFRARED NIGHT VISION (AUTOMATIC)

The infrared night vision function allows the camera to pick up images in dark or low light conditions. In this mode, only black and white images will be displayed on the monitor. The optimum image lie in where baby and is 6ft (2m) away from object. The camera is in night vision mode, the icon will be displayed on the top of screen.

6. PRODUCT OVERVIEW

6.1 ICONS OVERVIEW:

Signal Strength

Alarm

Lullaby

Camera

Volume

Brightness

Night vision

VOX

Zoom

Two-Way Talk

Battery level

Temperature

6.2 PARENT UNIT OVERVIEW:

Charging LED

Power LED

Sound Level Indicator

Zoom / View / Scan

Left/Two Way Talk

Up key

Right key

Down key

Menu/OK

MIC

Lock key

6.3 BABY UNIT OVERVIEW:

MIC

Light sensor

Infrared LEDs

Lens

Speaker

Antenna

DC Jack

Pair key

Temperature sensor

7. KEY OPERATION

7.1 TURN ON/OFF

Press and hold the power key for 3 seconds to turn on / off the parents unit.

7.2 UP ▲ KEY

Press once to tilt the camera up by one step. Press and hold to tilt continuously.

7.3 DOWN ▼ KEY

Press once to tilt the camera down by one step. Press and hold to tilt continuously.

7.4 LEFT ◀ KEY

Press once to pan the camera left by one step. Press and hold to pan continuously.

7.5 RIGHT ▶ KEY

Press once to pan the camera right by one step. Press and hold to pan continuously.

7.6 CAMERA VIEW/SCAN

Press once to switch to view/scan camera: during scan mode, the scan icon will be displayed on the top of screen. Each camera's video will be displayed on the LCD around 10 seconds then change to next camera.

7.7 DIGITAL ZOOM

Press and hold the zoom key around 2 seconds to operate zoom in/ out;

7.8 Two Way Talk

Press and hold the key to enter two way talk mode. A microphone icon will be displayed in the corner of the LCD screen. Release the key to stop.

8. MENU OPERATION

8.1 PARENTING THE CAMERA AND PARENT UNITS

The baby unit is pre-registed to your parent unit. You do not need to register it again unless the baby unit loses its link with the parent unit. To re-register your baby unit, or register a

WARNING

Strangulation Hazard: Children have STRANGLED in cords. Keep this cord out of the reach of children (more than 3 ft (0.9 m) away). Do not remove this tag.

AVERTISSEMENT

DANGER D'ÉTRANGLEMENT: Des enfants se sont ÉTRANGLÉS avec des cordons électriques. Gardez le cordon/électrique hors de la portée des enfants (à plus de 0,9m/3 pi du lit d'enfant). Ne pas enlever cette étiquette.

FC

CE

UK

BC

RoHS

REACH

WEEE

Recycling

Recycling

Recycling

Recycling

Recycling

540.00 mm

120.00 mm

a new baby unit, follow the procedure below:

Note: Camera icon with means it is well registered. You should select and pair with the camera icon without sign.

8.1.1 ADD CAMERA

1. Press the MENU key then the menu will pop up;

2. Press the key to select is selected by red box;

3. Press the key to enter into sub-menu, then press the key to select your desired camera;

4. Press the key enter into sub-menu; Press the key to select 1 then press the key;

5. When the icon is displayed on the LCD screen, press the PAIR button on the back of camera;

6. Once paired, Successful pairing icon shows on the LCD screen;

7. If fails, repeat the above steps.

8.1.2 DELETE CAMERA

1. Press the MENU key and the menu will pop up;

2. Press the key to select is selected by red box;

3. Press the key enter into sub-menu, then press the key to select the camera you want to delete;

4. Press the key enter into sub-menu; Press the key then press the key;

5. Press the key to select icon to delete the camera;

6. Press the key to confirm the option.

8.2 VOLUME

1. Press the key then the menu will pop up;

2. Press the key to select is selected by red box;

3. Press the key enter into sub-menu;

4. Press the key to select the desired volume level from level 1~5.

8.3 DISPLAY BRIGHTNESS

1. Press the MENU key then the menu will pop up;

2. Press the key to select the brightness icon is selected by red box;

3. Press the key enter into sub-menu;

4. Press the key to select the desired brightness level from level 1~5.

(The default brightness level setting is level 3.)

8.4 TEMPERATURE UNIT SETTING

1. Press the MENU key then the menu will pop up;

2. Press the key to select the temperature icon is selected by red box;

3. Press the key enter into sub-menu;

4. Press the key to select the °F or °C for setting temperature unit;

5. Press the key to confirm;

6. Press the key to Exit.

Note: The detected temperature range is 0~40 °C.

8.1.1 TEMPERATURE ALARM SETTING

1. Press the key to select for turning on alarm function; Press the key to confirm;

2. Press the key to select for turning off alarm function; Press the key to confirm.

8.1.2 SET TEMPERATURE/HILO ALERT LIMITS

1. Press the key to select (for Hi/Lo limits settings);

2. Press the key to adjust the Hi limit when (red) selected;

3. Press the key to adjust the Lo limit when (green) selected;

Note: The high temperature alarm default setting is 36 °C, and the low temperature alarm default setting is 8 °C. When the temperature gets above or below the settings, the temperature icon will display on the screen. It will alert user by beeps. Press any key on the parent unit to stop beeping and flashing.

8.5 LULLABY SETTING

You can soothe the baby to sleep by playing a gentle lullaby from the Camera unit.

1. Press the MENU key and the menu will pop up;

2. Press the key to enter into sub-menu, then press the key to select the camera you want to delete;

3. Press the key enter into sub-menu;

4. Press the key to select one of the available lullabies, you can pick single playback, loop (all 8 lullabies) playback, PC or stop.

5. Press the key to confirm.

Note: The lullaby default setting is OFF.

8.6 ALARM SETTING

1. Press the MENU key and the menu will pop up;

2. Press the key to select the alarm icon is selected by red box;

3. Press the key enter into sub-menu; Press the key to select the alarm time you need;

4. Press the key to confirm;

5. Press the key to Exit.

Note 1: The minimum unit is 0.5 hour. The maximum setting is 5 hours (7 levels).

Note 2: Once the alarm is turned on, alarm icon will display on the screen.

Note 3: The alarm default setting is OFF.

Note 4: When the alarm is ringing, press any key on the parent unit to turn the alarm off.

Note 5: If you don't turn off the alarm, the alarm will ring for 1 minute. After three minutes the alarm will ring again for 1 minute. The alarm will ring for three times in total, after this the alarm goes off.

8.7 VOX SETTING

This mode allows you to control the sound activation of your baby unit. If there is no sound around the baby unit within 30 seconds, it will stop audio transmission and turn off the

screen of the parent unit. When the baby unit detects any sounds louder than the sensitivity level, it will start transmitting the signal to the parent unit again and turn on the screen of the parent unit. To change the VOX level, please follow the below instructions:

1. Press the MENU key and the menu will pop up;

2. Press the key to select is selected by red box;

3. Press the key enter into sub-menu, then press the key to select desired level;

4. Press the key to confirm;

5. Press the key to Exit.

Note: is Low sensitivity level, the baby have to make a lot of sound before the VOX function will be activate;

Note: is middle sensitivity level;

Note: is High sensitivity level, the baby don't have to make a lot of sound before the VOX function will be activate;

8.8 LANGUAGE SETTING

1. Press the MENU key and the menu will pop up;

2. Press the key to select is selected by red box;

3. Press the key enter into sub-menu, then press the key to select the language you need;

4. Press the key to confirm;

5. Press the key to Exit.

9. TECHNICAL DATA

Frequency	2412MHz~2486MHz
Parent Unit: Input: 100~240VAC 50/60Hz	
Output: 5V DC 1A	
Camera Unit: Input: 100~240VAC 50/60Hz	
Output: 5V DC 1A	
Operating Range	Up to 1000m (100m) outdoor (line of sight)
	Up to 165ft (50m) indoor
Display	5.0" Diagonal TFT LCD
Battery (Parent Unit)	Li-ion 3.7V 2800mAh (7.4Wh)
Remain life	Up to 10 hours
Maximum power	<150mW
Operation environment	Temperature: +32F~+104F (0°C~40°C) Battery Charging Temperature: +50F~+104F (10°C~40°C) Relative Humidity: 35%~65%

10. TROUBLE SHOOTING

No reception on the monitor	* The power adapters may not be properly connected; * Confirm the camera and monitor are ON; * Cables may be far away from the monitor; * Camera and monitor may not be properly paired. Follow PAIRING instructions.
Interference or poor reception	* Move the monitor closer to the camera; * The camera or monitor may be placed too close to many metal objects; * Other electronic devices may be interfering with the signal; * The battery power may be too low.
Audio feedback (high pitched noise)	* The camera and monitor may be placed too close;

11. MAINTENANCE

* Clean your baby monitor with a slightly damp or anti-static cloth.

* Never use cleaning agents or solvents.

12. DISPOSAL GUIDELINE FOR BATTERY AND PRODUCT

* Do not attempt to repair or adjust any of the electrical or mechanical functions of the unit.

* Remember to dispose of the product in an environmentally responsible way;

* For proper collection and processing of these products, take them to the collection points designated by local authorities. You can also contact the store where you purchased the product.

Improper or incorrect use of batteries may cause corrosion or battery leakage, which could cause personal injury or damage to property. Use only the types of the batteries which are indicated by local authorities.

CAUTION: Risk of Fire and Burns. Do Not Open, Crush, Heat Above 45 degree C or Incinerate. Follow Manufacturer's Instructions.

Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.

-Leaving a battery in an extremely high temperature surrounding environment can result in an explosion or the leakage of flammable liquid or gas.

-A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

-The battery should not be exposed to excessive heat such as sunshine, fire or the like;

FC, AND IC REGULATIONS

FC Part 15

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FC Caution:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Statement:

"This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help."

Industry Canada

This device complies with Industry Canada license exempt RSS standard(s).
Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire d'interférence, et (2) l'appareil doit accepter toute interférence radioélectrique qu'il reçoit, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with Industry Canada radiation exposure limits set forth for an uncontrolled environment.
Cet équipement est conforme à l'exposition aux rayonnements d'Industrie Canada limites établies pour un environnement non contrôlé.

This device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and complies with the RSS 102 exposure limits, users can obtain Canadian information on RF exposure and compliance on device met conform to l'exemption des limites d'évaluation courante dans la section 2.5 de cr - 102 et respecte les limites d'exposition aux ondes radioélectriques, les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs RF et le contrôle.

FC Caution:

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.
Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.
For these link:
Specific Absorption Rate (SAR) information
This device meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC/ISED RF Exposure Information and Statement the SAR limit of 0.08 W/kg (IC/ISED SAR limit) is 0.08 W/kg averaged over one gram of tissue. Device types: Device has also been tested for SAR limit. This device was tested for typical body-worn operation with the back of the phone held over the back of the body. To maintain compliance with FCC/ISED RF exposure requirements, use accessories that maintain an 0mm separation distance between the user's body and the back of the device. The use of third-party holders and other accessories should not contain metallic components or be assembly. The use of accessories that do not satisfy these requirements may not comply with FCC/ISED RF exposure requirements, and should be avoided.
Informations sur le débit d'absorption spécifique (DAS)
Cet appareil respecte les exigences du gouvernement en matière d'exposition aux ondes radio. Les lignes directrices sont basées sur des normes élaborées par des organisations scientifiques indépendantes à travers une évaluation périodique et approfondie des études scientifiques. Les normes comprennent une marge de sécurité substantielle conçue pour assurer la sécurité de toutes les personnes, quel que soit leur âge ou leur état de santé. Informations sur l'exposition aux ondes radio: Cet appareil a été testé pour la conformité avec les exigences d'exposition RF d'ISED. Utilisez des accessoires qui maintiennent une distance de séparation de 0 mm entre le corps de l'utilisateur et l'arrière du dispositif. L'utilisation de supports de ceinture, d'étuis et d'accessoires similaires ne doit pas contenir de composants métalliques dans les assemblages. L'utilisation d'accessoires qui ne satisfont pas à ces exigences peut ne pas être conforme aux exigences d'exposition aux RF d'ISED et doit être évitée.

ED Declaration of Conformity (DOC)

Hereby, Videosims declares that the radio equipment type is in compliance with RED Directive 2014/53/EU.
The full text of the ED declaration of conformity is available on the website: www.hellobaby.net.cn

Model: HB6351

Responsible Party (UK): Startline LLC

Address: 22 Hazelwood Drive, Jericho, NY 11753

Tel: 1-516-683-3729

Authorized UK Representative(s): Safetone wnt

Address: 100 Progress Road, Jericho, NY 11753

Tel: (440) 740 570 2799

Shenzhen Videosims Technology Co., Ltd

701, Building 3, No. 1, Nanhua Road, Gangkang Community, Jihua Street Office, Longgang District, Shenzhen

Risk Group 1

WARNING! Do not emit from this product. Do not stare at operating lamp

Product tested against EN62473