

多方向開合線

電機開合

150mm

100mm

支持系统
Win/iOS/Android

系统切换
Fn+Q 切换iOS
Fn+E 切换Win

Figure 1-10 shows a USB cable with a Type-A connector on the left and a Micro-B connector on the right. A callout bubble points to the Micro-B connector, showing a circular arrow and the text "ON" and "OFF".

1. 将打开键合电源开关，蓝色灯亮后，选择频道，按F+C时数码灯闪烁进入配对模式。

2. 在开始打开“设置”，然后打开蓝牙，进行探索模式。

3. 直到发现“Bluetooth 5.1 Keyboard”，然后点击该连接。

4. 显示连接成功或失败，您就可以舒适地使用您的键盘了。

注：配对成功以后，再次使用只需要打开蓝牙电源及使用该设备的蓝牙，蓝牙键盘将会自动连接到上次使用过的设备，不需要再进行配对操作。

注：配对成功以后下次使用只需要打开蓝牙键盘电源及使用设备的蓝牙，蓝牙键盘将会自动搜索连接上次使用过的设备，不需要再进行配对操作。

iOS/Android		Windows		Windows	
直接	对应功能	F1+	对应功能	直接	对应功能
F1	返回桌面	Esc	主页	Esc	F5c
F2	搜索	F1	搜索	F1	F5c
F2	全选	F2	全选	F2	F2
F3	复制	F3	复制	F3	F3
F4	粘贴	F4	粘贴	F4	F4
F5	剪切	F5	剪切	F5	F5
F6	上一曲	F6	上一曲	F6	F6
F7	暂停/播放	F7	暂停/播放	F7	F7
F8	下一曲	F8	下一曲	F8	F8
F9	静音	F9	静音	F9	F9
F10	音量减小	F10	音量减小	F10	F10
F11	音量增大	F11	音量增大	F11	F11
F12	锁屏	F12	锁屏	F12	F12

Windows : Alt+Shift 切换语言 iOS : Ctrl+空格键 切换语言
Android : Shift+空格键 切换语言

键盘尺寸：342.35x114.7x10.9 mm(打开)	触摸屏尺寸：56.1 x 45.1 mm
182.25x114.7x19.5 mm(折叠)	键盘重量：222 g
使用触摸屏工作电流：<11 mA	待机电流：<1 mA
使用按键工作电流：<4 mA	休眠电流：17μA
工作距离：10 m	休眠时间：10 分钟
锂电池容量：140 mAh	唤醒方式：按键唤醒
工作电压：3.7 V	

	单指点击 - 鼠标左键		双指点击 - 鼠标右键
	双指上/下/左右滑动 - 鼠标滚轮		双指分开/合拢 - 放大/缩小
	三指点击 - 搜索		三指向左轻划制 - 活动窗口切换
	三指向上扫 - 打开任务类窗口		三指向右轻划制 - 活动窗口切换
	三指向下扫 - 返回桌面		四指点击 - 打开Action-center

[illegible]

设置-辅助功能-触控-辅助触控-设备-点击键盘配对名，然后对单指点/双指点/三指点进行功能自定义。

- 对码：打开电源开关，蓝牙指示灯亮起，按下对码键，蓝灯闪烁
- 充电：指示灯红色，充满灯灭
- 低电压指示：当电压低于3.3V，红色指示灯闪烁

- 连接第一个设备时, 先按Fn+ F1 , 再按Fn+C对码, 开始连接。
- 连接第2个设备前, 先按一次Fn+ F2 , 再按Fn+C对码, 开始连接。
- 连接第3个设备前, 先按一次Fn+ F3 , 再按Fn+C对码, 开始连接。
- 在多个设备同时使用, 按Fn+ F1 / F2 / F3 切换, 即可自由切换到已连接的设备。

请与售后服务人员联系
知识产权信息

请不要打开或修理该设备，请不要在潮湿环境内布擦拭该设备。

- 1、请勿将设备暴露于液体和潮湿的环境中或使其淋雨，请勿在浴缸、水槽、桑拿房、游泳池或蒸汽房附近使用。
- 2、请勿将设备暴露于过高或过低的温度下。
- 3、请勿长时间放置在阳光直射的地方。
- 4、请勿靠近明火，如烹饪炉、蜡烛或壁炉。
- 5、避免使用锋利器物刮擦产品，及时给产品进行充电以保证正常使用。

1. 平板无法连接蓝牙键盘？
请先检查蓝牙键盘是否进入配对状态。然后再打开平板电脑蓝牙搜索设备进行连接。
2. 检查蓝牙键盘电量是否充足，电量不足也会导致无法连接，请将蓝牙键盘充电后再使用。
3. 键盘指示灯在使用途中一直闪烁？
键盘指示灯在使用途中一直闪烁，表示电池即将没电，请尽快将键盘充电。
3. 设备显示蓝牙键盘断开连接？
蓝牙键盘在一段时间内不使用，设备为了省电将自动关闭蓝牙功能，按键盘任意键唤醒，蓝牙连接自动恢复。

front

Multi-Function Keys

back

Charging Port

Note: Please read the user manual carefully before you start using this product.

- Press open the power switch, blue lights up, select channel, press the FinC-connect button, blue light twinkles.
- Open the tablet PC setting "Bluetooth" into searching and pairing status.
- You will find the "Bluetooth 5.1 Keyboard" and click to "next step"
- There is a tip for connecting successfully you can use your keyboard comfortably.

1. Press down the power switch, blue light is up. Select channel, press the Fin+Connect button, blue light betides.
2. Open settings; turn on Bluetooth; click Add Bluetooth or other devices.
3. Select "Bluetooth" in the Add Device to search.
4. You will find the "Bluetooth 5. Keyboard" and click the pairing name to connect.
5. There is a tip for connecting successfully; you can use your keyboard comfortably.

1. Press the power switch, blue lights up. See channel, press the Fn+F2 connect button, blue light twinkles.

2. Open the set up button at the starting interface and select "Bluetooth" then searching.

3. You will find the "Bluetooth" 1 keyboard* and click the pairing name to connect.

iOS/Android		Windows		Windows	
Press directly	Corresponding function	Fn+	Corresponding function	Press directly	Corresponding function
F1	Return to Esc	F1	Home Page	F1	Esc
F2	Select	F2	Select	F2	F2
F3	Copy	F3	Copy	F3	F3
F4	Stick	F4	Stick	F4	F4
F5	Cut	F5	Cut	F5	F5
F6	Pre-Track	F6	Pre-Track	F6	F6
F7	Play/Pause	F7	Play/Pause	F7	F7
F8	Next	F8	Next	F8	F8
F9	Mute	F9	Mute	F9	F9
F10	Volume-	F10	Volume-	F10	F10
F11	Volume+	F11	Volume+	F11	F11
F12	Lock	F12	Lock	F12	F12

Windows : Alt+Shift switch language
iOS : Ctrl+Space key switch language
Android : Shift+Space key switch language

Product: Bluetooth Keyboard
Model No.: S006
Trade Marks: N/A
Hardware Version: V04
Software Version: V1.0

Accessories:
Battery information:
Specification: Model: S006
Specification: Nominal voltage: 3.7V Capacity: 145mAh
Manufacturer: SHENZHEN TAIWOO GADGET CO.,LTD.

(Name of product, type or model, batch or serial number)

attestifies that the terminal equipment applicable to the product within the scope of Council
Directives 2014/53/EU, 2014/53/EU and 2014/30/EU, and declare that the same application has not
been used with any other notified body.

EN 62479:2010
EN 60465:2017
EN 62369-1:2014+AC1:2017
EN 62369-2:2014+AC1:2017
EN 62369-3:2014+AC1:2017
EN 62369-4:2014+AC1:2017
EN 62369-5:2014+AC1:2017
EN 62369-6:2014+AC1:2017
EN 62369-7:2014+AC1:2017
EN 62369-8:2014+AC1:2017
EN 62369-9:2014+AC1:2017
EN 62369-10:2014+AC1:2017
EN 62369-11:2014+AC1:2017
EN 62369-12:2014+AC1:2017
EN 62369-13:2014+AC1:2017
EN 62369-14:2014+AC1:2017
EN 62369-15:2014+AC1:2017
EN 62369-16:2014+AC1:2017
EN 62369-17:2014+AC1:2017
EN 62369-18:2014+AC1:2017
EN 62369-19:2014+AC1:2017
EN 62369-20:2014+AC1:2017
EN 62369-21:2014+AC1:2017
EN 62369-22:2014+AC1:2017
EN 62369-23:2014+AC1:2017
EN 62369-24:2014+AC1:2017
EN 62369-25:2014+AC1:2017
EN 62369-26:2014+AC1:2017
EN 62369-27:2014+AC1:2017
EN 62369-28:2014+AC1:2017
EN 62369-29:2014+AC1:2017
EN 62369-30:2014+AC1:2017
EN 62369-31:2014+AC1:2017
EN 62369-32:2014+AC1:2017
EN 62369-33:2014+AC1:2017
EN 62369-34:2014+AC1:2017
EN 62369-35:2014+AC1:2017
EN 62369-36:2014+AC1:2017
EN 62369-37:2014+AC1:2017
EN 62369-38:2014+AC1:2017
EN 62369-39:2014+AC1:2017
EN 62369-40:2014+AC1:2017
EN 62369-41:2014+AC1:2017
EN 62369-42:2014+AC1:2017
EN 62369-43:2014+AC1:2017
EN 62369-44:2014+AC1:2017
EN 62369-45:2014+AC1:2017
EN 62369-46:2014+AC1:2017
EN 62369-47:2014+AC1:2017
EN 62369-48:2014+AC1:2017
EN 62369-49:2014+AC1:2017
EN 62369-50:2014+AC1:2017
EN 62369-51:2014+AC1:2017
EN 62369-52:2014+AC1:2017
EN 62369-53:2014+AC1:2017
EN 62369-54:2014+AC1:2017
EN 62369-55:2014+AC1:2017
EN 62369-56:2014+AC1:2017
EN 62369-57:2014+AC1:2017
EN 62369-58:2014+AC1:2017
EN 62369-59:2014+AC1:2017
EN 62369-60:2014+AC1:2017
EN 62369-61:2014+AC1:2017
EN 62369-62:2014+AC1:2017
EN 62369-63:2014+AC1:2017
EN 62369-64:2014+AC1:2017
EN 62369-65:2014+AC1:2017
EN 62369-66:2014+AC1:2017
EN 62369-67:2014+AC1:2017
EN 62369-68:2014+AC1:2017
EN 62369-69:2014+AC1:2017
EN 62369-70:2014+AC1:2017
EN 62369-71:2014+AC1:2017
EN 62369-72:2014+AC1:2017
EN 62369-73:2014+AC1:2017
EN 62369-74:2014+AC1:2017
EN 62369-75:2014+AC1:2017
EN 62369-76:2014+AC1:2017
EN 62369-77:2014+AC1:2017
EN 62369-78:2014+AC1:2017
EN 62369-79:2014+AC1:2017
EN 62369-80:2014+AC1:2017
EN 62369-81:2014+AC1:2017
EN 62369-82:2014+AC1:2017
EN 62369-83:2014+AC1:2017
EN 62369-84:2014+AC1:2017
EN 62369-85:2014+AC1:2017
EN 62369-86:2014+AC1:2017
EN 62369-87:2014+AC1:2017
EN 62369-88:2014+AC1:2017
EN 62369-89:2014+AC1:2017
EN 62369-90:2014+AC1:2017
EN 62369-91:2014+AC1:2017
EN 62369-92:2014+AC1:2017
EN 62369-93:2014+AC1:2017
EN 62369-94:2014+AC1:2017
EN 62369-95:2014+AC1:2017
EN 62369-96:2014+AC1:2017
EN 62369-97:2014+AC1:2017
EN 62369-98:2014+AC1:2017
EN 62369-99:2014+AC1:2017
EN 62369-100:2014+AC1:2017
EN 62369-101:2014+AC1:2017
EN 62369-102:2014+AC1:2017
EN 62369-103:2014+AC1:2017
EN 62369-104:2014+AC1:2017
EN 62369-105:2014+AC1:2017
EN 62369-106:2014+AC1:2017
EN 62369-107:2014+AC1:2017
EN 62369-108:2014+AC1:2017
EN 62369-109:2014+AC1:2017
EN 62369-110:2014+AC1:2017
EN 62369-111:2014+AC1:2017
EN 62369-112:2014+AC1:2017
EN 62369-113:2014+AC1:2017
EN 62369-114:2014+AC1:2017
EN 62369-115:2014+AC1:2017
EN 62369-116:2014+AC1:2017
EN 62369-117:2014+AC1:2017
EN 62369-118:2014+AC1:2017
EN 62369-119:2014+AC1:2017
EN 62369-120:2014+AC1:2017
EN 62369-121:2014+AC1:2017
EN 62369-122:2014+AC1:2017
EN 62369-123:2014+AC1:2017
EN 62369-124:2014+AC1:2017
EN 62369-125:2014+AC1:2017
EN 62369-126:2014+AC1:2017
EN 62369-127:2014+AC1:2017
EN 62369-128:2014+AC1:20

Keyboard size: 342.35 x 114.7 x 10.9mm (open)	
182.25 x 114.7 x 19.5mm (folding)	
Working distance: 10 m	Touchpad size: 56.1X45.1mm
Lithium battery capacity: 140mAh	Weight: 222 g
Working voltage: 3.7V	Key working current: <4mA
Use touchpad the working current: <11mA	Standby current: <1mA
Sleep time: Ten minutes	Sleep current: 17µA
Awaken way : Press key	

	Tap — The left of mouse button		Two-finger tap — The right of mouse button
	Two-finger slides vertically / horizontally — Mouse wheel		Two-finger separation / collapse — Zoom in / out
	Three-finger tap — Search		Three-finger slide to the left continuously — Switch the active window
	Three-finger slides up — Open the browser window		Three-finger slide to the right continuously — Active window switch
	Three-finger slides down — Go Home		Four-finger tap — Open the (Action + Center)

Two-finger tap — (near/defined)	Tap — Mouse cursor	Single drag — then drag — Drag
Two-finger tap — Open the menu — (near/defined)	Two-finger slide vertically — Mouse wheel	Two-finger horizontal slide — Move the window and the content
Two-finger separation / collapse — Zoom in / out	Three-finger tap — Desktop — (near/defined)	Three-finger lift — On the bottom panel — (near/defined)
Three-finger slide — Open all the active windows — (near/defined)	Three-finger slide left — Active windows — (Cmd+Shift+Tab)	Three-finger right — On the left — (Cmd+Shift+Tab)
Four-finger tap — Replicate screenshots — (Cmd+Shift+4)		

Settings ▸ Auxiliary Functions ▸ Touch - Auxiliary Touches ▸ Device ▸
Click the keyboard's pairing name, and then customize the function of
'single finger, Two-finger, Three-finger'.

The diagram illustrates four mouse gestures, each with a corresponding icon and text description:

- Tap** — The left of mouse button
- Two-finger tap** — Return
- Two-finger slides vertically / horizontally** — Mouse wheel
- Drag** — Mouse cursor

- **Connect** : Open the power switch, blue lights up, press the connect button, blue light twinkles.
- **Charging** : Indicator light will be on red, after fully charging, the light crush out.
- **Low Voltage Indication** : When the voltage is below 3.3 V, red light twinkles.

- When connecting the first device, first press Fn + 1 and then press Fn + C to start the connection.
- Before connecting the second device, press Fn + 2 once, then press Fn + C to start the connection.
- Before connecting the third device, press Fn + 3 once, then press Fn + C to start the connection.

Please contact the after-sales service.

Do not open or repair this device, Do not use the device in a damp environment. Clean the device with a dry cloth.

Warranty

The device is provided with one-year limited hardware warranty from the purchase day.

1. Please keep the keyboard away from liquid or humid environment, saunas, swimming pool, steam room and don't let the keyboard get wet in the rain.
2. Please don't expose the keyboard at too high or too low temperature condition.
3. Please don't put keyboard under sun for a long time.
4. Please don't put keyboard close to the flame, such as cooking stoves, candles or fireplace.
5. Avoid sharp objects scratching products, timely to recharge products to ensure the normal use.

1. The tablet PC can't connect the BT keyboard?
 - 1) At first check the BT keyboard is into match code state, then open the tablet PC Bluetooth searching.
 - 2) Checking the BT keyboard Battery is enough, the battery low is also lead to can't connect, you need charge.
2. The keyboard indication light always flashing when use?

Keyboard indication always flashing when use, means the keyboard will be no power ,please charge the power as soon as possible.
3. The tablet PC display BT keyboard is disconnect?

The Bluetooth keyboard is not used for a period of time, the device will automatically enter the sleep state in order to save power. Press any key on the keyboard to wake up, and the Bluetooth connection will be automatically restored.

User information

Company or personage full name

Contact address

TEL Zip

The purchased product name and mode NO.

Purchased date

This reason due to the product **break** and **damage** is **not** include on the warranty.

- (1) accidents, misuse, improper operation, or any unauthorized maintenance, alteration or disassembly.
- (2) improper operation or maintenance, violation of product instructions or improper connection of power during use;
- (3) Or use consumables (such as spare batteries) that are not provided by the company but applicable laws. Except where such restrictions are prohibited

B006 is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.

In accordance with Article 10(2) and Article 10(10), this product allowed to be used in all EU member states in all EU member states.

Use the Bluetooth Keyboard in the environment with the temperature between 0°C and 35°C.

Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

The product shall only be connected to a USB interface of version USB2.0

Operation Frequency: 2402MHz-2480MHz

Max output Power: 0.005W

Manufacturer: Shenzhen OZH Industrial Co., Ltd
Address: 3th Floor, Yituo Mike Industrial A building, Bu'Yong Industrial District, Shajing, Shenzhen, China
E-mail: lgh@ozhgy.com

Manufacturer: Shenzhen DZH Industrial Co., Ltd
Address: 3th Floor, YITuo Mike Industrial A building, Bu Yong Industrial D zone,
Shajing, Shenzhen, China
E-mail: liqh@dzhgy.com

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when this equipment is operated normally. The limits include radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Plug the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device must not cause harmful interference.
2. This device must accept any interference that may be received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure statement.

This device is not intended to be used in the following circumstances: