



M01S SMART GLASSES User's Manual (English) Appearance Camera Charging Contact Flash  Key Definition  Key ①: A: In the off state, long press the key for 3 seconds to turn on the power;	B: Under power-on state, long press the key for 5 seconds to turn off the product; C: Under power on state, long press the key for 10 seconds will make the product restore the factory settings (this operation will clear all the data on the device, please use with caution); D: Under power-on state, short press 1 time to take a picture, the photo will be automatically stored in the local memory of the product, and can be imported to the cell phone after connecting the APP; E: Under power-on state, short press 2 times quickly to record video, and then short press once to end this recording during the recording process, the video taken will be automatically stored in the local memory of the product, and it can be imported to your cell phone after connecting the APP; F: In the power-on state, long press the button for 16 seconds will make the product forced to restart and enter into the pending connection state; G: When a call comes in, short press once to answer the incoming call, long press for 3 seconds to reject the current incoming call; Press button ②: A: While the device is powered on, press the button once briefly to wake up the AI voice assistant. You can then ask the AI voice assistant questions. This operation requires the HeyCyan app to remain displayed on the front screen; B: While the device is powered on, press and hold the button for 2 seconds to enable the recording function. During recording, press the button once briefly to end the recording.	The recorded audio will be automatically stored in the device's local memory and can be imported into your phone after connecting to the app; C: While the device is powered on, quickly press the button twice to activate the object recognition feature. Keep your head still while the camera takes a photo of the object in front of you and syncs it to the app for analysis. The results can be viewed in the AI section of the app. Touch area ③: A: When playing music, continuously double-click the touch area to start/pause playback; B: When playing music, three consecutive clicks on the touch area to switch to the previous music; C: When playing music, long press the touch area to switch the next music. D: While playing music, swipe along the touch area toward the "Front" direction to increase the music volume; swipe along the touch area toward the "Back" direction to decrease the music volume. Connection instructions 1. This smart glasses is a stand-alone product, many functions must be connected with the cell phone before use. 2. You can search "HeyCyan" in Google Play or iPhone App Store, download and install it to your cell phone. 3. You can also scan the QR code and select the corresponding system version to download.	 Open the installed app and follow the instructions to complete the registration; Select [Home] and click [Connect Device]; Select the name of the searched device [M01S]; When you hear the ding-dong sound, the connection is successful.
--	--	---	---

Warm tips

• This product supports photo and video recording, but the power consumption is relatively high, when the power is lower than 15%, the device will deactivate the photo and video recording function, when the power is lower than 20%, the device will pause the transmission of data to the cell phone, and can be resumed after charging.

• This product supports wifi to transfer data to cell phone and save it, it needs the cell phone to allow APP to use the relevant permissions before it can be realized.