

105MM


450MM

105MM

450MM

1 BUTTONS

FR-Boutons ES-Botones DE-Tasten IT-Pulsanti NL-Knoppen PT-Botões PL-Przyciski HU-Gombok RO-Butoane SK-Tlačidlá CS-Tlačítka SV-Knappar HR-Gumbi SL-Tipke TR-Butonlar LT-Mygutukai SR-Tasteni LV-Pogas EL-Kouymó BG-Бутони KK-Tvimenep RU-Knopki UK-Knopki VI-Các nút ID-Tombol ZH-按钮 JA-ボタン ZT-按钮 TH-ปุ่ม KO-버튼 KM-අනුවා AR-زر



EN-Up FR-Vers le haut ES-Hacia arriba DE-Nach oben IT-Verso l'alto NL-Omhoog PT-Para cima PL-Do góry HU-Fel RO-Sus SK-Hore CS-Nahoru SV-Upp HR-Gore SL-Gor TR-Yukarı doğru LT-Aukštyn SR-Gore LV-Uz augšu EL-Tóvho BG-Harope KK-Korapı RU-Besny UK-Bropy VI-Lên trên ID-Naik ZH-向上 JA-アップ ZT-上 TH-ขึ้น KO-위 KM-අඩංගු AR-أعلى



EN-Down FR-Vers le bas ES-Hacia abajo DE-Nach unten IT-Verso il basso NL-Omlaag PT-Para baixo PL-Niżej HU-Le RO-Jos SK-Dole CS-Dolů SV-Ner HR-Dolje SL-Dol TR-Aşağı doğru LT-Zemyn SR-Dole LV-Uz leju EL-Káto BG-Hagony KK-Tewer RU-Bwas UK-Bwas VI-Xuống dưới ID-Turun ZH-向下 JA-ダウン ZT-下 TH- вниз KO-아래 KM-අඩංගු AR-أدنى



EN-Menu FR-Menu ES-Menu DE-Menü IT-Menu NL-Menu PT-Menu PL-Menu HU-Menü RO-Meniu SK-Menu CS-Menu SV-Meny HR-Izbornik SL-Meni TR-Menü LT-Meniu SR-Meni LV-Izvēlne EL-Menú BG-Menyo KK-Menyu RU-Meny UK-Meny VI-Bảng chọn ID-Menu ZH-菜单 JA-メニュー ZT-選擇 TH-เมนู KO-메뉴 KM-අනුවා AR-القائمة



EN-Settings FR-Réglages ES-Configuración DE-Einstellungen IT-Impostazioni NL-Instellingen PT-Definições PL-Ustawienia HU-Béállítások RO-Reglaje SK-Nastavenia CS-Nastavení SV-Inställningar HR-Postavitev SL-Nastavitve TR-Ayarlar LT-Nustatymai SR-Postavke LV-Iestatījumi EL-Ρυθμίσεις BG-Настройки KK-Бастрылар RU-Настройка UK-Настройка VI-Cài đặt ID-Pengaturan ZH-设置 JA-設定 ZT-各項設定 TH-การตั้งค่า KO-설정 KM-ការកំណត់ AR-إعدادات



EN-Start/Pause FR-Démarrer/mettre en pause ES-Iniciar/Pausa DE-Starten/Unterbrechen PT-Avianar/mettere in pausa NL-Starten/Op pauze zetten PT-Iniciar/colocar em pausa PL-Start/pauza HU-Indítás/Szünet RO-Pornire/pauză SK-Spustiť/prenútiť CS-Spuštění/pozastavení SV-Starta/pausa HR-Pokreni/pauzuj SL-Start/pauza TR-Başlat/durdur EL-Προσέλι / παρατήρηση SR-Pokreni/dijuzustavi LV-Uzskat/ātrunāt EL-Εναρξη / βλεπ σε παύση BG-Старти/пауза KK-İске крөү/тоқтау RU-Включити/поставить на паузу UK-Почати/призупинити VI-Khởi động/dừng ID-Start/jeda ZH-开始/暂停 JA-スタート - 一旦停止する ZT-啟動/暫停 TH-เริ่ม / หยุดพัก KO-시작/일시 중지 KM-ចាប់ផ្តើម/ ឈប់ AR-بدء/توقيف



EN-Lap FR-Tour ES-Vuelta DE-Runde IT-Giro NL-Slag PT-Volta PL-Okrążenie HU-Kör RO-Încercare SR-Kolo CS-Kolo SV-Vanri HR-Napredak SL-Krog TR-Döviz LT-Viršus SR-Krug LV-Aplis EL-Γύρος BG-Обръщане KK-Айналым RU-Оборот UK-Bnepea VI-Vòng ID-Lap ZH-旋转 JA-周 ZT-轉動 TH-รอบ KO-회전 KM-វង់ AR-دورة




EN-Back FR-Retour ES-Atrás DE-Zurück IT-Indietro NL-Terug PT-Retroceder PL-Powrót HU-Vissza RO-Înapoi SK-Spät CS-Zpět SV-Tillbaka HR-Natrag SL-Vrnitev TR-Geri LT-Grįžti SR-Povratak LV-Atpakaļ EL-Εμπρός BG-Назад KK-Kaytaray RU-Hazay UK-Hazay VI-Trở lại ID-Kembali ZH-后返 JA-戻る ZT-返回 TH-กลับ KO-돌아가기 KM-ត្រឡប់ វិញ AR-رجوع

2 START YOUR WATCH

FR-Démarrage de la montre ES-Inicio del reloj DE-Uhr starten IT-Awlio dell'orologio NL-Het horloge starten PT-Iniciar o relógio PL-Uruchomienie zegarka HU-Az óra bekapcsolása RO-Pornirea ceasului SK-Spustenie hodinek CS-Spuštění hodinek SV-Starta klocka HR-Pokretanje sata SL-Vklop ure TR-Saatı başlatılmas LT-Laikrodžio įjungimas SR-Pokretanje sata LV-Uzskāšana EL-Εκκίνηση του ρολογιού BG-Стартиране на часовника KK-Saratay iске крөү RU-Запуск часов UK-Увімнення годинника VI-Khởi động đồng hồ ID-Menghidupkan jam tangan ZH-启动手表 JA-ウォッチを起動する ZT-啟動手錶 TH-กดปุ่มให้ทำงาน KO-시계 시작 KM-ព្រហ្មចាប់ផ្តើមឈ្នួល ឆ្នាំឡើង ប្រចាំឆ្នាំ - بدء تشغيل الساعة

2"





3

App Store

Google Play

APK Download



4 KIPRUN

FR-Connecter ES-Conectar DE-Verbinden IT-Connetti NL-Aansluiten PT-Ligar PL-Połącz HU-Csatlakozás RO-Conectare SK-Pripojiť CS-Připojit SV-Ansluta HR-Povezivanje RO-Povezati TR-Bağlantı kur LT-Prisijungti SR-Povezati LV-Savienoties EL-Συνδέω BG-Свързване KK-Kocy RU-Подключи UK-Підключити VI-Kết nối ID-Menghubungkan ZH-连接 JA-接続 ZT-連線 TH-เชื่อมต่อ KO-커넥트 KM-අනුවා AR-متصل




5 START A SESSION

FR-Lancer une session ES-Inicia una sesión DE-Eine Sitzung starten IT-Avvia una sessione NL-Een sessie starten PT-Iniciar uma sessão PL-Rozpocznij trening HU-Edzés indítása RO-Lansarea unei sesiuni SK-Spustiť reláciu CS-Zahájit trénink SV-Starta en session HR-Pokretanje sesije SL-Zagon vadbe TR-Sesans başlat LT-Pradėti sesiją SR-Pokrenuti sesiju LV-Sākt sesiju EL-Εκκίνηση προπόνησης BG-Започване на сесия KK-Севанты бастрау RU-Начать сессию UK-Почати сесію VI-Bắt đầu bài tập ID-Memulai sesi ZH-开始一个会话 JA-セッションを開始する ZT-開始前練習 TH-การออกกำลังกาย KO-시작 KM-ចាប់ផ្តើម វិញ AR-بدء الحصة



6 CHARGING

FR-Chargement ES-Carga DE-Laden IT-Ricarica NL-Laden PT-Carregamento PL-Ladowanie HU-Tölés RO-Încărcare SK-Nabíjanie CS-Nabíjení SV-Laddar HR-Punjenje SL-Nalaganje TR-Sarj LT-Ikraunama SR-Punjenje LV-Uzāde EL-Φόρτιση BG-Заряджане KK-Њуктене RU-Зарядка UK-Завантаження VI-Sạc ID-Mengisi ZH-充电 JA-ロード ZT-充電 TH-ชาร์จ KO-충전 KM-អនុវត្ត វិញ AR-شحن



7 LEARN MORE

FR-En savoir plus ES-Más información DE-Mehr IT-Maggiori informazioni NL-Meer informatie PT-Para obter mais informações PL-Dowiedz się więcej HU-Többet szeretnék tudni RO-Pentru mai multe detalii SK-Zistiť viac CS-Více informací SV-Ta reda på mer HR-Da biste saznali više SL-Več TR-Daha fazla bilgi LT-Daugiau informacijos SR-Saznati više LV-Uzzināt vairāk EL-Περισσότερες πληροφορίες BG-Научете повече KK-Қосымша апаратты аны үшін RU-Для более подробной информации UK-Дізнатися більше VI-Tìm hiểu thêm/Dể biết thêm ID-Untuk mengetahui lebih lanjut ZH-了解更多 JA-詳細 ZT-另更進一步了解 TH-ค้นหาข้อมูลเพิ่มเติม KO-더 알아보기 KM-ស្វែងរកព័ត៌មានបន្ថែម AR-المزيد من المعلومات

SUPPORTDECATHLON.COM

instructions to user:
For regulatory information, certification, and compliance marks specific to M1DKT, go to settings > more settings > about product name.

Pack Ref. 4554874

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ISED Radiation Exposure Statement:

This device complies with Innovation, Science and Economic Development Canada licence-exempt RSS standard (s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.
Le onjunc areil est conforme aux CNR d’ l’ innovation, la science et le d é veloppement é conomique Canada licables aux areils radio exempts de licence. L’ exploitation est autoris é e aux deux conditions suivantes:(1)l’ areil ne doit pas produire de brouillage, et
(2)l’ utilisateur de l’ appareil doit accepter tout brouillage radio é lectrique subi, onj si le brouillage est susceptible d’ en compromettre le fonctionnement.

This equipment complies with ISED RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
IC exposition aux radiations:
Cet é quipement est conforme avec ISED les limites d’exposition aux rayonnements d é finies pour un contról é environnement.
Cet é metteur ne doit pas é tre co-localis é s ou fonctionner en conjonction avec une autre antenne ou é metteur.