

TactGlove DK1 User Manual



TACTGLOVE

1. Product Overview



TACTGLOVE

- Main Control Case: You can turn on/off the TactGlove DK1 with the power button.
Blue Blinking: Bluetooth Pairing / Yellow Solid: Bluetooth Paired
- Built-in Battery: The battery is embedded in the wrist area.
- Embedded Vibration Motor: Each fingertip has a built-in vibration motor. Also, one vibration motor is embedded into the Main Control Case

2. Product Specification

Product Name	TactGlove DK1
Model Name	BHTG06D100
Size (M Size)	Length: 23.1cm, Width: 9.5cm, Height: 4.5cm
Weight (M Size)	110g
Operation Time	3.5 hours
Wireless Frequency	2.402 – 2.480 GHz (Bluetooth LE)
Connection Type	Bluetooth Low Energy (BLE)
Battery	Li-ion rechargeable battery (3.8V, 680mAh, 2.584Wh)
Charging Time	2 hours with 5V, 0.5A, 2.5W max

3. How to Play

You can control each vibration motor of TactGlove DK1 using a smartphone.

- 1) Turn on the Bluetooth function of a smartphone.
- 2) Download and install the bHaptics player application from Android/iOS store.
- 3) Press the power button of TactGlove DK1 and check the blue blinking
- 4) Run the bHaptics Player application, touch the menu button at the top left to connect TactGlove DK1
- 5) Touch the Test menu in the center of the bottom of the application
- 6) Turn on and off each motor of TactGlove DK1 by pressing the circular icon and adjust the vibration strength by controlling the slider at the bottom.
- 7) Long press the power button of TactGlove DK1 to turn off the power and disconnect the connection.

FCC Information to User

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution

Modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Compliance Information : This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation