


easyFeed User Guide

1. Buttons



1) Switch Wi-Fi Modes With WF Button

- When easyFeed is running, click the WF button will ask the device to enter “Airlink” mode. User will hear one “beep” immediately, and then a voice like “Wi-Fi is ready to pair your smart device” indicates the device enters “Airlink” mode successfully.
- Quick double click WF button will ask the easyFeed to enter “AP” mode. User will hear two “beep” immediately. This mode is used for Firmware updating. Users are not recommended to enter this mode without instructions.
- In Wi-Fi “AP” mode, double click WF button quickly will quit “AP” mode. EasyFeed can connect to Wi-Fi router only when it quits “AP” mode.

2) Calibration & Zero Cleaning of Weighing Sensor

- Long pressing WF button, user will hear one “Beep”. Meanwhile, zero cleaning of weighing sensor is completed. Please make sure the food holder and food tray are both empty before doing zero cleaning
- After zero cleaning, if no calibration is needed, click the WF button will make easyFeed return to

normal mode.

- Calibration of weighing sensor. Long pressing WF button, user can find the two LED displays showing "CALB" and twinkling for 1 minute. In one minute, user need to place 500g weights on both food holder and tray. Wait for 2-3 seconds, and then long pressing the WF button. Calibration will be done when user hears one beep and the new factors will show in two LED display. The function is used in factory assembly. Not recommended for user to do that.
- Calibration mode will quit automatically if user short click WF button or no action after 1 minute timeout.

3) Feed Button

- Long pressing the feed button with one "Beep", motor in easyFeed will run forward. And when user releases the button, motor will stop at once.
- Double click the feed button will show the current time in the upper LED display. To quit this mode, click the feed button again, the easyFeed will return to normal mode with three beeps. If user doesn't quit by manual, the easyFeed will return normal mode automatically after 1 minute timeout.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.