

Pedmate reserves rights of changes	Tips • Recovery Signal is easily interpreted in the following environment: • Corridor environment with multiple Wi-Fi signals and Bluetooth Signals. • Bright, sunny, sunny or rainy weather. • Are excluded: motor vehicles, Motor vehicle with the exhaust, a sound guarantee (one stable connection of the paired device is near the Left earbud). • Current current technology cannot guarantee synchronization of gaming and video playing. • Warning: use the microphones of the earpiece that is blocked by water, sweat, oil, etc., which will affect the device from working properly. • Warning: in rainy season, it is suggested to use a dry free cloth to clean the earphone or dry it by cool air.
---	--

EN



Press down to open the cover

In order to obtain a more stable and better experience, it is recommended to use mobile phones with Android 6.0, iOS 10.0 or higher OS versions.

How to power on and pair the earphones (step 1)

Power on:

Method 1: Take out the earphones from the stand, they will start up automatically and enter the pairing mode (make sure the stand is charged).

Method 2: Touch the button of the earphone to turn it on (the earphones must not be in the charging case and must be off).

An illustration of a person sitting at a desk, interacting with a stand. The stand has a circular base and a vertical column with a button on top. The person is reaching up to press the button. The stand is connected to a device on the desk.

Bluetooth On

Allow New Connections

New Bluetooth connections have been turned off from Control Center.

OF DEVICES

PHIA: Qum L

How to wear




Wearing manner for the left earplugs

Wearing manner for the right earplugs

In order to obtain better noise reduction effect, you can adjust the angle after wearing the earplugs, so that the earplugs fit snugly and firmly in your ears.

Choose the right earbuds



The diagram illustrates the selection of earbuds based on size. On the left, three earbuds are shown, labeled S (Small), M (Medium), and L (Large) from top to bottom. On the right, a person's head is shown in profile, wearing an earbud. A bracket indicates the earbud is positioned in the ear canal, with a label 'M' pointing to it, suggesting the medium size is the correct fit.

Earbuds with appropriate sizes are of great importance to the noise reduction experience, sound quality and comfort. Our earphones are equipped with S, M and L earbuds (M earbuds are installed on the earphones), please try on different sizes of earbuds and choose

How to use (Touch Button)

Touch Button	Touch Button
Play / Pause Click on the touch button Click on the touch button	Play / Pause Click on the touch button Click on the touch button
Incoming call Double click on the touch button	Incoming call Click on the touch button
Call rejection Double click on the touch button	Call rejection Double click on the touch button
Previous track Double click	Next track Double click
Call/Voice Assistant/SPE Press and hold	ANC mode switch Press and hold

Touch area

Left ear Right ear

Note: The function definition of Press and hold, double-click can be customized in APP

How to shut down and charge

About **3.5** hours
Battery life

About **3** times
Mobile charger



The telephone will automatically turn off and start charging when it is placed in the stand.

Diagram illustrating the components of the wireless charging system:

- Battery indicator:** Located on the top edge of the device.
- Wireless charging area:** The bottom edge of the device where it contacts the charging pad.
- Wireless charger:** The circular base used for charging the device.

FFC Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE:

Now, this equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .