

Smart Holster Sensor - Installation and Users Manual

Installing the Sensor

NOTE: Please charge sensor for 5 hours before installation

1. Shake primer tube for 10 seconds (once you hear ball rattle.)
2. Break internal tube by squeezing tube at mid-point.
3. Apply cleaner in area where sensor is to be applied.
4. Wait 5 minutes for the primer to dry.
5. Peel back protective liner from the adhesive pad located on bottom of sensor.
6. Place sensor to preferred location.
7. Apply pressure for 30 seconds to allow permanent bond to adhere correctly.

Pairing Sensor to BodyWorn Device

1. Place Smart Holster Sensor into pairing mode by connecting up to USB type C charging station.
2. Go to BodyWorn device and scan for device.
3. Pair device on BodyWorn

Support

Contact Information

Email : support@utility.com

Phone : 1.800.597.4707

Compliance Statement



Smart Holster Sensor

HS01

FCC ID: 2AJYJHS01 / IC: 27067-HS01

CAN ICES-3 (B)/NMB-3(B)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

"This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

(1) This device may not cause interference; and

(2) This device must accept any interference, including interference that may cause undesired operation of the device."

"Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes :

1) l'appareil ne doit pas produire de brouillage;

2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement."