

USER'S MANUAL

STZ

STZ-HS6490

Front panel:

1. Power Switch

2. Press the button for 1 sec to turn on the receiver and press it again to turn off.

3. Square control

4. Adjust the volume output of sound from body pack transmitter.

5. LED display

6. Displays the current frequency the unit is operating on.

Rear panel:

1. Antenna interface ANT 1

2. Antenna interface ANT 2

3. External power adapter socket (DC IN)

4. Audio output of the 6.3mm jack, symmetrical output (AF OUT UNBAL.)

5. Audio output of the XLR-3 jack, symmetrical output (AF OUT BAL.)

UHF Wireless Microphone

UHF Wireless Microphone

User's Manual

STZ-HS6490

Body-pack Microphone Receiver Installation:

1. Connect the antenna cable to the antenna connector.

2. Connect the antenna cable to the antenna connector.

3. Connect the antenna cable to the antenna connector.

4. Connect the antenna cable to the antenna connector.

5. Connect the antenna cable to the antenna connector.

6. Connect the antenna cable to the antenna connector.

7. Connect the antenna cable to the antenna connector.

8. Connect the antenna cable to the antenna connector.

9. Connect the antenna cable to the antenna connector.

10. Connect the antenna cable to the antenna connector.

Body-pack microphone use:

1. Switch on the body-pack microphone. The signal level on the control will light up to indicate the effective signal is received. Adjust the control volume to an adequate listening level on the system. The LED will light up gradually in correspondence with the increasing volume. This indicates the system is functioning normally.

2. Receiver must not come into contact with any liquid.

3. Before starting to use the equipment, please disconnect the device from the power.

4. Regularly clean the equipment with a soft cloth. Avoid using any solvents or cleaning products.

Single System setup

1. Place the receiver in a suitable location. Connect the antenna, connect the antenna cable to the appropriate connector and the power adapter provided with the unit. Connect the other end of the antenna cable to the input of the power or powered amplifier. Plug the antenna cable into the antenna connector. Connect the power supply to a wall socket. Switch on the receiver power, while it is ready to use, make use of the range of amplifying being used.

2. The receiver should be placed in a suitable location. Connect the antenna, connect the antenna cable to the appropriate connector and the power adapter provided with the unit. Connect the other end of the antenna cable to the input of the power or powered amplifier. Plug the antenna cable into the antenna connector. Connect the power supply to a wall socket. Switch on the receiver power, while it is ready to use, make use of the range of amplifying being used.

Battery installation

1. Please be careful of the battery position and negative direction.

2. Insert the battery into the battery slot.

3. Make sure the battery is inserted into the battery slot. Do not use other power sources that can damage the system.

4. The frequency control should be set to the frequency of the antenna. Do not use the antenna if the frequency is not set to the correct frequency.

5. Use the antenna if the frequency is not set to the correct frequency.

6. Use the antenna if the frequency is not set to the correct frequency.

7. Use the antenna if the frequency is not set to the correct frequency.

8. Use the antenna if the frequency is not set to the correct frequency.

9. Use the antenna if the frequency is not set to the correct frequency.

10. Use the antenna if the frequency is not set to the correct frequency.

UHF Wireless Microphone

User's Manual

STZ-HS6490

Cleaning and maintenance of the receiver

1. Liquid may penetrate into the enclosure and cause short circuit of the electronic device.

2. Before starting to use the equipment, please disconnect the device from the power.

3. Regularly clean the equipment with a soft cloth. Avoid using any solvents or cleaning products.

Plug configuration

1. 6.3mm Single Channel plug, unbalanced

2. XLR-3 plug, with hole, balanced

3. DC plug, used for power supply

Important safety tips

1. Please read the instruction manual carefully.

2. Please use the equipment in a safe and sound manner.

3. Please use the equipment in a safe and sound manner.

4. Please use the equipment in a safe and sound manner.

5. Please use the equipment in a safe and sound manner.

6. Please use the equipment in a safe and sound manner.

7. Please use the equipment in a safe and sound manner.

8. Please use the equipment in a safe and sound manner.

9. Please use the equipment in a safe and sound manner.

10. Please use the equipment in a safe and sound manner.

UHF Wireless Microphone

User's Manual

STZ-HS6490

Specification

1. Receiver

2. Receiver

3. Receiver

4. Receiver

5. Receiver

6. Receiver

7. Receiver

8. Receiver

9. Receiver

10. Receiver

Body-pack Microphone

1. Body-pack Microphone

2. Body-pack Microphone

3. Body-pack Microphone

4. Body-pack Microphone

5. Body-pack Microphone

6. Body-pack Microphone

7. Body-pack Microphone

8. Body-pack Microphone

9. Body-pack Microphone

10. Body-pack Microphone

FCC Warning:

1. FCC Warning

2. FCC Warning

3. FCC Warning

4. FCC Warning

5. FCC Warning

6. FCC Warning

7. FCC Warning

8. FCC Warning

9. FCC Warning

10. FCC Warning

MANUAL DEL USUARIO

STZ

STZ-HS6490

Panel frontal:

1. Interruptor de encendido

2. Presione el botón durante 1 segundo para encender el receptor, presione nuevamente para apagarlo

3. Control de volumen

4. Ajuste el volumen de salida de sonido que viene del receptor

5. Pantalla LED

6. Muestra la frecuencia actual en la que está operando la unidad.

Panel posterior:

1. Interfaz de antena ANT 1

2. Interfaz de antena ANT 2

3. Conector de alimentación de 6.3 mm (3/16")

4. Salida de audio con conector de 6.3 mm (3/16")

5. Salida de audio con conector XLR-3

Micrófono inalámbrico UHF

Micrófono inalámbrico UHF

Manual del Usuario

STZ-HS6490

Funciones del Micrófono de pértiga

1. Función de pértiga

2. Función de pértiga

3. Función de pértiga

4. Función de pértiga

5. Función de pértiga

6. Función de pértiga

7. Función de pértiga

8. Función de pértiga

9. Función de pértiga

10. Función de pértiga

Configuración de un sistema individual

1. Configuración de un sistema individual

2. Configuración de un sistema individual

3. Configuración de un sistema individual

4. Configuración de un sistema individual

5. Configuración de un sistema individual

6. Configuración de un sistema individual

7. Configuración de un sistema individual

8. Configuración de un sistema individual

9. Configuración de un sistema individual

10. Configuración de un sistema individual

Uso del micrófono de pértiga ("bodypack")

1. Uso del micrófono de pértiga ("bodypack")

2. Uso del micrófono de pértiga ("bodypack")

3. Uso del micrófono de pértiga ("bodypack")

4. Uso del micrófono de pértiga ("bodypack")

5. Uso del micrófono de pértiga ("bodypack")

6. Uso del micrófono de pértiga ("bodypack")

7. Uso del micrófono de pértiga ("bodypack")

8. Uso del micrófono de pértiga ("bodypack")

9. Uso del micrófono de pértiga ("bodypack")

10. Uso del micrófono de pértiga ("bodypack")

Configuración de múltiples sistemas

1. Configuración de múltiples sistemas

2. Configuración de múltiples sistemas

3. Configuración de múltiples sistemas

4. Configuración de múltiples sistemas

5. Configuración de múltiples sistemas

6. Configuración de múltiples sistemas

7. Configuración de múltiples sistemas

8. Configuración de múltiples sistemas

9. Configuración de múltiples sistemas

10. Configuración de múltiples sistemas

Micrófono inalámbrico UHF

Manual del Usuario

STZ-HS6490

Limpieza y mantenimiento del receptor

1. Limpieza y mantenimiento del receptor

2. Limpieza y mantenimiento del receptor

3. Limpieza y mantenimiento del receptor

4. Limpieza y mantenimiento del receptor

5. Limpieza y mantenimiento del receptor

6. Limpieza y mantenimiento del receptor

7. Limpieza y mantenimiento del receptor

8. Limpieza y mantenimiento del receptor

9. Limpieza y mantenimiento del receptor

10. Limpieza y mantenimiento del receptor

Configuración de conectores

1. Configuración de conectores

2. Configuración de conectores

3. Configuración de conectores

4. Configuración de conectores

5. Configuración de conectores

6. Configuración de conectores

7. Configuración de conectores

8. Configuración de conectores

9. Configuración de conectores

10. Configuración de conectores

Consejos de seguridad importantes

1. Consejos de seguridad importantes

2. Consejos de seguridad importantes

3. Consejos de seguridad importantes

4. Consejos de seguridad importantes

5. Consejos de seguridad importantes

6. Consejos de seguridad importantes

7. Consejos de seguridad importantes

8. Consejos de seguridad importantes

9. Consejos de seguridad importantes

10. Consejos de seguridad importantes

En el funcionamiento multicanal del dispositivo

1. En el funcionamiento multicanal del dispositivo

2. En el funcionamiento multicanal del dispositivo

3. En el funcionamiento multicanal del dispositivo

4. En el funcionamiento multicanal del dispositivo

5. En el funcionamiento multicanal del dispositivo

6. En el funcionamiento multicanal del dispositivo

7. En el funcionamiento multicanal del dispositivo

8. En el funcionamiento multicanal del dispositivo

9. En el funcionamiento multicanal del dispositivo

10. En el funcionamiento multicanal del dispositivo

Micrófono inalámbrico UHF

Manual del Usuario

STZ-HS6490

Especificaciones

1. Especificaciones

2. Especificaciones

3. Especificaciones

4. Especificaciones

5. Especificaciones

6. Especificaciones

7. Especificaciones

8. Especificaciones

9. Especificaciones

10. Especificaciones

MICROFONO DE PÉRTIGA (BODYPACK)

1. MICROFONO DE PÉRTIGA (BODYPACK)

2. MICROFONO DE PÉRTIGA (BODYPACK)

3. MICROFONO DE PÉRTIGA (BODYPACK)

4. MICROFONO DE PÉRTIGA (BODYPACK)

5. MICROFONO DE PÉRTIGA (BODYPACK)

6. MICROFONO DE PÉRTIGA (BODYPACK)

7. MICROFONO DE PÉRTIGA (BODYPACK)

8. MICROFONO DE PÉRTIGA (BODYPACK)

9. MICROFONO DE PÉRTIGA (BODYPACK)

10. MICROFONO DE PÉRTIGA (BODYPACK)

Especificaciones generales

1. Especificaciones generales

2. Especificaciones generales

3. Especificaciones generales

4. Especificaciones generales

5. Especificaciones generales

6. Especificaciones generales

7. Especificaciones generales

8. Especificaciones generales

9. Especificaciones generales

10. Especificaciones generales