

USER MANUAL

USER MANUAL

T-TRACK BRAIN
+
T-TRACK TAG

T-Track
by **TOTTO**

T-Track tag

Please pull and remove the tape to activate the T-Track tag. Battery is installed but not in contact. The T-Track tag is ready for the connection to T-Track app.

T-Track app connection

- Open the T-Track app in your mobile device
- Select "Connect to T-Track"
- Select the T-Track device that appears on the screen
- Select "Connect"

For more information please use the T-Track App.

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

T-Track notifies you via vibrating alert if you've forgotten or are missing something from your backpack. Attach T-Track tag to everything from laptops to headphones the possibilities are endless! With an integrated lock, discreet pockets, and a sleek, water resistant design, T-Track is the backpack of the future with 20 killer features.

Thank you for purchasing T-Track by TOTTO. For optimum performance and safety, please read these instructions carefully before operating the product. Please keep this manual for future reference.

This product comes with a 3 month warranty. Our product warranty is limited to the unit itself, under normal use in accordance with the operating instructions and the system environment.

The T-Track tag connection

- Open the T-Track app in your mobile device
- Select "Add a T-Track tag"
- Scan the QR on the back of your T-Track tag
- Name the new T-Track tag
- Select "Add"

For more information please use the T-Track App.

Charging T-Track brain


Estimated time for full charge: TBD

1. Connect the Micro USB tip to the power bank's input port.
2. Connect the other tip of the Micro USB to an open USB port or to a standard Wall charger with output DC 5V/1.5 A max.
3. While the Power Bank is charging, the red LED will light solid, once it is fully charged the red LED will go off.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Description



1. Red Led.
2. Blue Led.
3. Button 1.
4. Button 2.

4. Disconnect the Micro USB cable from the port and the brain.

Replacing the T-Track tag battery

1. Turn the battery cover of your T-Track tag to the left.
2. Lift the battery cover of your T-Track tag.
3. Remove the worn out battery.
4. Insert a new battery.
5. Replace the battery cover and turn clockwise.


Attention

Please read these safety warnings carefully to guarantee your personal safety and prevent damages.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Radiation Exposure Statement: The product complies with the FCC portable RF exposure limit set forth for an uncontrolled environment and are safe for intended operation as described in this manual.



Caution

- Clean the T-Track devices only with a soft dry cloth.
- Do not expose your T-Track devices to liquid, moisture, humidity or rain.
- Do not use the T-Track devices near a bathtub, sink, sauna, pool or steamroom.
- Exposure of the T-Track devices to moisture could result in electric shock.
- Do not drop, disassemble, open, crush, bend, deform, puncture, shred, microwave, incinerate, paint, or insert foreign objects into the T-Track devices.
- Do not insert anything into your T-Track devices unless otherwise specified in the user instructions.
- This may damage internal components.
- Do not attempt to repair, modify or disassemble your T-Track devices yourself, it does not contain any user serviceable components. Such actions could result in electric shock.
- Do not expose your T-Track devices to extremely high or low temperatures.

The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available.


FCC

T-Track Brain FCC ID: 2AM6Y-063IND076
T-Track tag FCC ID: 2AM6Y-063IND077

The FCC label is a certification mark employed on electronic products manufactured or sold in the United States which certifies that the electromagnetic interference from the device is under limits approved by the Federal Communications Commission.

What's in the box?

- T-Track Backpack
- T-Track Brain
- T-Track tag x2
- USB cable
- User manual



Specifications

- **T-Track Brain**
Model number: AC063IND076-1720Z-N01
 - Capacity: 900 mAh
 - Input: DC 5V 1.5A (MAX)
 - Battery type: Rechargeable Lithium Polymer
- **T-Track Tag**
Model number: AC063IND077-1720Z-N01
 - Coin Cell replaceable battery CR2032 DC3V

Power on

T-Track Brain

Press the button #1 for 5 seconds, then blue LED blinking. The device will be ready for connection with T-Track app and T-Track tag.

- Observe all signs and displays that require an electrical device or RF radio product to be switched on in designated areas.
- Turn off your T-Track devices prior to boarding and aircraft. Do not use the T-Track devices inside an aircraft unless allowed by your airline.

The crossed-out bin symbol means that the product must be disposed of separately. This product must not be disposed of with unsorted household waste.



Some of the materials used can be recycled.

Nalsani, S.A.S.
ttrack@totto.com

Colombia:
(+571) 01 8000 51 02 03
USA:
1-844-99-TOTTO (86886)

Carrera 43 a # 20c 55
Bogotá - Colombia

us.totto.com

totto.com



Restriction of the use of Hazardous Substances (The materials used don't pose a health risk)



The product satisfies legislation set out by the European Union, essentially meeting a basic level of quality.

Caution risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.