


User Manual

Thank you for using this Smart watch!

Product Manual contains the product feature,using and operating procedures,please read carefully in order to achieve the best results and prevent unnecessary damage.Do not arbitrarily change the products ,accessories and disassemble and leads beyond warranty. Package contents:Smart watch,wireless charger,the product manual.

The watch Describe



Remarks:
The charger body must be aligned with the watch.
Please charge 2 hours before the first use smart watch.

First, the user's mobile phone Bluetooth notification software installation
Watch the boot, two-dimensional code found inside the wristwatch main menu, click on the go. With Android 4.0+ smartphones or iOS smart phone. Scan two-dimensional code using QQ or browser. Download Bluetooth notify APP software. And install the software in the phone.


1-1, install mobile terminal APP, shown in Figure



Android mobile phone users, select "splitter wear Dai Anzhuo Edition"; ios users select splitter Wear Apple version, download and

Second, the Bluetooth pairing connection
A, connected Android phone.

1, long press the power button to power the watch, the dial interface, slide down the screen to enter the shortcut sector Surface, touch the icon to open the Bluetooth.



Watches side pairing Bluetooth

Pairing a Bluetooth mobile phone side

2, open the Bluetooth mobile phone side, the side of the Bluetooth watch search inside click on "search for Bluetooth devices" (shown above), and connect. Or search for Bluetooth watch phone side, and connect.
3, the mobile phone side open the Bluetooth notification, select Sync you need to set one by one, as columns: Click the Sync settings, you can set the text according to your desired settings, contacts, call history, calendar, and other information with your phone sync , set a good feature to watch all the synchronized push notification center


Wear synchronize watches splitter end operating methods:
Android phone users



click

click

Apple phone user must first log register



Click on the "Start Search"



Click on N6



Click applications Recommended




Click on personal APP

Data is synchronized to the mobile terminal



Click to synchronize data

Click Sync Now



As the left click on motion Watch the data can be synchronized to the phone side. The sleep monitoring date does not support synchronous.

Tips: Due to the different users of the phone settings are different, the first end connected to the watch may not connect. When this occurs, please turn off the Bluetooth mobile phone back on, or reboot the watch off.

Three shortcut menu operation guidelines

1, Dial interface

2, Personalized Dial

In the dial screen will appear the following interface touch screen. After 2 seconds, the screen will slide to the left following ,three kinds of personality dial for you to choose. When you have confirmed a good selection dial, the finger off the screen for about three seconds, this mark disappears, the dial begin to take effect.

3, Notification Center

In dial interface, slide the screen to the right, into Notification Center, you can view various types of information smartphone push. Note: This feature requires the watch and smart phones can be used after binding.

4, Fast interface

In dial interface, slide down the screen and enter the standby interface. Press the lower left corner of the icon to access the main menu, press te lower right corner of the icon to enter the tool icon. The left is dial-up interface, the right is access to the information.

Fourth, the basic functions of the main menu, operating instructions

1, Phonebook

Touch the phone book icon to view the phone book records and phone synchronized. Note: This feature requires the watch and smart phones can be used after binding.

2, Dials

Touch the dial icon when a Bluetooth audio connection can make calls.

3, call records

Touch the Call log icon to view sync with the phone call records. Note: This feature requires the watch and smart phones can be used after binding.

4, Information

Touch the information icon to view the recorded phone message was synchronized. This feature requires the watch and smart phones can be used after binding.

5, Notice

Touch remote notification icon, the Bluetooth watch phone connected to the premise, the phone installed Bluetooth notification. Smart phone can achieve all kinds of push messages.

6, the search appliance

Under the premise of open Bluetooth, you can search for other Bluetooth devices.

7, Alarm

When you need to time it will remind you to, touch the screen, you can set the time, ring tones and other functions.

8, Calendar

Show sun and the moon, the lunar calendar, week, etc.

9, Bluetooth music

Remote control mobile music.

10, The remote camera

Touch the remote camera icon, you can use the watch to control the mobile phone camera, watch this time is displayed on the phone's main camera viewfinder screen, allowing you to self-timer or remote control. Note that this time the phone must be unlocked screen state. Apple phone into the camera interface.

11, Bluetooth

Tap the Bluetooth icon, you can activate and deactivate Bluetooth, modify Bluetooth names.

12, File Manager

Touch the File Manager icon to watch the relevant documentation.

13, Pedometer

Touch the icon to enter the settings interface pedometer, click Start counting steps can be carried out.

14, PSG

The sleep monitoring date does not support synchronous

15, Sedentary remind

Touch sedentary alert icon, can be inside the set.

16, Siri (Baidu voice)

1, the smart phone side [does not support the Apple phone] use by third-party applications or QQ sweep sweep sweep scan watch end built-in two-dimensional code, will link a few applications package automatically, click the corresponding Bluetooth notification package and Baidu voice installation package to download and install to your phone.

17, Two-dimensional code

Touch the icon two-dimensional code, after entering. QQ browser for mobile phones or two-dimensional code scanning. Download Bluetooth notification. After connecting Bluetooth, you can synchronize the time, phonebook synchronization, information synchronization. Also information, micro-channel information such notification.

18, stopwatch

The number of seconds to record a plurality of time points. Simple, easy to use. Pedometer

19, calculator

20, topics

You can set a variety of background color

21 Set

Bluetooth can be set up, time, sound (incoming call alert type, ring tones, and ring size and other settings), volume size, display (menu style, screen brightness, backlight time), actions (gestures wakeup function setting), language restore factory settings operation.

22, Heartrate

You can record the number of beats per minute.

FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Smart Life