

Product Installation · Installation du produit · Installazione del prodotto · Produktinstallation · Instalación del producto

Flush

! Ensure car temperature is **above 65 °F** before installing for best results.

! Assurez-vous que la température interne de la voiture soit supérieure à 65°F pour de meilleurs résultats.

! Assicurarsi che la temperatura interna dell'auto sia superiore a 65°F per ottenere i migliori risultati.

! Stellen Sie sicher, dass die Innentemperatur des Autos über 65°F liegt, für beste Ergebnisse.

! Asegúrese de que la temperatura interna del coche esté por encima de 65°F para obtener mejores resultados.

1



Choose a mounting location and wipe the surface clean.


Choisir un emplacement pour le montage puis essuyer la surface pour la rendre propre.

Scegliere dove posizionare la montatura, e pulire bene l'area.

Wählen Sie einen Befestigungsort und wischen Sie die Oberfläche sauber.

Elija un espacio de montaje y limpie la superficie.

2



Connect the cradle to the flush mount and tighten the cradle knob.


Connectez le berceau au support encastré et serrez le bouton du berceau.

Collegare la base al supporto della montatura e serrare la manopola della base.

Verbinden Sie die Halterung mit der Flachbefestigung und ziehen Sie den Halterungsknopf an.

Conecte la base al soporte de la montura empotrada y apriete la perilla de la base.

3



Peel off film and press evenly for 30 seconds.

Retirer le film et presser fermement pendant 30 secondes.

Staccare la pellicola e premere uniformemente per 30 secondi.

Ziehen Sie die Folie und drücken 30 Sekunden lang fest.

Quite la lámina protectora y presione firmemente por 30 segundos.

4



To change the viewing angle, loosen the cradle knob and adjust the mount to your desired position. Tighten to secure it in place.

Pour faire pivoter le support, desserrez la vis de support. Serrez pour verrouiller dans la position désirée.

Per ruotare la base, allentare la manopola della base. Serrare per bloccare nella posizione desiderata.

Um die Wiege zu drehen, lösen Sie den Wiesenknopf. Anziehen, um in der gewünschten Position zu arretieren.

Para girar la horquilla, afloja la perilla de la horquilla. Apriete para bloquear en la posición deseada.

5



Wait more than 20 minutes before mounting your phone for a secure hold.

Attendez plus de 20 minutes avant de monter votre téléphone pour un maintien sûr.

Attendi più di 20 minuti prima di montare il telefono per una presa sicura.

Warten Sie mehr als 20 Minuten, bevor Sie Ihr Telefon anbringen, um einen sicheren Halt zu gewährleisten.

Espere más de 20 minutos antes de montar su teléfono para una sujeción segura.

Scan QR code




Scan QR code for full manual & product registration

<http://www.iottie.com/qr-code?sku=ITMNCG000>

Quick Start Guide

Velox Mini Qi2 Magnetic Wireless
Air Vent and Flush Mount




iottie

Product Installation

Installation du produit · Installazione del prodotto ·
Produktinstallation · Instalación del producto

Air Vent

1



Connect the cradle to the vent mount and tighten the cradle knob.

Connectez le berceau au support de ventilation et serrez le bouton du berceau.


Collegare la base al supporto della presa d'aria e serrare la manopola della base.

Verbinden Sie die Halterung mit der Lüftungshalterung und ziehen Sie den Halterungsknopf an.

Conecte la base al soporte de ventilación y apriete la perilla de la base.

EN Only compatible with Qi2-enabled devices and MagSafe series iPhones and cases. **FR** Uniquement compatible avec les appareils compatibles Qi2 et les iPhones et étuis de la série MagSafe. **IT** Compatibile solo con dispositivi abilitati Qi2 e iPhone e custodie della serie MagSafe. **DE** Nur kompatibel mit Qi2-zfähigen Geräten und iPhones und Hüllen der MagSafe-Serie. **ES** Solo compatible con dispositivos habilitados para Qi2 y iPhones y fundas de la serie MagSafe.

2



Rotate the dial counterclockwise to extend the hook. If installing on a vertical air vent, rotate the hook so it is facing sideways.


Tournez le cadran dans le sens anti-horaire pour déployer le crochet. En cas d'installation sur une bouche d'aération verticale, tourner le crochet pour qu'il soit orienté vers le côté.

Ruotare il quadrante in senso antiorario per estendere il gancio. Se si installa su una presa d'aria verticale, ruotare il gancio in modo che sia rivolto lateralmente.

Drehen Sie das Rad gegen den Uhrzeigersinn, um den Haken herauszuziehen. Wenn die Installation an einer vertikalen Lüftungsöffnung erfolgt, müssen Sie den Haken so drehen, dass er zur Seite gerichtet ist.

Gire el dial en sentido antihorario para extender el gancho. Si se instala sobre una ventilación de aire vertical, gire el gancho para que quede orientado hacia los lados.

3



Insert the hook onto the air vent and secure the mount in place by rotating the dial clockwise until the mount sits flush against the vent.


Insérez le crochet dans la bouche d'aération et fixez le support en tournant le cadran dans le sens horaire jusqu'à ce que le support soit aligné avec la bouche d'aération.

Inserire il gancio sulla presa d'aria e fissare in posizione il supporto ruotando il quadrante in senso orario finché il supporto non sia posizionato a filo della presa.

Bringen Sie den Haken an der Lüftungsöffnung an und befestigen Sie die Halterung, indem Sie das Rad im Uhrzeigersinn drehen, bis die Halterung fest an der Lüftungsöffnung anliegt.

Inserte el gancho en la ventilación de aire y sujete la montura en su lugar girando el dial en sentido horario hasta que la montura quede a ras contra la ventilación.

4



To change the viewing angle, loosen the cradle knob and adjust the mount to your desired position. Tighten to secure it in place.


Pour faire pivoter le support, desserrez la vis de support. Serrez pour verrouiller dans la position désirée.

Per ruotare la base, allentare la manopola della base. Serrare per bloccare nella posizione desiderata.

Um die Wiege zu drehen, lösen Sie den Wiesenknopf. Anziehen, um in der gewünschten Position zu arretieren.

Para girar la horquilla, afloja la perilla de la horquilla. Apriete para bloquear en la posición deseada.

5



Connect the USB-C cable to your vehicle's USB-C port or auxiliary power outlet via a 10W adapter (not included).


Connectez le câble USB-C au port USB-C de votre véhicule ou à la prise d'alimentation auxiliaire via un chargeur de voiture (non inclus).

Collega il cavo USB-C alla porta USB-C del tuo veicolo o alla presa di alimentazione ausiliaria tramite un caricabatteria per auto (non incluso).

Verbinden Sie das USB-C-Kabel über ein Autoladegerät (nicht im Lieferumfang enthalten) mit dem USB-C-Anschluss oder der Zusatzsteckdose Ihres Fahrzeugs.

Conecte el cable USB-C al puerto USB-C de su vehículo o toma de corriente auxiliar a través de un cargador de automóvil (no incluye).

6



Tap your phone against the mount face. Charging will begin automatically.

Tapez votre téléphone contre la face du support de téléphone. Le chargement démarre automatiquement.

Avvicina il tuo telefono alla superficie del supporto. La ricarica comincerà automaticamente.

Tippen Sie Ihr Telefon gegen die Oberfläche der Halterung. Das kabellose Laden beginnt automatisch.

Coloque su teléfono contra la cara del soporte. La carga inalámbrica comenzará de forma automática.

Declaration of Conformity (FCC)

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. You can refer to the following completed FCC warnings.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference.
- 2) This device must accept any interference received, including interference that may cause undesired operation.

Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 15cm between the radiator & your body.

IC warning statements:

-English Warning Statement:

RSS-GEN ISSUE 5, 8.4 User manual notice

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).

-French Warning Statement:

RSS - Gen version 5, 8.4 avis du manuel de l'utilisateur

Cet appareil contient un émetteur / récepteur sans licence conforme au RSS sans licence d'innovation, science et développement économique Canada. L'opération doit satisfaire aux deux conditions suivantes:

Cet équipement peut ne pas causer d'interférence.

L'équipement doit accepter toute interférence, y compris toute interférence qui pourrait entraîner un fonctionnement indésirable de l'équipement.

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment and meets RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment has very low levels of RF energy that are deemed to comply without testing of specific absorption ratio (SAR).

Cet équipement est conforme aux limites d'exposition aux rayonnements énoncées pour un environnement non contrôlé et respecte les règles d'exposition aux fréquences radioélectriques (RF) CNR-102 de l'IC. Cet équipement émet une énergie RF très faible qui est considérée conforme sans évaluation du débit d'absorption spécifique (DAS).

This equipment should be installed and operated with minimum distance 0cm between the radiator & your body.

Lors de l'installation et du fonctionnement de cet équipement, la distance minimale entre le radiateur et le corps doit être de 0 cm.



Follow @iottie for the latest news and updates!

Please visit our website for more information.

www.iottie.com

iottie

HELLO!

Thank you for your purchase.

Take 15% Off

Your next order at
iottie.com with code:

THANKYOU15



If you're happy with your purchase,
please leave us a review on Amazon!



If you are unsatisfied for any reason,
please reach out to our support team
at cs@iottie.com

Rethinking Packaging



**100% recyclable and
plastic-free**



Reduced packaging size



Printed with soy ink

Learn more at iottie.com/about-us/sustainability