


SMART EYEWEAR

T06

SMART GLASSES  
User Guide



Instruction

Please read the manual before using it. The manual may change due to hardware or software updates.  
Smart Eyewear with open directional audio, this product is a Bluetooth eyewear with stereo super mini speakers, easy to operate and carry.

Parameter

|                  |                               |
|------------------|-------------------------------|
| Frame material   | TR 90                         |
| Lens material    | TAC polarized sunglasses lens |
| Bluetooth        | 5.3                           |
| Charging time    | 3 hours                       |
| Play time        | 10 hours*                     |
| Batery capacity  | 130mAh                        |
| Charging voltage | DC5V                          |
| Speakers         | Dual stereo speakers          |

\*10 hours at 80% volume, play music.


●Compatible with mainstream brands of mobile phones, tablets and other Bluetooth devices.

- Support AAC audio decoding technology, achieve CD-level sound quality.
- Left and right speakers, the audio is directed all around you to give a high-quality stereo sound effect.

Packing list

- Smart Eyewear \*1
- Charging cable \*1
- Cleaning cloth \*1
- User manual \*1
- Gift Box \*1

Operations



Power on/off

- 1) Turn on the device: when it is off, press the button for 3 seconds to turn it on. When you hear 'Power on' , the device turns on, and then you can connect.
- 2) Turn off the device: plug in the charger, the device will switch off automatically, when the device is on, long press the button for 3 seconds to turn off.  
By hearing 'Power off' and a beep sound, the device is now off.
- 3) Turn off automatically: the device will be turned off automatically as soon as bluetooth disconnected for more than 3 minutes.

Bluetooth connect

Turn the device on

- 1) First connection: click 'setting' and turn on Bluetooth on your mobile phone or smart device, search for Bluetooth name 'iSTAR T06' , and click to connect.
- 2) Second connection: when you turn on your smart eyewear, it will automatically connect to your last connected mobile phone or smart device.

Music funtion

- 1) Single press the button to play or pause.
- 2) Double press button to switch to the next song.

Call funtion

- 1) Single press button to answer and press again to hang up.
- 2) Double press button to reject call when the call comes.
- 3) Thrice press button to activate voice assitant.

Charging

- 1) Low Battery alarm, will hear indicating tone 'low battery' twice.
- 2) When the device runs out of power, it will power off automatically.
- 3) When charging, the indicator is always red, when fully charged the indicator is always blue.


Attention

- 1) For the first time use charge fully charge the product.
- 2) If the product is not charged for a long time (more than 2 weeks), please fully charge before use.
- 3) Use the cleaning cloth provided inside the pouch to dean the lens. Other cloths may damage the lens.
- 4) When battery temperature exceeds -10°C - 45°C, the product will automatically shut down.

Notice

- 1) Do not disassemble and repair the product for any reason, otherwise it might cause fire, electronic breakdown, or even complete damage to the product.
- 2) Do not put the equipment in an environment with too low or too high temperature (below -10°C or above -45°C).
- 3) Do not put the product under water or other liquid or humid environment.

Important safety information



- Before using the device, please read all the safety information to ensure correct and safe use.
- Use of power supply, chargers or batteries not certified by the manufacturer may cause fire and other hazards.
- Please use the accessories approved by the manufacturer and compatible with the type of device.
- Please use the equipment within the temperature range of 0-45°C and store the equipment and accessories within the temperature range of -10°C-45°C. When the temperature is too high or too low, it may cause equipment failure.
- The device uses a non-removable built-in battery, and does not replace the battery to avoid damage.
- After full charge disconnect the charger from the device and unplug charger from power source. Do not charge for more than 12 hours.
- Do not disassemble the battery, or bump, squeeze or put the battery into fire. If serious expansion occurs, please do not continue to use it.
- Please keep it in a dry place.
- Do not repair the product by yourself when it is not working properly.
- When connecting other devices, please refer to the user manual for the connection method, do not purposely connect to equipment that does not match.

WARNING



- 1) Please follow the relevant laws and regulations. Do not use in the mentioned environment below:  
For example, gas stations, oil warehouses and other places where inflammable and explosive oil, gas or chemicals are stored.
- 2) Do not listen at high volume for long periods of time to prevent hearing damage.

- Do not use the equipment in the operating room, emergency room, intensive care department.
- In order to avoid interference with the medical devices, please keep the device away from the pacemaker, a distance of at least 15 meters.
- If there is a need to use the device near a personal medical device, consult a physician and device seller.
- Do not use outside in thunderstorms to avoid lightning strikes.
- Do not use the charger in the bathroom where there is high humidity, this may lead to electric shock, personal injury, fire, and damage to charger.
- Please comply with the relevant laws that clearly prohibit use in any environment.

FCCCaution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-Reorient or relocate the receiving antenna.  
-Increase the separation between the equipment and receiver.  
-Connect the equipment into an outlet on a circuit different from that to which thereceiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The devicecan be used in portable exposure condition without restriction.