

Smart Watch User Manual



Welcome to use our high-performance wrist-band smart bracelet which creates thoughtful and health experience for you.

Device maintenance

Please remember the following tips when you maintain your smart bracelet:


- Clean the smart bracelet regularly, especially its inner side, and keep it dry.
- Adjust the smart bracelet tightness to ensure air circulation.
- Excessive skincare product should not be used for the wrist wearing the smart bracelet.
- Please cease wearing the smart bracelet in case of skin allergy or any discomfort.

Schematic diagram of main body of the smart bracelet



Power-on

Long press the side button for 3 seconds or plug in the Magnetic charging cable to charge the smart bracelet.



Downloading and binding of smart bracelet APP

1.Download and install APP
Scan QR code with mobile phone to download APP.


For IOS system, select APP , storesearch Da Fit
Android system, select Google Play to download and install Da Fit.Or scan QR code to download




Note: your mobile phone must support Android 5.1 or IOS 8.0 or above, and Bluetooth 4.0 or above.

Bind smart bracelet with APP

1.Click on "Add Device" to bind the smart bracelet.
2. Click on your device in the device list scanned.



3.The IOS system will show a Bluetooth pairing request and you can click on Bluetooth "Pairing" to confirm. Connect it directly to Android system.
4. Successfully bound.



Introduction of smart bracelet functions


Power-on status
switch the menu interfaces of main screen, as the interfaces shown in the following;



Remove Device

For the Android mobile phone, the device can be disconnected from your mobile phone by simply clicking on Remove device.

For Apple mobile phone after binding removal, you need to click on the symbol on the right in Setting- Bluetooth, and choose to ignore the device. As shown below:



Frequently Asked Questions (FAQs)

1. Why does the smart bracelet automatically disconnect Bluetooth when the Android screen goes out?

1> Lock background APP. When the Da Fit process is cleared, the smart bracelet will be disconnected from the mobile phone.
2 > Set APP self-startup
3 > Unrestricted background operation. The Android mobile phone installed with APP intelligently restricts the background operation by default, and App should be set manually without any restriction.

2. Why cannot the smart bracelet receive message push?

1> Please confirm that you have turned on the switch for message push at the mobile phone client.
2 > Please confirm that messages can be displayed normally in the mobile phone notification bar. The message push on the smart bracelet is completed by reading the message from the mobile phone notification bar. The smart bracelet will not receive the message push if there is no message in the mobile phone notification bar. (You need to find notification settings in the mobile phone settings, and turn on the notification switch of WeChat, QQ, call, SMS and mobile phone client).
3 > Turn on the mobile phone --- Settings. Enter "Notification use right" on the top search box, re-open Da Fit.

3. Why can't take a hot bath with the smart bracelet?

Answer: the bath water has a relatively high temperature, and generates a lot of vapor which is in the gas phase with small molecular radius and can easily infiltrate into the smart bracelet from the shell gap. When the temperature drops down, the vapor will condensate into liquid-phase droplets which will easily cause the short circuit inside the smart bracelet and damage the circuit board and then damage the smart bracelet.

Warning:

Please consult your doctor before you take a new sport. The smart bracelet should not be used for any medical purpose though it may dynamically monitor the heart rate at real time.

智能手表用户手册



欢迎使用智能手环，高性能腕带智能手环为您打造贴心健身体验。

设备保养

在保养您的手表时，请记住以下提示：


- 定期清洁手表，特别是手表内侧，使其保持干爽。
- 调整手表松紧度，确保空气流通。
- 佩戴手表的手腕不宜使用过量护肤品。
- 如出现皮肤过敏或不适情况，请停止佩戴。

手表主机示意图



开机

长按侧键3秒或插上磁吸充电线充电开机。



手表APP下载及绑定

1.下载安装APP

一、使用手机扫描二维码，下载APP

二、 IOS系统选择 App store,搜索下载 Da Fit
Android系统可选择应用宝来下载安装Da Fit，或者扫描二维码下载。




注意：手机须支持安卓5.1 或 IOS 8.0系统以上， 蓝牙4.0版本以上。

APP绑定手表

1.点击“添加设备”绑定手表。
2.在扫描到的设备列表点击你的设备。



3.IOS系统会出现蓝牙配对请求，点击蓝牙“配对”确认即可。Android系统直接连接。
4.绑定成功



手环功能简介

开机状态：

主屏菜单界面切换，如下所示的界面等；



解除绑定

安卓手机只需点击移除设备，即可与手机断开。

苹果手机解除绑定后， 还需要在设置---蓝牙，点击右边的符号，选择忽略此设备。如下图



常见问题

1.安卓手机屏幕熄灭后，手环为什么会自动断开蓝牙连接？

1> 锁定后台APP。Da Fit进程清除后，会导致手环与手机断开。
2>设置APP自启动。
3>后台运行无限制。安卓手机安装APP，默认是智能限制后台运行，需手动设置APP不采取任何限制措施。

2.为什么手环接收不到消息推送？

1> 确认在手机客户端开启了消息推送的开关。
2> 确认消息在手机通知栏都可以正常显示,手环消息推送是通过读取手机通知栏消息进行推送,若手机通知栏没有消息显示,手环将无法接收推送。(需要在手机设置中找到通知设置,开启微信、QQ、电话、短信、手机客户端的通知开关)。
3 >打开手机---设置，最上面的搜索框，输入“通知使用权”，重新打开Da Fit。

3.为什么不能佩戴手环洗热水澡？

答：洗澡水的温度比较高,会产生很多的水蒸气,而且水蒸气是气相的,其分子半径小,容易从手环的壳体空隙渗进去,当温度降下来后又会重新凝结成液相的水滴,容易造成手环内部线路短路,损伤手环电路板,进而损坏手环。

警告:

新的运动项目之前请咨询你的医生，智能手环尽管可以监测实时动态心率，但不能用作任何医疗用途。

Federal Communications Commission (FCC) Statement. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received,

including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide Reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by **Shenzhen**

Yawell intelligent Technology Co., Ltd may void the FCC authorization to operate this

device. Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF exposure statement:

The device complies RF exposure requirement and can be installed and used without restriction