

说明书尺寸: 80x60mm
材质: 128G铜版纸
折页

80 mm

60 mm

Bluetooth Speaker Sleep Aid Machine

H3



1. Product Description

The H3 Bluetooth speaker sleep aid machine transmits audio signals through Bluetooth wireless transmission technology, and using Bluetooth version 5.3 which is the latest Bluetooth communication standard in the design. It is compatible with the lower version of Bluetooth communication standards, and the performance in all aspects has been further improved to a higher level. It is not only a Bluetooth speaker but also a sleep aid machine, with a variety of natural sound effects, music player timer, compact and portable, allowing you to enjoy a better life!

2. Product Parameter

- Item NO.H3
- Speaker battery: 300mah
- Effective distance: 10 meters
- Key type: key/button
- Speaker horn specifications: 40/3W external magnets
- Speaker charging time: 1-2 hours
- Speaker working time: 2-3 hours
- Sleep aid machine music playtime: 3-4 hours
- Standby time: more than 180 days
- Input voltage: DC 5V
- Charging current: 300mA

- Bluetooth version: 5.3
- Working temperature: 0 ~ 45 °C
- Charging method: Type-C

Product Diagram

Turn left volume -

Turn Off

Turn right volume +

Turn On

Mode key

Timer Button

Timer Indicator Light

Rotary potentiometer button

Headphone plug hole

Type-C

Non-slip pad

55mm

50mm

3. Operation Instructions

Function	Item	Status	Action	Remark
Bluetooth speaker sleep aid machine	Turn On	Power off	Turn the potentiometer button	Hear the sound of birds and enter the sleeper mode
	Turn Off	Bluetooth Mode/ Sleep Mode	Rotate the potentiometer button	
	Bluetooth Mode/ Sleep Mode	Power on	Long press the M key to switch	"Ding" sound
	Sleep music	Sleep Mode	Click the M button to select the sound	Bird/Rain/Fire/White Noise/waves/wind
	Sleep timer	Sleep Mode	Click the timer button	Click 1 time for 15 minutes, click 2 times 2 for 30 minutes, click 3 times for 60 minutes
	Volume +	Bluetooth Mode/ Sleep Mode	Turn the potentiometer to the maximum position	
	Volume -	Bluetooth Mode/ Sleep Mode	Potentiometer to the minimum position	
LED light Statue	Earphone Function	Earphone	Plug into the headphone jack	
	While charging	Red light on		
	Battery is fully charged	Red light off		
	Sleep timer mode	Timing mode blue light on		15 minutes, 30 minutes, 60 minutes from left to right

4. Safety Instructions

In order to prevent some dangerous situations during usage, please read the safety instructions before usage.

- Please do not place the product near heating equipment such as heaters, microwave ovens, rice cookers, high voltage cookers, to prevent the product from overheating and causing a fire.
- Please do not drop or hit the product to avoid an explosion.
- When used by children, please ensure normal operation under adult supervision.
- Do not use in low temperature and humid environment, please use under the environment of 0-45℃.
- Do not disassemble or repair the product without authorization.
- Do not place the product within 20cm from the medical equipment to prevent Device interference occurs.
- When not in use, please unplug the product charger from the socket to avoid draining battery life or causing damage.

5. FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

折痕 不印刷