

材质：80G 书写纸

单色黑白印刷

Value=1 Purple	Value=5 Green	Second button release send SWITCH_MULTILEVEL_STOP_LEVEL_CHANGE	FCC warning:	MEDICAL EQUIPMENT
Value=2 Orange	Value=6 Blue	Group 5	This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference.	Please DO NOT use this plug to control Medical or Life Support equipment. This device should never be used to control the On/Off status of Medical and/or Life Support equipment.
Value=3 Cyan		Third button hold more than 0.5s send SWITCH_MULTIT - LEVEL_START_LEVEL_CHANGE(Dim Up)	(2) This device must accept any interference received, including interference that may cause undesired operation, changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.	OTHER WARNINGS
(DEFAULT) : 3		Third button release send SWITCH_MULTILEVEL_STOP_LEVEL_CHANGE	NOTE:	Risk of Fire / Risk of Electrical Shock / Risk of Burns
Parameter 7 indicates LED Indicator Brightness. Choose the LED indicator Brightness level.		Fourth button hold more than 0.5s send SWITCH_MULTIT - LEVEL_START_LEVEL_CHANGE	This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:	IMPORTANT SAFETY INSTRUCTIONS
size=1 byte Available settings: 0-10		(Dim Down)	~ Reorient or relocate the receiving antenna.	1. READ AND FOLLOW ALL SAFETY INSTRUCTIONS.
Value=0 LED off		Fourth button release send SWITCH_MULTILEVEL_STOP_LEVEL_CHANGE	~ Increase the separation between the equipment and receiver.	2. Read and follow all instructions that are on the product or provided with the product.
Value=1 10% Brightness	Value=6 60% Brightness	Group 6 First button press 1x to toggle on/off (send basic set 0xff or 0x00).	~ Connect the equipment into an outlet on a circuit different from that to which the receiver is receiver is connected.	3. do not use an extension cord.
Value=2 20% Brightness	Value=7 70% Brightness	Group 7 Second button press 1x to toggle on/off (send basic set 0xff or 0x00).	~ Consult the dealer or an experienced radio/TV technician for help.	4. Reference the National Electrical Code, NFPA 70, specifically for the installation of wiring and clearances from power and lighting conductors.
Value=3 30% Brightness	Value=8 80% Brightness	Group 8 Third button press 1x to toggle on/off (send basic set 0xff or 0x00).		5. Installation work and electrical wiring must be done by qualified person(s) in accordance with all applicable codes and standards, including fire-rated construction.
Value=4 40% Brightness	Value=9 90% Brightness	Group 9 Fourth button press 1x to toggle on/off (send basic set 0xff or 0x00).		6. do not install or use within 10 feet of a pool
Value=5 50% Brightness	Value=10 100% Brightness			7. do not use in a bathroom
(DEFAULT) : 5		Command Class		8. WARNING:
Scene Control:		Generic Device Class0x18 - WALL_CONTROLLER		Risk of Electric Shock.
This remote supports four scene controls		Specific Device Class0x00 - NOT_USED		When used outdoors, install only to a covered Class A GFCI protected receptacle that is weatherproof with the power unit connected to the receptacle. If one is not provided, contact a qualified electrician for proper installation. Ensure that the power unit and cord do not interfere with completely closing the receptacle cover.
Scene 1 : First Button	1-Tap/2-Tap/3-Tap/Held/Released	Command Classes:		9.WARNING:
Scene 2 : Second Button	1-Tap/2-Tap/3-Tap/Held/Released	0x5E - COMMAND_CLASS_ZWAVEPLUS_INFO		Risk of Electric Shock. Mount the unit at a height greater than 1 foot from the ground surface
Scene 3 : Third Button	1-Tap/2-Tap/3-Tap/Held/Released	0x85 - COMMAND_CLASS_ASSOCIATION		10.WARNING:
Scene 4 : Fourth Button	1-Tap/2-Tap/3-Tap/Held/Released	0x8E - COMMAND_CLASS_MULTICHANNEL_ASSOCIATION		Risk of Electric Fire. install only to a receptacle protected by 20A branch circuit over current protection.
Association Group:		0x59 - COMMAND_CLASS_ASSOCIATION_GRP_INFO		SAVE THESE INSTRUCTIONS – This manual contains important safety and operating instructions.
This remote supports 9 Association Group controls		0x55 - COMMAND_CLASS_TRANSPORT_SERVICE		
Support group number: 9		0x86 - COMMAND_CLASS_VERSION		
Each group max. Support 10 devices		0x72 - COMMAND_CLASS_MANUFACTURER_SPECIFIC		
Group 1 Lifeline		0x5A - COMMAND_CLASS_DEVICE_RESET_LOCALLY		
Group 2 First button press 1x send basic set 0xff, Second button press 1x send basic set 0x00.		0x73 - COMMAND_CLASS_POWERLEVEL		
Group 3 Third button press 1x send basic set 0xff, Fourth button press 1x send basic set 0x00.		0x80 - COMMAND_CLASS_BATTERY		
Group 4		0x9F - COMMAND_CLASS_SECURITY_2		
First button hold more than 0.5s send SWITCH_MULTIT - LEVEL_START_LEVEL_CHANGE(Dim Up)		0x5B - COMMAND_CLASS_CENTRAL_SCENE		
First button release send SWITCH_MULTILEVEL_STOP_LEVEL_CHANGE		0x87 - COMMAND_CLASS_INDICATOR		
Second button hold more than 0.5s send SWITCH_MULTIT - LEVEL_START_LEVEL_CHANGE(Dim Down)		0x70 - COMMAND_CLASS_CONFIGURATION		
		0x84 - COMMAND_CLASS_WAKE_UP		
		0x6C - COMMAND_CLASS_SUPERVISION		
		0x7A - COMMAND_CLASS_FIRMWARE_UPDATE_MD		