

PHILIPS

Wireless
Microphone
DLM3401



 www.philips.com/support




General specification

Microphone type: Moving coil (Dynamic)
Polar pattern: Cardioid
Transmit and receive distance: >20 meter
Frequency response: 60Hz –13KHz
THD: <1%(1kHz)
Sensitivity: -52dB ±3dB
Receiver connector: 1/4" (6.3mm)
Receiver rechargeable battery: Lithium-ion Polymer 1200mAh
Microphone battery: 2 x AA (not included)

Preparation

1. Insert 2 AA batteries (not included) into the microphone handset.
2. Fully charge the receiver using a USB charger (not included) via the USB-C port.




Setup

1. Long press the receiver power button until the blue light starts blinking.
2. Long press the microphone power button until the light turns on.
3. The microphone and receiver will pair automatically. Both lights will stop blinking once the connection is successful.

Plug and Play

1. Plug the receiver into the microphone jack of your audio set or receiver.
2. If your device has a 3.5mm jack, use the provided 6.3mm-to-3.5mm adaptor.
3. The microphone is preset to normal sensitivity (volume). Adjust the sensitivity by short pressing the power button on the microphone.
4. Sensitivity levels will cycle through 4 levels. The microphone light will blink accordingly to indicate the level.
5. The battery level will be displayed on the microphone. Replace the batteries as needed.
6. Long press power button to shut down.



Safety

1. Do not place this product near fire sources or any overheated environment.
2. Do not use this product near or contact of water, and do not immerse this product in any liquid. Avoid water droplets or splashes on this product.
3. Fully recharge the receiver every 3 month to enhance battery lifespan.
4. Do not open or reassemble this product by yourself. Please consult qualified personnel to repair or replace the internal battery of the receiver if necessary.
5. Please unplug the charger (not included) promptly after charging the receiver to avoid long-term operation that may damage the battery.
6. Use this product in a well-ventilated environment to avoid interference and safety hazards caused by static electricity. Keep this product away from fire sources.
7. Turn off the product during airplane takeoff or landing to avoid safety hazards.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference,
(2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure statement. The device can be used in portable exposure condition without restriction.



Get product support at:
www.philips.com/support

Philips and the Philips Shield emblem are registered trademarks of Koninklijke Philips N.V. and are used under license. This product has been manufactured by and is sold under the responsibility of MMD Hong Kong Holding Limited or one of its affiliates, and MMD Hong Kong Holding Limited is the warrantor in relation to this product.