



4. Choose your formula

There are two options for you to choose the formula: "Scan" / "Manual"
Scan barcode of your formula, usually you can find the barcode on your formula can.




If you cannot find your formula by bar code scan, you can pick up the formula manually.




5. Add a new formula function

If you still can not find your formula in our formula database, you can add a new formula by yourself.



6. Set the temperature and water volume




Set the right temperature and water volume for your baby.



7. Click the Green button to make baby bottle

while the button turns green, that mean the water is ready , now you can press the green button and start to make your perfect baby bottle.

Note: The temperature increment/decrement is 2 degrees.



6 Safe Operation Instruction

Attention

1. Please read this instruction carefully before using.
2. This instruction manual contains important information and should not be discarded.
3. Always test the temperature before feeding to your baby.
4. Never pour boiling/hot water in water tank. Only prepare one bottle at a time, feed immediately & follow all instructions carefully.
5. Unboiled tap water and/or unsterilized baby bottles can potentially lead to adverse effects on the health of your baby.
6. Use purified water suitable for infant formula preparation.
7. Do not keep leftover formula mix. If your child was born premature, with low birth-weight or is immune deficient, please consult your pediatrician before using this machine.

Warning

1. If the power supply or power cord is damaged, Do not use them. It may cause fire, electric shock, or personal injury. Please contact customer support for more information.
2. Please do not connect the machine to high voltage over 110V AC.
3. Please don't insert anything such as your finger or metal tool into the gap of the precursor which may cause fire, electric shock, body injury or machine malfunction.
4. If you try to modify, disassemble, or repair this device by yourself, you will lose the manufacture warranty.
5. Do not plug or unplug the power supply directly with wet hands which may cause electric shock or body injury
6. Do not clean the ON/OFF button with water.
7. Do not touch the switch when your hand is wet which may cause electric shock or body injury.

8. Keep the machine away from children
9. Do not clean the non-movable parts of this machine.
10. Turn off and unplug the appliance from the outlet when not in use, before assembling or disassembling parts and before cleaning. To unplug, grasp the plug and pull from the outlet. Never pull from the power cord.
11. For household and indoor use only. Do not use it outdoors.
12. Do not attempt to use the machine without water in the water tank.

Storage, Transportation, and Operation Regulation

1. This Baby Formula machine should be transported at temperature of 41F to 86F with humidity less than 75%.
2. Avoid sharp temperature or humidity change.
3. If not using this machine for while, Please remove the powder box parts, funnel, funnel cover, drip tray and water tank from the base.

FCC Regulations

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment. The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radio Frequency (RF) Energy

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter and must be installed to provide a separation distance of at least 20cm from all persons.

7 Q & A

Q1. Can I use the machine without the app?

Yes. You can use the machine independently to make formula, adjust the temperature and water volume. However, the formula powder concentration setting is complicated on machine, so we will recommend you to install the app to enjoy more services.

Q2. If I have two smart devices, can I connect the machine at the same time?

Please log into the same account for the second device, but the first device will automatically log out for safety purpose.

Q3. How far can I control the formula machine with my mobile phone?

We use a Wi-Fi connection, so you can control the machine from anywhere as long as this machine and your smart device are connected to the same WiFi network.

Q4. What if the app doesn't match the formula I'm using?

We have created a database of all the major formula brands. If you can't find the corresponding formula powder, you can either add it yourself or contact us at customer-service@housingez.com for help.

Q5. What if the app connection fails?

1. Make sure the app is connected to the same Wi-Fi as your smart device.
2. Please check if the network environment is good.

Q6. What if I press the Start button, but the formula doesn't dispense?

1. The formula indicator is flashing, heating is not completed.
2. The machine is equipped with a bottle sensor to prevent milk overflow caused by unintentionally touching the start button after dispensing. During the second dispensing, please remove and reposition the bottle before the machine can be started. In addition, this function can be turned off in the app settings.

7 Q & A

Q7.What does E05 means on display?

E05 means the insufficient water in the tank. Please add more water.

Q8.What if the machine does not dispense water correctly?

The water volume is tested by electronic scale (deviation of 3%), if it exceeds this deviation, please contact customer service for calibration assistance.

Q9.How often to clean the funnel and powder box?

We will advice you clean the funnel and powder-dispensing hole every day. Remove and clean the powder box,once all formula powder in the powder box has been used up,

Q10.Why it dispense more milk volume than shown on the display?

The volume on the display is the water only,the actual volume of milk after mixing will be greater than the volume of water.,

8 Customer Support

If you have any questions about our product, please feel free to contact us (customerservice@housingez.com),or check www.livingez.co Our customer service will response in 24 hours.

9 Warranty Service

Standard One Year Manufacturer Warranty

This Limited Warranty applies only if you purchased LivingEZ product from an Authorized Reseller and is valid only in the original country of purchase. Buying through an unauthorized reseller or using this product outside the original country of purchase will automatically voids this warranty. This warranty is available to consumers only. You are a consumer if you own a LivingEZ product through retail purchase for personal, family or household use. Except as otherwise required under applicable law, this warranty is not available to retailers or other commercial purchasers or owners. We warrant that your LivingEZ product to be free from defects in workmanship and materials, under normal residential use and conditions, for a period of one (1) year for the original invoice date. Customer will be required to present original proof of purchase in order to obtain the warranty benefits. In the event that you do not have proof of purchase date, the purchase date for purposes of this warranty will be the date of manufacture. If your LivingEZ product should prove to be defective within the warranty period, we will repair it or, if we consider it necessary, replace it.

To obtain warranty services, please call Customer Service at 1(800) 829-1885 , customerservice@housingez.com or write to: LivingEZ, Unit 190,7250 Keele St,Concord,Canada L4K 1Z8 Attn: Customer Service. Please do not return any product without first contacting a Customer Service Representative.Shipping and handling fees are to be paid for by the customer.